



## 8Ch Mini NVR W/8 POE

# **NVR-ELE8-PS**



MOBILE APPS FREE MOBILE APPS FOR ANDRIOD AND IOS



FREE TECH SUPPORT FAST SERVICE SUPPORT

## **Cybersecurity Recommendations**

#### Mandatory actions to be taken towards cybersecurity

#### 1. Change Passwords and Use Strong Passwords:

The number one reason systems get "hacked" is due to having weak or default passwords. It is recommended to change default passwords immediately and choose a strong password whenever possible. A strong password should be made up of at least 8 characters and a combination of special characters, numbers, and upper and lower case letters.

#### 2. Update Firmware

As is standard procedure in the tech-industry, we recommend keeping NVR, DVR, and IP camera firmware up-to-date to ensure the system is current with the latest security patches and fixes.

#### "Nice to have" recommendations to improve your network security

#### 1. Change Passwords Regularly

Regularly change the credentials to your devices to help ensure that only authorized users are able to access the system.

#### 2. Change Default HTTP and TCP Ports:

• Change default HTTP and TCP ports for systems. These are the two ports used to communicate and to view video feeds remotely.

• These ports can be changed to any set of numbers between 1025-65535. Avoiding the default ports reduces the risk of outsiders being able to guess which ports you are using.

#### 3. Enable HTTPS/SSL:

Set up an SSL Certificate to enable HTTPS. This will encrypt all communication between your devices and recorder.

#### 4. Enable IP Filter:

Enabling your IP filter will prevent everyone, except those with specified IP addresses, from accessing the system.

#### 5. Change ONVIF Password:

On older IP Camera firmware, the ONVIF password does not change when you change the system's credentials. You will need to either update the camera's firmware to the latest revision or manually change the ONVIF password.

#### 6. Forward Only Ports You Need:

• Only forward the HTTP and TCP ports that you need to use. Do not forward a huge range of numbers to the device. Do not DMZ the device's IP address.

• You do not need to forward any ports for individual cameras if they are all connected to a recorder on site; just the NVR is needed.

#### 7. Disable Auto-Login on SmartPSS:

Those using SmartPSS to view their system and on a computer that is used by multiple people should

disable auto-login. This adds a layer of security to prevent users without the appropriate credentials from accessing the system.

#### 8. Use a Different Username and Password for SmartPSS:

In the event that your social media, bank, email, etc. account is compromised, you would not want someone collecting those passwords and trying them out on your video surveillance system. Using a different username and password for your security system will make it more difficult for someone to guess their way into your system.

#### 9. Limit Features of Guest Accounts:

If your system is set up for multiple users, ensure that each user only has rights to features and functions they need to use to perform their job.

#### 10. UPnP:

• UPnP will automatically try to forward ports in your router or modem. Normally this would be a good thing. However, if your system automatically forwards the ports and you leave the credentials defaulted, you may end up with unwanted visitors.

• If you manually forwarded the HTTP and TCP ports in your router/modem, this feature should be turned off regardless. Disabling UPnP is recommended when the function is not used in real applications.

#### 11. SNMP:

Disable SNMP if you are not using it. If you are using SNMP, you should do so only temporarily, for tracing and testing purposes only.

#### 12. Multicast:

Multicast is used to share video streams between two recorders. Currently there are no known issues involving Multicast, but if you are not using this feature, deactivation can enhance your network security.

#### 13. Check the Log:

If you suspect that someone has gained unauthorized access to your system, you can check the system log. The system log will show you which IP addresses were used to login to your system and what was accessed.

#### 14. Physically Lock Down the Device:

Ideally, you want to prevent any unauthorized physical access to your system. The best way to achieve this is to install the recorder in a lockbox, locking server rack, or in a room that is behind a lock and key.

#### 15. Connect IP Cameras to the PoE Ports on the Back of an NVR:

Cameras connected to the PoE ports on the back of an NVR are isolated from the outside world and cannot be accessed directly.

#### 16. Isolate NVR and IP Camera Network

The network your NVR and IP camera resides on should not be the same network as your public computer network. This will prevent any visitors or unwanted guests from getting access to the same network the security system needs in order to function properly.

## Regulatory Information

## **FCC** Information



Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

#### FCC conditions:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference.
- This device must accept any interference received, including interference that may cause undesired operation.

#### FCC compliance:

This equipment has been tested and found to comply with the limits for a digital device, pursuant to part 15 of the FCC Rules. This equipment generate, uses and can radiate radio frequency energy and, if not installed and used in accordance with the guide, may cause harmful interference to radio communication.

- For class A device, these limits are designed to provide reasonable protection against harmful interference in a commercial environment. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.
- For class B device, these limits are designed to provide reasonable protection against harmful interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
  - Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help.

## Table of Contents

1	Fea	ures and Specifications			
1.1 Overview					
1.2 Features		Features			
2	.1	Alarm Connection			
	2.1.1	Alarm Port			
	2.1.2	Alarm input port			
	2.1.3	Alarm input and output port			
	2.1.4	Alarm relay specifications			
2	.2	Bidirectional talk			
	2.2.1	Device-end to PC-end			
	2.2.2	PC-end to the device-end			
2	.3	Mouse Operation			
	.3 .4	Mouse Operation Remote Control			
	.4				
2 3	.4	Remote Control			
2 3 3	.4 Dev	Remote Control			
2 3 3 3	.4 Dev .1	Remote Control ice Installation Device Installation Diagrams			
2 3 3 3 3	.4 Dev .1 .2	Remote Control ice Installation Device Installation Diagrams Check Unpacked NVR			
2 3 3 3 3	.4 Dev .1 .2 .3	Remote Control ice Installation Device Installation Diagrams Check Unpacked NVR About Front Panel and Rear Panel HDD Installation			
2 3 3 3 3	.4 Dev .1 .2 .3 .4	Remote Control ice Installation Device Installation Diagrams Check Unpacked NVR About Front Panel and Rear Panel HDD Installation I Smart 1U Series			
2 3 3 3 3	.4 Dev .1 .2 .3 .4 3.4.	Remote Control ice Installation Device Installation Diagrams Check Unpacked NVR About Front Panel and Rear Panel HDD Installation 1 Smart 1U Series 2 Mini 1U/Compact 1U Series			

3.5 CD-		CD-ROM Installation	
4	4 Local Basic Operation		
4.1 Getting Started			
	4.1.1	Boot up and Shut down	
	4.1.2	2 Device Initialization	
	4.1.3	8 Reset Password	
	4.1.4	Quick Settings	
	4.2	Camera	
	4.2.1	Connection	
	4.2.2	2 Remote Device Initialization	
	4.2.3	Short-Cut Menu to Register Camera	
	4.2.4	Image	
	4.2.5	5 Encode	
	4.2.6	6 Channel Name	
	4.2.7	7 Remote Upgrade	
	4.2.8	Remote Device Info	

4.3	.3 Preview		
4.3.	4.3.1 Preview		
4.3.	2	Navigation bar	
4.3.	3	Preview Control Interface	
4.3.	4	Right Click Menu	
4.3.	5	Edit View (Sequence)	
4.3.	6	Preview Display Effect Setup	
4.3.	7	Fisheye (Optional)	
4.4	PT	Z	
4.4.		PTZ Settings	
4.4.	2	PTZ Control	
4.5	Re	cord File	
4.6		yback and Search	
4.6.		Instant Playback	
4.6.		Search Interface	
4.6.		Smart Search Playback	
4.6.		Mark Playback	
4.6.		Playback Image	
4.6.		Splice Playback	
4.6.		Smart Playback	
4.6.		File List	
4.6.		Other Aux Functions	
4.7		ent Manager	
4.7		Video Detect	
4.7.		Smart Plan	
4.7.	-	IVS (General Behavior Analytics) (Optional)	
4.7.		Face Detect (Optional)	
4.7.		People Counting (Optional)	
4.7.		Heat Map	
4.7.		Plate Recognition	
4.7.		Audio Detect (Optional)	
4.7.		Alarm Settings	
4.7.		Abnormality	
4.7.		Alarm output	
4.7.		POS	
4.8		twork	
4.8		Network Settings	
4.8		Network Test	
4.9		brage	
4.9		Basic	
4.9	.2	Schedule	
4.9		HDD	
4.9	.4	FTP	
4.9.	5	Record Control	
4.9.	6	HDD Information	
4.9.	7	HDD Group	
4.9.	8	HDD Detect	
4.9.	9	RAID Manager	
4.10	De	vice Maintenance and Manager	

4.	.10.1	Account
4.	.10.2	System Info
4.	.10.3	Voice
4.	.10.4	RS232
4.	.10.5	Broadcast
4.	.10.6	Security
4.	.10.7	Auto Maintain
4.	.10.8	Backup
4.	.10.9	Default
4.	.10.10	Upgrade
4.11	1 Log	out /Shutdown/Restart
5 W	Veb Op	eration
5.1	Ger	eral Introduction
5.	.1.1	Preparation
5.2	Dev	ice Initialization
5.3	Log	in
5.4	Res	et Password
5.5		I Mode
5.6	Rea	I-time Monitor
5.7	PTZ	,
5.8	Ima	ge/Alarm-out
5.	.8.1	Image
5.	.8.2	Alarm output
5.9	Zero	p-channel Encode
5.10	O WA	N Login
5.11	1 Set	nb
5.	.11.1	Camera
5.	.11.2	Network
5.	.11.3	Event
5.	.11.4	Storage
5.	.11.5	Setting
5.12	2 Info	rmation
5.	.12.1	Version
5.		Log
5.	.12.3	Online User
5.	.12.4	People Counting
5.	.12.5	Heat Map
		HDD
5.13		/back
5.	.13.1	Search Record
5.	13.2 F	File List
5.	13.3 F	Playback
5.		Download
		Load more
5.14		rt Playback
5.		VS (Behavior Analytics)
5.		Plate Recognition
		Human Face
5.15		n
5.16	Ũ	out
5.17	′ Un-i	nstall Web Control

6	Glossary
	FAQ
	Appendix A HDD Capacity Calculation
9	Appendix B Compatible Network Camera List

## General

This user's manual (hereinafter referred to be "the Manual") introduces the installation, functions and operations of the Network Video Recorder (NVR) devices (hereinafter referred to be "the Device").

## Safety Instructions

The following categorized signal words with defined meaning might appear in the Manual.

Signal Words	Meaning
	Indicates a high potential hazard which, if not avoided, will result in death or serious injury.
	Indicates a medium or low potential hazard which, if not avoided, could result in slight or moderate injury.
	Indicates a potential risk which, if not avoided, may result in property damage, data loss, lower performance, or unpredictable result.
	Indicates dangerous high voltage. Take care to avoid coming into contact with electricity.
	Indicates a laser radiation hazard. Take care to avoid exposure to a laser beam.
ESD	Electrostatic Sensitive Devices. Indicates a device that is sensitive to electrostatic discharge.
©TIPS	Provides methods to help you solve a problem or save you time.
	Provides additional information as the emphasis and supplement to the text.

## **Revision History**

No. Version Revision Content Release Time
---

No.	Version	Revision Content	Release Time
1	V1.0.0	First Release.	-
2	V3.0.0	<ul> <li>Add new modules.</li> <li>Baseline switch and update screen interfaces.</li> <li>Add new models.</li> </ul>	May 10, 2016
3	V4.0.0	<ul> <li>Add cloud update module.</li> <li>Baseline switch and update screen interfaces.</li> </ul>	August 15, 2017
4	V4.1.0	<ul><li>Update POS.</li><li>Modify pictures with QR code and SN.</li></ul>	September 6, 2017
5	V4.2.0	Add models.	September 21, 2017
6	V4.3.0	Delete old models and add new models. Update relevant information.	October 12, 2017
8	V4.3.1	Add new models and update relevant information.	April 28, 2018
9	V4.3.2	Add Privacy Protection Notice and update About the Manual.	May, 2018
10	V4.4.2	<ul> <li>Add GDPR information.</li> <li>Add FCC information.</li> <li>Update HDD installation.</li> </ul>	June, 2018
11	V4.4.3	<ul> <li>Add Compact 1U 4K(S2) with Wireless and Smart 1U 4K(S2) with Wireless. Add Wi-Fi AP and Repeater functions.</li> </ul>	July, 2018

## **Privacy Protection Notice**

As the device user or data controller, you might collect personal data of others' such as face, fingerprints, car plate number, Email address, phone number, GPS and so on. You need to be in compliance with the local privacy protection laws and regulations to protect the legitimate rights and interests of other people by implementing measures include but not limited to: providing clear and visible identification to inform data subject the existence of surveillance area and providing related contact.

## About the Manual

- The Manual is for reference only. If there is inconsistency between the Manual and the actual product, the actual product shall govern.
- We are not liable for any loss caused by the operations that do not comply with the Manual.
- The Manual would be updated according to the latest laws and regulations of related regions. For detailed information, see the paper User's Manual, CD-ROM, QR code or our official website. If there is inconsistency between paper User's Manual and the electronic version, the electronic version shall prevail.

- All the designs and software are subject to change without prior written notice. The product updates might cause some differences between the actual product and the Manual. Please contact the customer service for the latest program and supplementary documentation.
- There still might be deviation in technical data, functions and operations description, or errors in print. If there is any doubt or dispute, please refer to our final explanation.
- Upgrade the reader software or try other mainstream reader software if the Guide (in PDF format) cannot be opened.
- All trademarks, registered trademarks and the company names in the Manual are the properties of their respective owners.
- Please visit our website, contact the supplier or customer service if there is any problem occurred when using the device.
- If there is any uncertainty or controversy, please refer to our final explanation.

## Important Safeguards and Warnings

The following description is the correct application method of the device. Read the manual carefully before use to prevent danger and property loss. Strictly conform to the manual during application and keep it properly after reading.

## **Operating Requirement**

- Install the POE front-end device indoors.
- The device does not support wall mount.
- Don't place and install the device in an area exposed to direct sunlight or near heat generating device.
- Don't install the device in a humid, dusty or fuliginous area.
- Keep its horizontal installation, or install it at stable places, and prevent it from falling.
- Don't drip or splash liquids onto the device; don't put on the device anything filled with liquids, in order to prevent liquids from flowing into the device.
- Install the device at well-ventilated places; don't block its ventilation opening.
- Use the device only within rated input and output range.
- Don't dismantle the device arbitrarily.
- Transport, use and store the device within allowed humidity and temperature range.

## **Power Requirement**

- Make sure to use the designated battery type. Otherwise there may be explosion risk.
- Make sure to use batteries according to requirements; otherwise, it may result in fire, explosion or burning risks of batteries!
- To replace batteries, only the same type of batteries can be used.
- Make sure to dispose the exhausted batteries according to the instructions.
- The product shall use electric wires (power wires) recommended by this area, which shall be used within its rated specification.
- Make sure to use standard power adapter matched with this device. Otherwise, the user shall undertake resulting personnel injuries or device damages.
- Use power supply that meets SELV (safety extra low voltage) requirements, and supply power with rated voltage that conforms to Limited Power Source in IEC60950-1. For specific power supply requirements, please refer to device labels.
- Products with category I structure shall be connected to grid power output socket, which is equipped with protective grounding.
- Appliance coupler is a disconnecting device. During normal use, please keep an angle that facilitates operation.

## **1** Features and Specifications

## 1.1 Overview

This series NVR is a high performance network video recorder. This series product support local preview, multiple-window display, recorded file local storage, remote control and mouse shortcut menu operation, and remote management and control function.

This series product supports center storage, front-end storage and client-end storage. The monitor zone in the front-end can be set in anywhere. Working with other front-end devices such as IPC, NVS, this series product can establish a strong surveillance network via the CMS. In the network system, there is only one network cable from the monitor center to the monitor zone in the whole network. There is no audio/video cable from the monitor center to the monitor zone. The whole project is featuring of simple connection, low-cost, low maintenance work.

This series NVR can be widely used in many areas such as public security, water conservancy, transportation and education.

Cloud	<ul> <li>For the NVR connected with the Internet, it supports online upgrade to</li></ul>	
Upgrade	update applications.	
Real-time	<ul> <li>VGA, HDMI port. Connect to monitor to realize real-time surveillance.</li></ul>	
Surveillance	Some series support TV/VGA/HDMI output at the same time. <li>Short-cut menu when preview.</li> <li>Support popular PTZ decoder control protocols. Support preset, tour and pattern.</li>	
Playback	<ul> <li>Support each channel real-time record independently, and at the same time it can support search, forward play, network monitor, record search, download and etc.</li> <li>Support various playback modes: slow play, fast play, backward play and frame by frame play.</li> <li>Support time title overlay so that you can view event accurate occurred time</li> <li>Support specified zone enlargement.</li> </ul>	
User	<ul> <li>Each group has different management powers that can be edited freely.</li></ul>	
Management	Every user belongs to an exclusive group.	
Storage	<ul> <li>Via corresponding setup (such as alarm setup and schedule setup), you can backup related audio/video data in the network video recorder.</li> <li>Support Web record and record local video and storage the file in the client end.</li> </ul>	
Alarm	<ul> <li>Respond to external alarm simultaneously (within 200MS), based on user's pre-defined relay setup, system can process the alarm input correctly and prompt user by screen and voice (support pre-recorded audio).</li> <li>Support central alarm server setup, so that alarm information can remotely notify user automatically. Alarm input can be derived from</li> </ul>	

## 1.2 Features

	various connected peripheral devices.			
	Alert you via email/sms.			
Network Monitor	<ul> <li>Through network, sending audio/video data compressed by IPC or NVS to client-ends, then the data will be decompressed and display.</li> <li>Support max 128 connections at the same time.</li> <li>Transmit audio/video data by HTTP, TCP, UDP, MULTICAST, RTP/RTCP and etc.</li> <li>Transmit some alarm data or alarm info by SNMP.</li> </ul>			
	<ul> <li>Support WEB access in WAN/LAN.</li> </ul>			
Window Split	• Adopt the video compression and digital process to show several windows in one monitor. Support 1/4/8/9/16/ 25/36-window display when preview and 1/4/9/16-window display when playback.			
Record	<ul> <li>Support normal/motion detect/alarm record function. Save the recorded files in the HDD, USB device, client-end PC, or network storage server. You can search or playback the saved files at the local-end or via the Web/USB device.</li> </ul>			
Backup	<ul> <li>Support network backup, USB2.0 record backup function, the recorded files can be saved in network storage server, peripheral USB2.0 device, burner and etc.</li> </ul>			
Network Management	<ul><li>Supervise NVR configuration and control power via Ethernet.</li><li>Support management via WEB.</li></ul>			
Peripheral Equipment Management	<ul> <li>Support peripheral equipment management such as protocol setup and port connection.</li> <li>Support transparent data transmission such as RS232 (RS-422), RS485 (RS-485).</li> </ul>			
<ul> <li>Support switch between NTSC and PAL.</li> <li>Support real-time system resources information and runr display.</li> <li>Support log file.</li> <li>Local GUI output. Shortcut menu operation via mouse.</li> </ul>				
	<ul> <li>IR control function (For some series product only.). Shortcut menu operation via remote control.</li> <li>Play the video/audio from the network camera or NVS remotely.</li> </ul>			

## 2 Alarm Connection

## 2.2.1 Alarm Port

The alarm port is shown as below. See Figure 2-69. The following figure for reference only.



Figure 2-69

Icon	Function
1~16	ALARM1~ALARM16. The alarm becomes activated in the
	low level.
NO1 C1, NO2 C2, NO3 C3, NO4	Four NO activation output groups. (On-off button).
C4	
NO5 C5 NC5	One NO/NC activation output group. (On-off button).
CTRL 12V	Control power output. Disable power output when alarm is
	canceled. Current is 500mA.
+12V	Rated current output. Current is 500mA.
	GND
A/B	485 communication port. They are used to control devices
	such as PTZ. Please parallel connect $120T\Omega$ between A/B
	cables if there are too many PTZ decoders.

Note

- Different models support different alarm input ports. Please refer to the specifications sheet for detailed information.
- Slight difference may be found on the alarm port layout.

### 2.3.2 Alarm input port

Connect the positive end (+) of the alarm input device to the alarm input port (ALARM IN 1~16) of the

NVR. Connect the negative end (-) of the alarm input device to the ground end (=) of the NVR.



Figure 2-70

## 

- There are two alarm input types: NO/NC.
- When connect the ground port of the alarm device to the NVR, you can use any of the GND ports



- Connect the NC port of the alarm device to the alarm input port (ALARM) of the NVR.
- When there is peripheral power supplying for the alarm device, please make sure it is earthed with the NVR.

### 2.2.3 Alarm input and output port

- There is peripheral power supplying for the external alarm device.
- In case overload may result in NVR damage, please refer to the following relay specifications for detailed information.
- A/B cable of the RS485 is for the A/B cable connection of the speed PTZ.

#### 2.2.4 Alarm relay specifications

Model:	JRC-27F	
Material of the touch	Silver	
Rating	Rated switch capacity	30VDC 2A, 125VAC 1A
Resistance	Maximum switch power	125VA 160W
Load)	Maximum switch voltage	250VAC, 220VDC
	Maximum switch currency	1A
Insulation	Between touches with same	1000VAC 1minute
	polarity	

	Between touches with different polarity	1000VAC 1minute
	Between touch and winding	1000VAC 1minute
Surge voltage	Between touches with same polarity	1500V (10×160us)
Length of open time	3ms max	
Length of close time	3ms max	
Longevity	Mechanical	50×106 MIN (3Hz)
	Electrical	200×103 MIN (0.5Hz)
Temperature	-40℃ ~+70℃	

## 2.3 Bidirectional talk

## 2.3.1 Device-end to PC-end

#### **Device Connection**

Please connect the speaker or the pickup to the first audio input port in the device rear panel. Then connect the earphone or the sound box to the audio output port in the PC.

Login the Web and then enable the corresponding channel real-time monitor.

Please refer to the following interface to enable bidirectional talk. See Figure 2-71.



Figure 2-71

#### Listening Operation

At the device end, speak via the speaker or the pickup, and then you can get the audio from the earphone or sound box at the pc-end. See Figure 2-72.





### 2.3.2 PC-end to the device-end

#### **Device Connection**

Connect the speaker or the pickup to the audio output port in the PC and then connect the earphone or the sound box to the first audio input port in the device rear panel.

Login the Web and then enable the corresponding channel real-time monitor.

Please refer to the above interface (Figure 2-71) to enable bidirectional talk.

### **Listening Operation**

At the PC-end, speak via the speaker or the pickup, and then you can get the audio from the earphone or sound box at the device-end. See Figure 2-73.





## 2.4 Mouse Operation

Please refer to the following sheet for mouse operation instruction.

Left click	When you have selected one menu item, left click mouse to view menu content.		
mouse	Modify checkbox or motion detection status.		
	Click combo box to pop up dropdown list		
	In input box, you can select input methods. Left click the corresponding button		
	on the panel you can input numeral/English character (small/capitalized). Here		
	← stands for backspace button stands for space button.		
	In English input mode: _stands for input a backspace icon and $\leftarrow$ stands for		
	deleting the previous character.		
	! ? @ # \$ % = + * - ← 123		
	awertvuiop/456		
	asdfqhjkl:Enter 789		
	$z \times c \vee b \cap m$ , Shift $\Box 0 \&$		
	! ? @ # \$ % = + * - ← 1 2 3		
	QWERTYUIOP7 456		
	ASDFGHJKL: Enter 789		
	$Z \times C \vee B \wedge M$ , Shift $\square 0 \&$		
	In numeral input mode: $\_$ stands for clear and $\leftarrow$ stands for deleting the		
	previous numeral.		
Double left	Implement special control operation such as double click one item in the file list		
click mouse	to playback the video.		

	In multiple-window mode, double left click one channel to view in full-window. Double left click current video again to go back to previous multiple-window mode.
Right click	In real-time monitor mode, pops up shortcut menu.
mouse	Exit current menu without saving the modification.
Press middle	In numeral input box: Increase or decrease numeral value.
button	Switch the items in the check box.
	Page up or page down
Move mouse	Select current control or move control
Drag mouse	Select motion detection zone
	Select privacy mask zone.

## 2.5 Remote Control

The remote control interface is shown as in Figure 2-74.

Please note remote control is not our standard accessory and it is not included in the accessory bag.



Figure 2-74

Serial Number	Name	Function
1	Power button	Click it to boot up or shut down the device.
2	Address	Click it to input device number, so that you can control it.

3	Forward	Various forward speeds and normal speed playback.
4	Slow play	Multiple slow play speeds or
		normal playback.
5	Next record	In playback mode, playback the next video.
	Previous record	In playback mode, playback the
6		previous video.
7	Play/Pause	In pause mode, click this button
		to realize normal playback.
		In normal playback click this
		button to pause playback.
		In real-time monitor mode, click
		this button to enter video search
		menu.
	Reverse/pause	Reverse playback pause mode,
8	•	click this button to realize normal
		playback.
		In reverse playback click this
		button to pause playback.
	Esc.	Go back to previous menu or
9		cancel current operation (close
		upper interface or control)
10	Record	Start or stop record manually
		In record interface, working with
		the direction buttons to select the
		record channel.
		Click this button for at least 1.5
		seconds, system can go to the
		Manual Record interface.
11	Direction keys	Switch current activated control,
		go to left or right.
		In playback mode, it is to control
		the playback process bar.
		Aux function(such as switch the
		PTZ menu)
12	Enter /menu key	go to default button
		go to the menu
13	Multiple-window switch	Switch between multiple-window
		and one-window.
14	Fn	In 1-ch monitor mode: pop up
		assistant function:PTZ control
		and Video color.
		Switch the PTZ control menu in
		PTZ control interface.

	In motion detection interface, working with direction keys to complete setup. In text mode, click it to delete	
		character.
15	0-9 number key	Input password, channel or switch channel.
		Shift is the button to switch the input method.

## 3 Device Installation

Note: All the installation and operations here should conform to your local electric safety rules.

## 3.1 Device Installation Diagrams

Please refer to the following diagrams to install the NVR.



## 3.2 Check Unpacked NVR

When you receive the NVR from the forwarding agent, please check whether there is any visible damage. The protective materials used for the package of the NVR can protect most accidental clashes during transportation. Then you can open the box to check the accessories.

Please check the items in accordance with the list. Finally you can remove the protective film of the NVR.

## 3.3 About Front Panel and Rear Panel

The model number in the stick on the bottom of NVR is very important; please check according to your purchase order.

The label in the rear panel is very important too. Usually we need you to represent the serial number when we provide the service after sales.

## 3.4 HDD Installation

For the first time installation, make sure whether the HDD has been installed or not. It is recommended to use the company's recommended HDD brand (high-speed HDD with 7200 RPM or above). It is not recommended to use PC HDD.

## 

- Shut off the power before you replace the HDD.
- Use the dedicated SATA HDD for monitoring recommended by the HDD manufacturer.
- You can refer to the Appendix for HDD space information and recommended HDD brand.

## 3.4.1 Tiny 1U

#### Note

Connect cable and then secure the HDD on the NVR if it is not convenient to connect the HDD data cable and power cable at first.





Place

(2)



①. Loosen the screws of the bottom of the chassis.



④ Connect the HDD cable and power cable to the HDD and the mainboard respectively.



the

HDD

in

③ Turn the device upside down and then secure the screws firmly.



(5) Put the cover back and then fix the screws of the rear panel. The installation is complete.

#### 3.4.2 Mini 1U/Compact 1U Series



①. Loosen the screws of the upper





(4) Place the HDD in accordance

with the four holes on the bottom of fix the screws to secure the HDD the chassis.



② Connect the one end of the HDD data cable and the power cable to the mainboard.



(5) Turn the device upside down;

on the bottom of the chassis.



③ Connect the other end of the HDD data cable and the power cable to the HDD.



6 Put the cover in accordance with the clip and then fix the screws on the rear panel and side panel.

#### 3.4.3 1U Series

#### The following figures are based on the professional 1U with 8 PoE ports series. Note

Connect cable and then secure the HDD on the NVR if it is not convenient to connect the HDD data cable and power cable at first.



 ${\ensuremath{\textcircled{}}}$  Loosen the screws of the rear panel and side panel.



2 Place the HDD in accordance with the four holes in the bottom.



③Turn the device upside down and then secure the screws firmly. It is to fix the HDD on the chassis.





④Connect the HDD cable and power cable.

<sup>(5)</sup>Put the cover in accordance with the clip and then fix the screws on the rear panel and side panel.

### 3.4.4 1.5U Series



- 1 Use the screwdriver to loose the screws of the rear panel and then remove the front cover.
- ② Put the HDD to the HDD bracket in the chassis and then line up the four screws to the four holes in the HDD. Use the screwdriver to fix the screws firmly to secure HDD on the HDD bracket



③ Connect to the HDD data cable to the main board and the HDD port respectively. Loosen the power cable of the chassis and connect another end of the power cable to the HDD port.



(4) After connect the cable, put the front cover back to the device and then fix screws of the rear panel.

#### 3.4.5 General 2U Series



① ①Use the screwdriver to loose the screws of the rear panel and then remove the front cover.



② 2Put the HDD to the HDD bracket in the chassis and then line up the four screws to the four holes in the HDD. Use the screwdriver to fix the screws firmly to secure HDD on the HDD bracket





③Connect to the HDD data cable to the main board and the HDD port respectively. Loosen the power cable of the chassis and connect another end of the power cable to the HDD port.

(4) After connect the cable, put the front cover back to the device and then fix screws of the rear panel.

## 3.5 CD-ROM Installation

Please follow the steps listed below.



HDD bracket



bracket.



① Open top cover and then remove the ② Take off the bottom of the HDD bracket and CD-ROM bracket.



③ Fix the CD-ROM bracket at the HDD ④ Install a pair of the CD-ROM bracket. Please make sure the reverse side is secure too.



5 Install SATA burner. Line up the SATA burner to the hole positions.



(6)User screwdriver to fix the screws.



⑦ Put the bracket back. Please adjust the CD-ROM to the proper position so that the button of the front panel is directly facing the pop-up button of the CD-ROM.



(9) Secure the HDD bracket and put the top cover back.



8 Connect the SATA cable and power wire.

## 4 Local Basic Operation

## D Note

Slight difference may be found on the user interface. The following figures for reference only.

## 4.1 Getting Started

## 4.1.1 Boot up and Shut down

4.1.1.1 Boot up

## 

Before the boot up, please make sure:

- For device security, please connect the NVR to the power adapter first and then connect the device to the power socket.
- The rated input voltage matches the device power on-off button. Please make sure the power wire connection is OK. Then click the power on-off button.
- Always use the stable current, if necessary UPS is a best alternative measure.

Please follow the steps listed below to boot up the device.

- Step 1 Connect the device to the monitor and then connect a mouse.
- Step 2 Connect power cable.
- Step 3 Click the power button at the front or rear panel and then boot up the device. After device booted up, the system is in multiple-channel display mode by default.

## 4.1.1.2 Shutdown

## D Note

- When you see corresponding dialogue box "System is shutting down..." Do not click power on-off button directly.
- Do not unplug the power cable or click power on-off button to shutdown device directly when device is running (especially when it is recording.)

There are three ways for you to log out.

a) Main menu (**RECOMMENDED**)

From Main Menu->Shutdown, select shutdown from dropdown list.

Click OK button, you can see device shuts down.

b) From power on-off button on the front panel or remote control.

Press the power on-off button on the NVR front panel or remote control for more than 3 seconds to shut down the device.

c) From power on-off button on the rear panel.

## 4.1.2 Device Initialization

If it is your first time to use the device, please set a login password of **admin** (system default user). You can select to use unlock pattern to login or not at your own choosing.

## D Note

For your device safety, please keep your login password of **admin** well after the initialization steps, and change the password regularly.

Please follow the steps listed below.

#### Step 1 Boot up NVR.

Device displays device initialization interface. See Figure 4-1.

	Device Initialization	
Enter Password	2 Unlock Pattern	3 Password Protection
	Username admin	
	Password It is 8 to 32-digit containing letter(s), ontains at least two types.	number(s),symbol(s). It c
	Confirm Password	
	Prompt Question	
		Next

Figure 4-1

#### Step 4 Set login password of admin.

- User name: The default user name is **admin**.
- Password/confirm password: The password ranges from 8 to 32 digitals. It can contain letters, numbers and special characters (excluding "!", "!", ";", ":", "&"). The password shall contain at least two categories. Usually we recommend the strong password.
- Prompt question: If you set the prompt question here. On the login interface, move your mouse

on 📠, device can display the corresponding prompt question for you to remind the password.



STRONG PASSWORD RECOMMENDED-For your device own safety, please create a strong password of your own choosing. We also recommend you change your password periodically especially in the high security system.

Step 5 Click Next, device goes to the following interface. See Figure 4-2.



Figure 4-2

Step 6 Set unlock pattern.

After set unlock pattern, device goes to password protection interrface. See Figure 4-3.



- Device adopts unlock pattern to login by default if you have set pattern here. If there is no unlock pattern, please input the password to login.
- Click Skip if there is no need to set unlock pattern.

		Device Initialization	
1 Er	nter Password	2 Unlock Pattern	8 Password Protection
✓ Email ✓ Security		(To reset pass	sword)
Question 1 Answer	(What is your favorite children's	book?	
Question 2 Answer	(What was the first name of your	r first boss?	
Question 3 Answer	(What is the name of your favori	ite fruit?	
			ОК

Figure 4-3

Step 7 Set security questions.



- After setting the security questions here, you can use the email you input here or answer the security questions to reset **admin** password. Refer to chapter 4.1.3 Reset password for detailed information.
- Cancel the email or security questions box and then click Next button to skip this step.
- Email: Input an email address for reset password purpose. In case you forgot password in the future, input the security code you got on the assigned email to reset the password of admin. If you have not input email here or you need to update the email information, please go to the main menu->Setting->System->Account to set. Refer to chapter 4.10.1 Account for detailed information.
- Security question: Set security questions and corresponding answers. Properly answer the questions to reset admin password. In case you have not input security question here or you need to update the security question information, please go to the main menu->Setting->System->Account->Security question to set. Refer to chapter 4.10.1.3 Security question for detailed information.

## Note

If you want to reset password by answering security questions, please go to the local menu interface.

Step 8 Click OK to complete the device initialization setup.

Device goes to startup wizard interface. Refer to chapter 4.1.4 Quick Settings for detailed information.

### 4.1.3 Reset Password

If you forgot the admin password, you can reset the password by the following ways:

- When the password reset function is enabled, you can scan the QR code on the local interface to reset the password.
- When the password reset function is disabled, you can reset password via the security questions configured before. If the secury questions are not configured, system displays that Password reset is closed! You need to contact the customer service for help.
- Step 1 Go to the device login interface. See Figure 4-4 or Figure 4-5. .
  - If you have set unlock pattern, device displays unlock pattern login interface. See Figure 4-4.
     Click "Forgot Unlock Pattern" and device goes to Figure 4-5.
  - If you have not set unlock pattern, device displays password interface. See Figure 4-5.

## III Note

Click Switch User button and NVR goes to general user login interface. The default user name is admin. Click the user name drop-down arrow, select a user from the drop-down list, and then you can log in via some other account.



Figure 4-4

SYSTEM LOGIN
User Name 🛛 admin 🔽 🖬 Password
🔒 Forgot password
OK Cancel

Figure 4-5

Step 2 Click

- If you have not input email address information when you are initializing the device, the interface is shown as in Figure 4-6. Please input an email address, click Next button, and then device goes to Figure 4-7.
- If you have input email when you are initializing the device, device goes to Figure 4-7.

Reset
Reset Type Email
Email (To reset password)
Next Cancel

Figure 4-6



Figure 4-7

Step 3 Click OK button and device goes to Figure 4-8

## 🛄 NOTE

After clicking OK, we will collect your personal information such as cell phone number, MAC address and device serial number. The collected information is used for verifying device legality and sending security code. Please read the notice carefully and confirm if you agree with the collection or not.



Figure 4-8

Step 4 Reset login password.

There are two ways to reset the password: Scanning QR code and resetting by email and answering security questions (local menu only)

Email

In Figure 4-8, follow the prompts on the interface to scan the QR code, and then input the security code you get via the assigned email.



- For the same QR code, max scan twice to get two security codes. Refresh the QR code if you want to get security code again.
- The security code on your email is only valid for 24 hours.
- Security questions

In Figure 4-6, select security question from the drop down list. Device displays security question interface. See Figure 4-9. Please input the correct answers here.

You shall configure the security questions before resetting password by answering the questions. If you have not configured the questions, this method will not be available in the drop-down list.

	Reset
Reset Type	Security Question
Question 1 Answer	What is your favorite cl <mark>u</mark> ildren's book?
Question 2 Answer	What was the first name of your first boss?
Question 3 Answer	When did you last enroll?
	Next Cancel

Figure 4-9

Step 5 Click Next button.

Device displays reset password interface. See Figure 4-10.
Reset
Reset password of (admin)
New Password
It is 8 to 32-digit containing letter(s), number(s),symbol(s). It contains at least two types.
Confirm Password
7
OK Cancel

Figure 4-10

Step 6 Input new password and then confirm.

The password can be set from 8 characters through 32 characters and contain at least two types from number, letter and special character (excluding"", """, ";", ":" and "&"). It is recommended to set password of high security according to the prompts.

Step 7 Click OK button to complete the setup.

#### 4.1.4 Quick Settings

After you successfully initialize the device, it goes to startup wizard. Here you can quickly configure your device. It includes general setup, basic network setup, camera registration, P2P, and schedule interface.

```
III Note
```

- Once the power is off during the quick settings process, you need to go through startup wizard again when the device boot up the next time.
- After completing all items on the startup wizard, the startup wizard automatically hides when the device boot up the next time.

Please follow the steps listed below.

Boot up the device and complete the device initialization. Device goes to startup wizard. See Figure 4-11.

 Select Auto-check for updates, device automatically checks if there is new applications or not every day.





# Note

- After auto-check is enabled, in order to inform you of the latest firmware upgrades, we will collect your personal information such as IP address, device name, firmware version and device SN. The collected information is used for verifying device legality and pushing upgrade notice.
- 4.1.4.1 General

It is to set NVR basic information such as system date, holiday and etc.

General

It is to set device basic information such as device name, serial number and etc. Please follow the steps listed below.

Step 1 Click Next button,

Enter General interface.

Step 2 Click General button.

The interface is shown as below. See Figure 4-12.

### D Note

From Main menu->Setting->System->General->General, you can go to the general interface.

- Step 3 Set parameters.
  - Device ID: Please input a corresponding device name here.
  - Device No: When you are using one remote control (not included in the accessory bag) to control several NVRs, you can give a name to each NVR for your management.
  - Language: System supports various languages: Chinese (simplified), Chinese (Traditional), English, Italian, Japanese, French, Spanish (All languages listed here are optional. Slight difference maybe found in various series.)
  - Video standard: There are two formats: NTSC and PAL.

- HDD full: Here is for you to select working mode when hard disk is full. There are two options: stop recording or rewrite old files.
- Pack duration: Here is for you to specify record duration. The value ranges from 1 to 120 minutes. Default value is 60 minutes.
- Realtime play: It is to set playback time you can view in the preview interface. The value ranges from 5 to 60 minutes.
- Auto logout: Here is for you to set auto logout interval once login user remains inactive for a specified time. Value ranges from 0 to 60 minutes.
- Monitor channels when logout: Here you can set channels you want to view when your account has logged out. Click the button and then cancel the channel name box, you need

to login to view the corresponding video. The channel window displays

- Navigation bar: Check the box here, system displays the navigation bar on the interface.
- IPC Time Sync: You can input an interval here to synchronize the NVR time and IPC time.
- Startup wizard: Once you check the box here, system will go to the startup wizard directly when the system restarts the next time. Otherwise, it will go to the login interface.
- Mouse sensitivity: You can set double click speed via dragging the slide bard. You can Click Default button to restore default setup.

	_
General Date&Time Holiday	
Device Name NVR Device No. 8 Language ENGLISH ♥ Instant replay 5 Min. Auto Logout 10 Min. Monitor Channel(s)) ✓ IPC Time Sync 24 Hour Navigation Bar Mouse Sensitivity Slow Fast	
Default	
Back	

Figure 4-12

Step 4 Click Apply button to save settings.

Here you can set device time. You can enable NTP (Network Time Protocol) function so that the device can sync time with the NTP server.

Step 1 Click Date and time button. See Figure 4-13.

### Note

From Main menu->Setting->System->General->Date and time, you can go to the date and time interface.

- System time: Here is for you to set system time
- Date format: There are three types: YYYY-MM-DD: MM-DD-YYYYY or DD-MM-YYYY.
- Date separator: There are three denotations to separate date: dot, beeline and solidus.
- DST: Here you can set DST time and date by week or by date. Please enable DST function and then select setup mode. Please input start time and end time and click Save button.
- Time format: There are two types: 24-hour mode or 12-hour mode.
- NTP: It is to set NTP server, port and interval.



- System time is very important; do not modify time casually unless there is a must!
- ♦ Before your time modification, please stop record operation first!

GENERAL
General Date&Time Holiday
Date Format       YYYY M       Time Format       24-HOUR         Date Separator       -       -         System Time       2017 - 09 - 20       19 : 55 : 01       GMT+08:00       Save
DST DST Type O Week 🌑 Date
Start Time 🚯 2000 - 01 - 01 00 : 00
End Time 🚯 2000 - 01 - 01 00 : 00
Server (time.windows.com (Manual Update)
Port (123)(1~65535)
Interval 60 Min.
(Default) (Apply)
Back

Figure 4-13

Step 5 Click Apply button to save settings. Holiday Here you can add, edit, delete holiday. After you successfully set holiday information, you can view holiday item on the record and snapshot period.

Step 1 Click Holiday button. See Figure 4-14.

# III Note

From Main menu->Setting->System->General->Holiday, you can go to the holiday interface.

		GENERAL	_
General	Date&Time	Holiday	
0	Status	Holiday Name	
			(Add Holidays)
Defau	ult		Apply
Back			Next

Figure 4-14

Step 2 Click Add new holiday button, device displays the following interface. See Figure 4-15.

Add Holidays	
Holiday Name       1         Repeat Mode       Once OAlways         Holiday Range       Date O Week         Start Time       2017         End Time       2017         O9 - 20	
Add More	
Save Add Cancel	

Figure 4-15

Step 3 Set holiday name, repeat mode and holiday mode.

III Note

Click Add more to add new holiday information.

Step 4 Click Add button, you can add current holiday to the list.

### D Note

- Click the dropdown list of the state; you can enable/disable holiday date.
- $\diamond$  Click *l* to change the holiday information. Click *k* to delete current date.

Step 5 Click Apply button to save settings.

#### 4.1.4.2 Basic Network Settings

Set device IP address, DNS (Domain Name System) information.

#### Preparation

Make sure the device has properly connected to the network.

Step 1 Click Next button, device goes to TCP/IP interface. See Figure 4-16.

# D Note

- ♦ From Main menu->Setting->Network->TCP/IP, you can go to the TCP/IP interface.
- Different series products have different Ethernet adapter amount and type. Please refer to the actual product.

IP Address 192.168.1.108	Net Mode Single NIC	NIC Member 1	Edit	Unbond
	_	I	/	
68 1 108	Default Gatev	wav: 192 168 1	1	MTU: 1500
				Mode: STATI
8.8.8.	. 8_)			
8.8.4.	4			
nernet Port1 🔹				
	8.8.4.	0:22:aa:a1:31:32 Subnet Mask 8 . 8 . 8 . 8 8 . 8 . 4 . 4	0:22:aa:a1:31:32 Subnet Mask: 255.255.2 8 . 8 . 8 . 8 8 . 8 . 4 . 4	0:22:aa:a1:31:32       Subnet Mask:       255.255.255.0         •       •          •       •    <

Figure 4-16

Step 2 Click , device display edit interface. See Figure 4-17.

_	Edit
Ethernet Card Net Mode	Ethernet Port1 ● Single NIC
IP Version MAC Address IP Address Subnet Mask Default Gateway	IPv4         10:22:aa:a1:31:32         192 . 168 . 1 . 108         DHCP         255 . 255 . 255 . 0         192 . 168 . 1 . 1
мти	(1500
	OK Cancel

Figure 4-17

#### Step 3 Set parameters.

- Network Mode : Includes multiple access, fault tolerance, and load balancing
- Multiple-address mode: eth0 and eth1 operate separately. You can use the services such as HTTP, RTP service via eth00 or the eth1. Usually you need to set one default card (default setup is etho) to request the auto network service form the device-end such as DHCP, email, FTP and etc. In multiple-address mode, system network status is shown as offline once one card is offline.
- Network fault-tolerance: In this mode, device uses bond0 to communicate with the external devices. You can focus on one host IP address. At the same time, you need to set one master card. Usually there is only one running card (master card).System can enable alternate card when the master card is malfunction. The system is shown as offline once these two cards are both offline. Please note these two cards shall be in the same LAN.
- Load balance: In this mode, device uses bond0 to communicate with the external device. The eth0 and eth1 are both working now and bearing the network load. Their network load are general the same. The system is shown as offline once these two cards are both offline. Please note these two cards shall be in the same LAN.
  - Main Network Card: Please select eth0/eth1 (optional).after enable multiple access function.

### I Note

The dual-Ethernet port series support the above three configurations and supports functions as multiple-access, fault-tolerance and load balancing.

- MAC address: The host in the LAN can get a unique MAC address. It is for you to access in the LAN. It is read-only.
- IP address: Here you can use up/down button (▲▼) or input the corresponding number to input IP address. Then you can set the corresponding subnet mask the default gateway.

- Default gateway: Here you can input the default gateway. Please note system needs to check the validity of all IPv6 addresses. The IP address and the default gateway shall be in the same IP section. That is to say, the specified length of the subnet prefix shall have the same string.
- DHCP: It is to auto search IP. When enable DHCP function, you cannot modify IP/Subnet mask /Gateway. These values are from DHCP function. If you have not enabled DHCP function, IP/Subnet mask/Gateway display as zero. You need to disable DHCP function to view current IP information. Besides, when PPPoE is operating, you cannot modify IP/Subnet mask /Gateway.
- MTU: It is to set MTU value of the network adapter. The value ranges from 1280-7200 bytes. The default setup is 1500 bytes.
- Transfer mode: Here you can select the priority between fluency/video qualities.
- Step 4 Click OK to NIC settings.

Device goes back to TCP/IP interface.



Click 🞽 to cancel NIC bonding. Please note device needs to reboot to activate new setup.

- Step 5 Set network parameters.
  - IP Version: There are two options: IPv4 and IPv6. Right now, system supports these two IP address format and you can access via them.
  - Preferred DNS server: DNS server IP address.
  - Alternate DNS server: DNS server alternate address.
  - Default Network Card: Please select eth0/eth1/bond0(optional) after enable multiple-access function.
  - LAN download: System can process the downloaded data first if you enable this function. The download speed is 1.5X or 2.0X of the normal speed.

### Note

- For IPv6 version, the IP address, default gateway, preferred DNS; alternate DNS is 128-digit. Please fill in all items here.
- This function is for some series product only.

Step 6 Click Next to complete the settings.

#### 4.1.4.3 P2P

P2P is a kind of convenient private network penetration technology. You do not need to apply for dynamic domain name, doing port mapping or deploying transit server. You can add NVR devices through the below way to achieve the purpose of managing multiple NVR devices at the same time.

- Scan the QR code, download mobile app, and then register an account. For details, see Mobile App Operation.
- Log in www.gotop2p.com, register an account, and then add device via the serial number. For details, see Introduction of P2P Operations which is available in the disk delivered with the device.



#### Connect the NVR device to the Internet, otherwise P2P can not run properly.

Step 1 Enter from main menu -> Setting -> Network -> P2P.

SETTING 😪 CAMERA STORAGE SYSTEM **NETWORK** EVENT TCP/IP Enable PORT To assist you in remotely managing your device, the P2P will be enabled. After enabling P2P and connecting to Internet, we need to collect IP address, MAC PPPoE address, device name, device SN, etc. All collected info is used only for the purpose DDNS of remote access. If you don't agree to enable P2P function, please deselect the check box UPnP Status (Not Connected SYNC TIME RIG ... EMAIL SNMP MULTICAST Cellphone client SN ALARM CENTER REGISTER SWITCH Wi-Fi ٦ P2P Scan QR to download 1D005F8PAED4DN7 Cancel Apply

The P2P interface is displayed. See Figure 4-18.

Figure 4-18

- P2P is enbaled by default.
- When P2P is enabled and the device is connected to the Internet, it displays Online in the Status box.
   We need to collect information like IP address, MAC address, device name and device SN. All collected information is used only for the purpose of remote access.
- Step 2 Click Next to conplete the setting.If system displays Online in the Status box, P2P registration is successful.

### Mobile APP Operation

The following contents are introduced in the example of mobile App.

- Step 1 Scan the QR code to download and install the mobile App.
- Step 2 Select Camera and enter the main interface.
- Step 3 Register device in the mobile App:
  - 1) Click and select Device Manager. See Figure 4-19.

내 中国电信 🗢	4:03 PM	1 47% 💼		4:03 PM Live Previe	w	47% 💼	내 中国电信 중 4:04 PM	47% 💷
				0KB/s		OKB/s	Home	
			+				Live Preview	+
	CAMERA			0KB/s		0KB/s	Device Manager	
							💮 Local Files	
	DOOR		+					+
	ALARM							
	MORE		B	Q 1	2 C	>		Eg (
					5			
		S in Section		01 M	J @	· س	and the second	

Figure 4-19

2) Click and enter the Add Device interface.

Mobile App supports device initialization.

- 3) Select Wired Device -> P2P to enter the P2P interface.
- 4) Click the QR code icon behind the SN to enter the QR code scan interface.
- Scan the device label or scan the SN QR code got by entering from main menu -> Setup -> Network -> P2P. When the scan is successful, the device SN will be displayed in the SN item.
- 6) Enter name and password.

Step 4 After device registraion on mobile App, click Start Preview and you can see the monitor screen.

#### 4.1.4.4 Wi-Fi AP

4.1.4.4.1 General Settings

Configure the Wi-Fi parameters of the NVR device to make the Wi-Fi IPC automatically connect to it via this Wi-Fi.

- This function is available only for NVR devices with built-in Wi-Fi module. See the actual situation.
- When the Wi-Fi IPC and NVR are corollary devices, they can be paired automatically after device startup.

Step 1 From main menu > Setting > Network > Wi-Fi AP > General. The General interface is displayed. See Figure 4-20.

	SETTING	
😪 CAMERA	FINETWORK 🙀 EVENT STORAGE	SYSTEM
TCP/IP Port	General Advanced	
REPEATER WIFI AP	2.4GHz SSID (NVR-2.4G_4C)	
DDNS EMAIL	Encryption Type (WPA2 PSK Password (12345678	
REGISTER	Channel (Auto -	
P2P	Gain (Middle )	
	Default	(Apply)

Figure 4-20

Step 2 Select the 2.4GHz check box and configure the parameters. For details, see following table.

Function
Select the check box to enable Wi-Fi.
Enter the SSID name. You can use this name to search the device.
Select the encryption type from the dropdown list, including WPA2 PSK, WPA
PSK and OPEN.
Enter the SSID password. You can use this password to connect to the
network.
Select the channel to connect the Wi-Fi IPC.
Adjust the Wi-Fi signal intensity.

4.1.4.4.2 Advanced Settings

### 

This function is available only for NVR devices with built-in Wi-Fi module. See the actual situation.

You can configure the Wi-Fi IP address, subnet mask, default gateway and DHCP derver here.

Step 1 From main menu > Setting > Network > Wi-Fi AP > Advanced. The Advanced interface is displayed. See Figure 4-21.

Figure 4-21

Step 2 Configure the parameters. For details, see following table.

Parameter	Function
IP Address	Input the IP address, subnet mask and default gateway of the NVR Wi-Fi AP.
Subnet Mask	NOTE NOTE
Default Gateway	The IP address and default gateway shall be in the same network segment.
Start IP/End IP	Input start IP and end IP of DHCP server. The NVR device can allocate the IP address in the range you specified here.
Upgrade	Click it to upgrade Wi-Fi AP module.

#### 4.1.4.5 Registration

After add remote device, the device can receive, storage, and manage the video streams of the remote device. You can view, browse, playback, manage several remote devices at the same time.

Step 1 On the P2P interface, click Next button.

Enter remote device interface. See Figure 4-22.

# Note

There are two ways to go to Registration interface.

- From main menu->Setting->Camera->Registration, you can go to the registration interface.
- On the preview interface, right click mouse and then select Registration.

	_			Regist	tration				
Device S	Search) (IP A	ddres	; ] (		) (Sea	rch )	Uninitial		•
0	Modify S	itatus	IP Addres	s	Port		Device Name	Man	ufa
	$\neg$					L			
( Add	) (Manua	al Add	(Modify				Filter (Nu	,III	
Added D	evice —								
🗌 СН		era Na	me	Modify	Delete	Status	IP Address	Port	
🗌 D1	CAM 1			1	×	0	10.15.5.81	40000	- 1
🗌 D2	IP PTZ Dom	ne		1	×	0	10.15.114.161	8005	- 1
🗌 D3	CAM 3			1	×	0	10.15.6.117	37777	- 1
🗌 D4	IPC			1	×	0	10.15.6.25	37777	- 1
🗌 D5	CAM 5			1	× × ×	0	10.15.5.82	40003	- 1
🗌 D6	IPC			/	×	$\bigcirc$	10.15.23.69	37777	- 1
					_				
					_				
Delete	e) (Impo	ort	Export						
						Back	Next	Cancel	



#### Step 2 Set parameters

- Channel: It is the device channel number. If you have not added the network camera, the channel number is shown as -.
- Status: Red circle (
  ) means current channel has no video, green circle (
  ) means current channel has video.
- IP address: It is to display network camera IP address.
- Type: There are two connection types. You can use the network to connect to the camera or

use the Wi-Fi. The 🗐 means current network camera connection mode is general; the

means current network camera mode is hotspot.

- Add/Delete: Click 🛛 to delete the device, click 🛃 to add the device to the NVR.
- Step 3 Add network camera.
  - Device search: Click the button; you can search all network cameras in the same network segment. See Figure 4-23. Double click a camera or check the camera box and then click Add button, you can add a device to the list.
    - Note

The device in the added device list is not shown in the search result column.

				Regis	tration			
Device S	Search) (I	P Addres	s <b></b> (		) (Sea	arch	Uninitial	Initialize
22	Modify	Status	IP Addre	ess	Port		Device Name	Manufa
1		$\triangleright$		239.255	.42.42	37777	NVR	
2	🗌 🖻			10.15.23	3.110	37777	12345	6
3	🗌 🖻			10.15.6.	218	37810	DSS7	016
4	🗌 🖻			10.15.6.	82	40008		
5				10.15.6.	253	37777	NVR6	08-32-4
•								►
Add	) (Ma	nual Add	) ( Modi	fv IP			Filter (Nu	
				<u>'y "</u>				
Added D	evice —							
СН 🗌	С	amera Na	ime	Modify	Delete	Status	IP Address	Port [
🗌 D1	CAM 1			/	×	0	10.15.5.81	40000 2
🗌 D2	IP PTZ D	ome		/	×	$\bigcirc$	10.15.114.161	8005 2
🗌 D3	CAM 3			/	×	0	10.15.6.117	37777 2
🗌 D4	IPC			111	×		10.15.6.25	37777 :
🗌 D5	CAM 5			/	××	0	10.15.5.82	40003 1
🗌 D6	IPC			/	×	$\bigcirc$	10.15.23.69	37777 1
								↓▶
Delete		mport	Expo	ort				
					E	Back	Next	Cancel



 Manual Add: Click Manual Add button, you can set the corresponding network camera information and then select the channel you want to add. See Figure 4-24.

 $\diamond \quad \text{Manufacturer: Please select from the dropdown list.}$ 

# Note

Different series products may support different manufactures, please refer to the actual product.

- ♦ IP address: Input remote device IP address.
- ♦ RTSP port: Input RTSP port of the remote device. The default setup is 554.

# Note

Skip this item if the manufacture is private or customize.

♦ HTTP port: Input HTTP port of the remote device. The default setup is 80.

# Note

Skip this item if the manufacture is private or customize.

- ♦ TCP port: Input TCP port of the remote device. The default setup is 37777.
- ♦ User name/password: The user name and password to login the remote device.

Channel No.: Input channel amount or click the Connect button to get the channel amount of the remote device.

# Note

We recommend click Connect button to get remote device channel amount, the manual add operation may result in failure if the input channel amount is not right.

Remote channel No.: After getting the remote device channel amount, click Setup to select a channel.

# Note

Click to select one or more remote channel numbers here.

- Channel: The local channel number you want to add. One channel name has corresponding one channel number.
- ♦ Decode buffer: There are three items: realtime,local,fluent.
- ♦ Service type: There are four types: auto/TCP/UDP/MULTICAST(ONVIF device only)

# Note

The default connection mode is TCP if the connection protocol is private.

There are four types including Auto, TCP, UDP and MULTICAST if the connection protocol is ONVIF.

There are two types including TCP and UDP if the connection protocol is from the third-party.

Encrypt: When the connection protocol is ONVIF, enable the encryption function and system transmits data in the encrypted mode.

# Note

HTTPS shall be enabled in IPC to support encryption.

	Manual Add
Manufacturer IP Address	Onvif (192.168.0.0
RTSP Port Username Password Connect	Customized
Channel No. Remote Channel No. Channel Decode Buffer Encrypt	Setting       1       D3       Default
	UDP O MULTICAST
	OK Cancel

Figure 4-24

Step 4 Click OK to add the camera to the device.

D Note		
Click 🧹	to change the remote device information. Click	to delete remote device.

#### 4.1.4.6 Schedule

After set record schedule and snapshot schedule, the device can automatically record video and snapshot image at the specified time.

Schedule Record

After set schedule record, device can record video file according to the period you set here. For example, the alarm record period is from  $6:00 \sim 18:00$  Monday, device can record alarm video files during the  $6:00 \sim 18:00$ .

All channels are record continuously by default. You can set customized record period and record type.

Step 1 Click Next button.

Enter schedule interface. See Figure 4-25.



From main menu->Setting->Storage->Schedule->Record, you can go to the record interface.





#### Step 2 Set parameters.

- Channel: Please select the channel number first. You can select "all" if you want to set for the whole channels.
- $\diamond$  Sync connection icon. Select icon  $\blacksquare$  of several dates, all checked items can be

edited or together. Now the icon is shown as



 $\diamond$  **Matrix**: Click it to delete a record type from one period.

- Record Type: Please check the box to select corresponding record type. There are six types: Regular/MD (motion detect)/Alarm/MD&Alarm/IVS/POS.
- Week day: There are eight options: ranges from Saturday to Sunday and all.
- Holiday: It is to set holiday setup. Please note you need to go to the General interface (Main Menu->Setting->System->General) to add holiday first. Otherwise you cannot see this item.
- Pre-record: System can pre-record the video before the event occurs into the file. The value ranges from 1 to 30 seconds depending on the bit stream.
- Redundancy: System supports redundancy backup function. It allows you backup recorded file in two disks. You can highlight Redundancy button to activate this function. Please note, before enable this function, please set at least one HDD as redundant. (Main menu->Setting->Storage->HDD Manager). Please note this function is null if there is only one HDD.
- ANR: It is to save video to the SD card of the network camera in case the network

connection fails. The value ranges from  $0s \sim 43200s$ . After the network connection resumed, the system can get the video from the SD card and there is no risk of record loss.

• Period setup: Click button after one date or a holiday, you can see an interface shown as in Figure 4-26. There are five record types: regular, motion detection (MD), Alarm, MD & alarm and IVS.

	Period			
Current Date: Sun				
Period 1 $00:00$ $-24:00$ Period 2 $00:00$ $-24:00$ Period 3 $00:00$ $-24:00$ Period 4 $00:00$ $-24:00$ Period 5 $00:00$ $-24:00$ Period 6 $00:00$ $-24:00$	Continuous Motion Continuous Motion Continuous Motion Continuous Motion Continuous Motion Continuous Motion	Alarm Alarm Alarm Alarm Alarm Alarm	MD&Alarm MD&Alarm MD&Alarm MD&Alarm MD&Alarm MD&Alarm	
Copy	9 (Wed ()Thu ()Fri (			
	ОК			

Figure 4-26

Please following the steps listed below to draw the period manually.

Step 1 Select a channel you want to set. See Figure 4-27.



Step 2 Set record type. See Figure 4-28.

General	Motion	Alarm	MD&A	<mark>,</mark> I∨s	POS



# Note

- When the record type is MD (motion detect), alarm, MD&Alarm, IVS and POS, please enable the channel record function when corresponding alarm occurs. For example, when the alarm type is MD, from main menu->Setting->Event->Video Detect->Motion Detect, please select the record channel and enable record function. See Figure 4-29.
- When the record type is MD (motion detect), alarm, MD&Alarm, IVS and POS, refer to chapter 4.7.1 Video detect, chapter 4.7.9 Alarm Settings, chapter 4.7.3 IVS and chapter 4.7.12 POS.

	SETTING	
📆 CAMERA	👼 NETWORK 🛛 📸 EVENT 🛛 🛃 STORAGE 🛛 🛃 S	SYSTEM
VIDEO DETEC SMART PLAN IVS FACE DETECTI	Motion Detect     Video Loss     Tampering     Scene Chan       Channel     D1     Enable     Region	
PEOPLE COUN HEAT MAP VEHICLE REC AUDIO DETECT ALARM ABNORMALITY ALARM OUTPUT POS	Period       Setup       Anti-Dither       5       S         Alarm Out       1       2       Latch       10       Sec.         Show Message       Alarm Upload       Send Email       Sec.       Sec.       Sec.         Previous       Setup       Post-Record       10       Setup       Setup       Setup         Tour       Setup       Setup       Setup       Setup       Setup       Setup	Sec.
	Ontpontor     Cottop       Log       Voice Prompts     File Name None       Buzzer       Default     Copy       Refresh     OK	Apply

Figure 4-29

Step 3 Please draw manually to set record period. There are six periods in one day. See Figure 4-30.



If you have added a holiday, you can set the record period for the holiday.





Step 4 Click Apply button to save schedule record settings.

### Note

Please enable auto record function so that the record plan can become activated. Refer to chapter 0 Record control for detailed information.

#### Schedule Snapshot

It is to set schedule snapshot period.

After set schedule snapshot, device can snapshot image according to the period you set here. For example, the alarm snapshot period is from  $6:00 \sim 18:00$  Monday, device can snapshot during the  $6:00 \sim 18:00$  when an alarm occurs.

Step 1 Click Snapshot button, device goes to following interface. See Figure 4-31.

# Note

From main menu->Setting->Storage->Schedule->Snapshot, you can go to the snapshot interface.





- Step 2 Select a channel to set schedule snapshot.
- Step 3 Set snapshot type as schedule. Refer to chapter 4.2.5.3 Snapshot for detailed information.
- Step 4 Check the box to set alarm type. See Figure 4-32.

#### 

Figure 4-32

# D Note

- When the record type is MD (motion detect), alarm, MD&Alarm, IVS and POS, please enable the channel snapshot function when corresponding alarm occurs. For example, when the alarm type is MD, from main menu->Setting->Event->Video Detect->Motion Detect, please select the snapshot channel and enable snapshot function. See Figure 4-33.
- When the snapshot type is MD (motion detect), alarm, MD&Alarm, IVS, refer to chapter 4.7.1
   Video detect, chapter 4.7.9 Alarm Settings, chapter 4.7.3 IVS and chapter 4.7.12 POS.

	SETTING	
🥰 CAMERA	TOTAGE	
VIDEO DETEC SMART PLAN IVS FACE DETECTI PEOPLE COUN HEAT MAP VEHICLE REC AUDIO DETECT ALARM	Motion Detect       Video Loss       Tampering       Scene Chan         Channel       D1       Enable       Region         Region       Setup       Anti-Dither       5         Period       Setup       Anti-Dither       5         Alarm Out       1       2       Latch       10         Show Message       Alarm Upload       Send Email         Post-Record       10       Sec.	
ABNORMALITY ALARM OUTPUT POS	PTZ Activation       Setup         Tour       Setup         ✓Snapshot       Setup         Log       Voice Prompts         File Name(None       ▼         Buzzer          Default       Copy         Refresh       OK       Cancel	

Figure 4-33

- Step 5 Refer to chapter 0 to set snapshot period.
- Step 6 Click Apply button to save snapshot plan.

### Note

Please enable auto snapshot function so that the snapshot plan can become activated. Refer to chapter 0 Record control for detailed information.

Step 7 Click Finish button, system pops up a dialogue box. Click the OK button, the startup wizard is complete. See Figure 4-34.



Figure 4-34

### **Record Control**

## Note

You need to have proper rights to implement the following operations. Please make sure the HDD has been properly installed.

There are three ways for you to go to record menu.

- Right click mouse and then select Manual->Record.
- In the main menu, from Setting->Storage->Record.

• In live viewing mode, click record button in the front panel or record button in the remote control. After set schedule record and schedule snapshot function, please enable auto record and auto snapshot function so that the device can automatically record and snapshot. System supports main stream and sub stream. There are three statuses: schedule/manual/stop. See Figure 4-35. Please highlight icon"o" to select corresponding channel.

- Manual: The highest priority. After manual setup, all selected channels will begin general recording.
- Schedule: Channel records as you have set in recording setup (Main Menu->Setting->Storage->>Schedule)
- Stop: Current channel stops recording.
- All: Check All button after the corresponding status to enable/disable all-channel schedule/manual record or enable/disable all channels to stop record.
- Snapshot: Select one or more channel(s) first and then enable/disable schedule snapshot function.

			ę	SETTI	NG					
SAMERA	📷 NETWORK	1	) EVE	ENT		4	STOR	AGE	SYSTEM	
BASIC										
SCHEDULE	Main St	All	D1	D3	D4	D5	D6	D7	D8	
HDD MANAGER	Auto	0	•	•	•	•	٠	٠	•	
FTP	Manual	0	0	0	0	0	0	0	0	
RECORD	Off	0	0	0	0	0	0	0	0	
ADVANCED	Sub Stream1_									
HDD DETECT	Auto	0	0	0	0	0	0	0	0	
	Manual	0	0	0	0	0	0	0	0	
	Off	0	•	•	٠	٠	٠	٠	•	
	Sub Stream2_									
	Auto	0	0	0	0	0	0	0	0	
	Manual	0	0	0	0	0	0	0	0	
	Off	0	•	•	•	•	•	•	•	
	Snapshot									
	Enable	0	0	0	0	0	0	0	0	
	Disable	0	•	•	•	•	•	•	•	
								OK	Cancel Apply	

Figure 4-35

#### **Record Info**

After system recorded video files, go to the record info interface to view device name, start time, end time and etc.

From main menu->Info-System->Record, the interface is shown as below. See Figure 4-36.



### 4.2 Camera

### 4.2.1 Connection

After register a remote device to the NVR, you can view the video on the NVR, and manage and storage the video file. Different series products support different remote device amount.

4.2.1.1 Change IP address

Step 1 From Main menu->Setting->Camera->Registration, check the box before the camera name and

then click Change IP or click the 🗐 before the camera name.

Enter change IP interface. See Figure 4-37.



Check the box before several cameras, change the IP addresses of several cameras at the same time.

Checked Device No.: 1 O DHCP STATIC IP Address 192.168.1.108 Incremental Value 1 Subnet Mask 255.255.0 Default Gateway 192.168.1.1 <u>1 Serial No. IP Address</u> 1 1D004B0YAZ00003 192.168.1.108		Modify IP
IP Address       192.168.1.108       Incremental Value (1)         Subnet Mask       255.255.255.0       0         Default Gateway       192.168.1.1       1         1       Serial No.       IP Address	O DHCP	
	IP Address (192 . 168 . 1 . Subnet Mask (255 . 255 . 255 .	0
Back Next Skip	Back	Next



#### Step 2 Select IP mode.

Check DHCP, there is no need to input IP address, subnet mask, and default gateway. Device automatically allocates the IP address to the camera.

Check Static, and then input IP address, subnet mask, default gateway and incremental value.

# D Note

If it is to change several devices IP addresses at the same time, please input incremental value. Device can add the fourth address of the IP address one by one to automatically allocate the IP addresses.

If there is IP conflict when changing static IP address, device pops up IP conflict dialogue box. If batch change IP address, device automatically skips the conflicted IP and begin the allocation according to the incremental value

- Step 3 Input remote device user name and password.
- Step 4 Click OK button to save settings.

After the changing operation, search again, device displays new IP address.

D Note

When change IP addresses of several devices at the same time, make sure the cameras user name and passwords are the same.

#### 4.2.1.2 IP Export

Device can export the Added device list to your local USB device.

Step 1 Insert the USB device and then click the Export button.

Enter the following interface. See Figure 4-38.

		Browse			
Device Name Total Space	(sda1(USB DISK))) (7.53 GB	Refresh Free Space (2.	16 GB		
Address	(/NVR/RemoteConfBa	ckup/			
Name			Size		Del
<b>-</b>				Folder	
🗹 File Backu	p Encryption				
				ОК	Cancel

Figure 4-38

Step 2 Select the directory address and then click the OK button.

Step 3 Device pops up a dialogue box to show the export is successful. Click OK button to exit.

### Note

Backup encryption is enabled by default when exporting files. The file information includes IP address, port, remote channel number, manufacturer, user name and password.

 When you enable backup encryption, the extension name of the exported file is .backup. All the other softwares cannot open the file to edit except the NVR device.  When you disable backup encryption, the extension name of the exported file is .csv. It might lead to data leakage.

#### 4.2.1.3 IP Import

Step 1 Click Import button.

Enter the following interface. See Figure 4-39.

Address (/English/		)
 Name	Size Type	Delete 🔺
is men7.bmp	2.50 MB File	×
and a state of the state of th	2.50 MB File	×
ne.bmp	2.50 MB File	× =
	2.50 MB File	×
➡ fre2.bmp	2.50 MB File	× 🗌
fr7.bmp	2.50 MB File	×
📑 f8.bmp	2.50 MB File	×
📑 col.bmp	2.50 MB File	×
ex2.bmp	2.50 MB File	×
RemoteConfig_20150202143711.csv	171 B File	×
⊒³im2.bmp	2.50 MB File	×
📑 re222.bmp	2.50 MB File	×
📑 re3.bmp	2.50 MB File	×
⊒³ima1.bmp	2.50 MB File	×
📑 en1.bmp	2.50 MB File	<b>-</b>



- Step 2 Select the import file and then click the OK button. System pops up a dialogue box to remind you successfully imported.
- Step 3 Click OK button to exit.

# Note

If the imported IP has conflicted with current added device, system pops up a dialogue box to remind you. You have two options:

Step 4 Click OK button, system uses the imported setup to overlay current one.



- You can edit the exported .CVS file. Do not change the file format; otherwise it may result in import failure.
- Does not support customized protocol import and export.
- The import and export device shall have the same language format.

### 4.2.2 Remote Device Initialization

Remote device initialization can change remote device login password and IP address.

### D Note

When connect a camera to the NVR via PoE port, NVR automatically initialize the camera. The

camera adopts NVR current password and email information by default.

- When connect a camera to the NVR via PoE port after NVR upgraded to the new version, the NVR may fail to initialize the camera. Please go to the Registration interface to initialize the camera.
- Step 1 From main menu->Setting->Camera->Registration. Enter Registration interface.
- Step 2 Click Device Search and then click Uninitialized. Device displays camera(s) to be initialized.
- Step 3 Select a camera to be initialized and then click Initialize. Device displays password setup interface. See Figure 4-40.

# III Note

• If you want to use current device password and email information, the remote device automatically uses NVR admin account information (login password and email). There is no need to set password and email. Please go to step 4.

Enter Password	
✓Using current device password and email info.	
	<b>\</b>
	Next



1. Cancel using current device password and email information, Enter password setting interface. See Figure 4-41.

Enter Password	
Using current device password and email info.	
Username admin	
Password	
It is 8 to 32-digit containing letter(s), number(s),symbol(s). It is ontains at least two types.	
Confirm Password	
	Next



2. Set camera password.

• The user name is **admin**. The password ranges from 8 to 32 digitals. It can contain letters, numbers and special characters (excluding "!", "!", ";", "&"). The password shall contain at least two categories. Usually we recommend the strong password.



STRONG PASSWORD RECOMMENDED-For your device own safety, please create a strong password of your own choosing. We also recommend you change your password periodically especially in the high security system.

3. Click Next button.

Enter input email interface. See Figure 4-42.

	Security Questions	
🗹 Email 🤇		)(To reset password)
Back		Next Skip

Figure 4-42

4. Set email information.

Email: Input an email address for reset password purpose.

# Note

Cancel the box and then click Next or Skip if you do not want to input email information here. Step 4 Click Next button.

Enter Change IP address interface. See Figure 4-43.

Modify IP	
Checked Device No.: 1 O DHCP STATIC IP Address Subnet Mask 255 . 255 . 255 . 0	Incremental Value (1
Default Gateway         192         168         1         1           1         Serial No.         IP Address         1         10004B0YAZ00003         192.168.1.108	
Back	Next Skip



#### Step 5 Set camera IP address

Check DHCP, there is no need to input IP address, subnet mask, and default gateway. Device automatically allocates the IP address to the camera.

Check Static, and then input IP address, subnet mask, default gateway and incremental value.

III Note

- If it is to change several devices IP addresses at the same time, please input incremental value. Device can add the fourth address of the IP address one by one to automatically allocate the IP addresses.
- If there is IP conflict when changing static IP address, device pops up IP conflict dialogue box. If batch change IP address, device automatically skips the conflicted IP and begin the allocation according to the incremental value

Step 6 Click Next button. Device begins initializing camera. See Figure 4-44.



Figure 4-44

Step 7 Click Finish to complete the setup.

### 4.2.3 Short-Cut Menu to Register Camera

If you have not register a remote device to a channel, please go to the preview interface to add.

Step 1 On the preview interface,

Move your mouse to the center, there is an icon "+". See Figure 4-45.



Figure 4-45

Step 2 Click "+", device pops up interface to add network camera. Refer to chapter 4.1.4.4 Registration for detailed information.

### 4.2.4 Image

It is to set network camera parameters according to different environments. It is to get the best video effect.

From main menu->setting->camera->image, you can see the image interface is shown as below. See Figure 4-46.

- Channel: Select a channel from the dropdown list.
- Saturation: It is to adjust monitor window saturation. The value ranges from 0 to 100. The default value is 50. The larger the number, the strong the color is. This value has no effect on the general brightness of the whole video. The video color may become too strong if the value is too high. For the grey part of the video, the distortion may occur if the white balance is not accurate. Please note the video may not be attractive if the value is too low. The recommended value ranges from 40 to 60.
- Brightness: It is to adjust monitor window bright. The value ranges from 0 to 100. The default value is 50. The larger the number is, the bright the video is. When you input the value here, the bright section and the dark section of the video will be adjusted accordingly. You can use this function when the whole video is too dark or too bright. Please note the video may become hazy if the value is too high. The recommended value ranges from 40 to 60.
- Contrast: It is to adjust monitor window contrast. The value ranges from 0 to 100. The default value is 50. The larger the number is, the higher the contrast is. You can use this function when the whole video bright is OK but the contrast is not proper. Please note the video may become hazy if the value is too low. If this value is too high, the dark section may lack brightness while the bright section may over exposure .The recommended value ranges from 40 to 60.
- Auto Iris: It is for the device of the auto lens. You can check the box before ON to enable this function. The auto iris may change if the light becomes different. When you disable this function, the iris is at the max. System does not add the auto iris function in the exposure control. This function is on by default.
- Mirror: It is to switch video up and bottom limit. This function is disabled by default.
- Flip: It is to switch video left and right limit. This function is disabled by default.
- BLC: It includes several options: BLC/WDR/HLC/OFF.
- BLC: The device auto exposures according to the environments situation so that the darkest area of the video is cleared
- WDR: For the WDR scene, this function can lower the high bright section and enhance the brightness of the low bright section. So that you can view these two sections clearly at the same time. The value ranges from 1 to 100. When you switch the camera from no-WDR mode to the WDR mode, system may lose several seconds record video.
- ♦ HLC: After you enabled HLC function, the device can lower the brightness of the brightest section according to the HLC control level. It can reduce the area of the halo and lower the brightness of the whole video.
- ♦ OFF: It is to disable the BLC function. Please note this function is disabled by default.
- Profile: It is to set the white balance mode. It has effect on the general hue of the video. This function is on by default. You can select the different scene mode such as auto, sunny, cloudy, home, office, night, disable and etc to adjust the video to the best quality.
- ♦ Auto: The auto white balance is on. System can auto compensate the color temperature to make sure the vide color is proper.
- $\diamond$  Sunny: The threshold of the white balance is in the sunny mode.
- ♦ Night: The threshold of the white balance is in the night mode.
- ♦ Customized: You can set the gain of the red/blue channel. The value reneges from 0 to 100.
- Day/night. It is to set device color and the B/W mode switch. The default setup is auto.
- ♦ Color: Device outputs the color video.
- Auto: Device auto select to output the color or the B/W video according to the device feature (The general bright of the video or there is IR light or not.)
- $\diamond$  B/W: The device outputs the black and white video.

♦ Sensor: It is to set when there is peripheral connected IR light.

Please note some non-IR series product support sensor input function.

	SETTING	
CAMERA	👼 NETWORK 🛛 🙀 EVENT	TORAGE 🔤 SYSTEM
REGISTRATION IMAGE ENCODE CAM NAME	Channel D14 •	Image Brightness 50 Contrast 50 Saturation 50 Hue 50
	Exposure	Mirror O On Off Flip (Normal V BLC V Mode Stop V
	WB Mode Auto	Day&Night

Figure 4-46

### 4.2.5 Encode

It is to set video encode parameters such as video bit rates, video overlay, snapshot settings. 4.2.5.1 Encode

It is to set IPC encode mode, resolution, bit stream type and etc.

D Note

Some series products support three streams: main stream, sub stream 1, sub stream 2. The sub stream maximally supports 1080P.

From Main menu->Setting->System->Encode, you can see the following interface. See Figure 4-47.

- Channel: Select the channel you want.
- Type: It is to set device bit stream type.
- ✤ For main stream, there are three options: regular/motion detect/alarm. The sub stream supports regular bit streams only.
- The active control frame function (ACF) can record in different frame rates. For example, you can use high frame rate to record important events, record scheduled event in lower frame rate.
- ♦ Set different frame rates for different record events.



#### Some series products do not support motion detect bit streams and alarm streams.

- Compression: Video encode mode.
- ♦ H.264: Main Profile encode mode.

- ♦ H.264H: High Profile encode mode.
- ♦ H.264B: Baseline Profile encode mode.
- ♦ H.265: Main Profile encode mode.
- MJPEG: System needs high bit streams to guarantee video definition. Use the recommended max bit stream value to get the better video effect.
- Smart Codec: This function is to reduce bit streams.

## Note

- ♦ Some series products support smart codec function.
- After changing smart code, please reboot network camera and some network camera functions (such as IVS, ROI, SVC, lobby mode and etc.) becomes null. Please think twice before the operation.
- Resolution: The resolution here refers to the capability of the network camera.

### D Note

Different series products support different resolutions. Please refer to the actual interface for detailed information.

- Frame rate (FPS): The video frame amount displayed in each second. The higher the frame rate is, the clearer and more fluent the video is. The frame rate may vary depending on the resolution.
- Bit rate type: System supports two types: CBR and VBR.
  - Main stream: It is to set frame rate to change video quality. The higher the frame rate is, the better the video quality is. The referenced bit rate is the recommended value.
  - Sub stream: In CBR mode, the bit stream is near the specified value. In VBR mode, the video quality changes according to the bit stream value. But its max value is near the specified value. Reference bit rate: The reference bit rate depends on the resolution and frame rate you set.
- Video/audio: You can enable or disable the video/audio. The main stream is enabled by default. After enable the audio function, the record file is composite file consisting of the video and audio. For the sub stream 1, please enable video first and then enable audio function.
- Audio format: Set audio encode format.

### I Note

Different series products support different audio encode mode. Please refer to the actual interface for detailed information.

- Sampling rate: Audio sampling rate refers to the sampling amount within 1 second. The higher the value is, the better the audio is. The default setup is 8K.
- Copy: After you complete the setup, you can click Copy button to copy current setup to other channel(s). You can see an interface is shown as in Figure 4-50. You can see current channel number is grey. Please check the number to select the channel or you can check the box ALL.
   Please click the OK button in Figure 4-50 and Figure 4-48 respectively to complete the setup. Please note, once you check the All box, you set same encode setup for all channels. Audio/video enable box, overlay button and the copy button is shield.

Please highlight icon 📕 to select the corresponding function.

	SETTING
	📅 NETWORK 🔂 EVENT STORAGE SYSTEM
REGISTRATION IMAGE	Encode Overlay Snapshot
ENCODE	Channel D1
CAM NAME	Code-Stream Type Continuous
	Compression (H.264 ) (MJPEG )
	Resolution (1920×108 ) (704×576(D1) )
	Frame Rate(FPS) 25
	Bit Rate Type VBR
	Quality 4
	Bit Rate(Kb/S) (4096 )
	Reference Bit Rate         1024-10240Kb/S         2048-4096Kb/S
	Audio/Video 🗹 🗹
	Audio Encode (G.711Mu )
	Sampling Rate
	Default Copy Refresh OK Cancel Apply



#### 4.2.5.2 Overlay

Click overlay button, you can see an interface is shown in Figure 4-48.

- Cover area: Here is for you to cover area section. You can drag you mouse to set proper section size. In one channel video, system max supports 4 zones in one channel. You can set with Fn button or direction buttons.
- Preview/monitor: The cover area has two types. Preview and Monitor. Preview means the privacy mask zone cannot be viewed by user when system is in preview status. Monitor means the privacy mask zone cannot be view by the user when system is in monitor status.
- Time display: You can select system displays time or not when you playback. Please click set button and then drag the title to the corresponding position in the screen.
- Channel display: You can select system displays channel number or not when you playback. Please click set button and then drag the title to the corresponding position in the screen.
|                       | SETTING   |
|-----------------------|---|
|                       | 📂 NETWORK 📷 EVENT 📴 STORAGE 🗾 SYSTEM  |
| REGISTRATION<br>IMAGE | Encode Mode Overlay Snapshot  |
| ENCODE                | Channel D2  |
| CAM NAME              | Time Display 🖌 Monitor Setup  |
|                       | Channel Display 🖌 Monitor 🛛 Setup   |
|                       |   |
|                       | Customized Title Monitor   Customized Title1   Customized Title2   Customized Title3   Customized Title4   Customized Title5   Align Mode   Left Align     Default   Copy   Refresh   OK   Cancel   Apply |

Figure 4-48

### 4.2.5.3 Snapshot

Here you can set snapshot mode, picture size, quality and frequency. See Figure 4-49.

- Snapshot mode: There are two modes: regular and trigger. If you set regular mode, you need to set snapshot frequency. If you set trigger snapshot, you need to set snapshot activation operation.
- Image size: Here you can set snapshot picture size.
- Image quality: Here you can set snapshot quality. The value ranges from 1 to 6.
- Interval: It is for you to set timing (schedule) snapshot interval.

	SETTING	
	秒 NETWORK 🛛 👼 EVENT 🛛 💁 SYSTEI	м
REGISTRATION IMAGE	Encode Mode Overlay Snapshot	
ENCODE CAM NAME	Snapshot 1   Channel D2   Mode Timing   Image Size NATIVE   Image Quality 6   Interval 1   S	
		Apply_)
	Figure 4-49	



Figure 4-50

### 4.2.6 Channel Name

From main menu->Setting->Camera-Channel name, you can see an interface shown as in Figure 4-51. It is to modify channel name. It max supports 63-character.

Please note you can only modify the channel name of the connected network camera.

		SETTING		
		D EVENT	STORAGE	E 🛃 SYSTEM
REGISTRATION IMAGE ENCODE CAM NAME	D3 (0 D5 (0 D7 (0 D9 (1 D11 (1 D13 (0 D15 (0	e CAM 1 CAM 3 CAM 5 CAM 7 P PTZ Dome PC CAM 13 CAM 15 CAM 15	D2 D4 D6 D8 D10 D12 D14 D16	CAM 2 CAM 4 CAM 6 IP PTZ Dome 独成像 CAM 12 &conf_img.channel1 CAM 16

Figure 4-51

## 4.2.7 Remote Upgrade

It is to upgrade the connected network camera firmware. It includes online upgrade and file upgrade. From main menu->setting->camera->remote, the interface is shown as below. See Figure 4-52.

	SETTING
	📬 NETWORK 🛛 😹 EVENT 🛛 💁 STORAGE 🛛 🛃 SYSTEM
REGISTRATION IMAGE ENCODE	Registration Status Firmware Upgrade
CAM NAME	Upgrade File (/ Select ) Device Upgrade(0/2) Device Type (None -
	Channel       Status       IP Address       System Version       Upgrade Status       Upgrade         D1       10.1.1.65       2.600.0005.0       To be upgraded       Detect         D5       10.1.1.69       2.210.0000.8       To be upgraded
	(File Upgrade) (Manual Check) (Online Upgrade)

Figure 4-52

#### **Online Upgrade**

- Step 1 Select a remote device and then click the Detect button on the right side, or check a box to select a remote device and then click Manual Check.
  System detects the new version on the cloud.
- Step 2 Select a remote device that has new version and then click online upgrade. After successful operation, system pops up upgrade successful dialogue box.

#### File upgrade

- Step 1 Select a channel and then click File upgrade.
- Step 2 Select upgrade file on the pop-up interface.
- Step 3 Select the upgrade file and then click OK button. After successful operation, system pops up upgrade successful dialogue box.

🛄 Note

If there are too much remote devices, select device type from the drop-down list to search the remote device you desire.

### 4.2.8 Remote Device Info

#### 4.2.8.1 Device Status

Here you can view the IPC status of the corresponding channel such as motion detect, video loss, tampering, alarm and etc. See Figure 4-53.

- IPC status: Front-end does not support. Front-end supports.
- Connection status: Connection succeeded.
- Refresh: Click it to get latest front-end channel status.

	SETTING
	📂 NETWORK 📷 EVENT 🧏 STORAGE 🗾 SYSTEM
REGISTRATION IMAGE	Registration Status Firmware Upgrade
ENCODE	Channel Status IP Address Video Detect IPC External Alarm
CAM NAME	D1 10.1.1.65 D5 10.1.1.69
	(Refresh

Figure 4-53

#### 4.2.8.2 Firmware

It is to view channel, IP address, manufacturer, type, system version, SN, video input, audio input, external alarm and etc. See Figure 4-54.

	(	SETTING		
		To EVENT	STORAGE	SYSTEM
REGISTRATION IMAGE	Registration S	Status Firmware	Upgrade	
ENCODE CAM NAME	D1 10.1	ddress Manufactur 1.1.65 Private 1.1.69 Private	er Type IP Camera IPC-HDBW2201F	System Vers 2.600.0005.0 2-ZS 2.210.0000.8
	Refresh			<b>&gt;</b>

Figure 4-54

### 4.3 Preview

After device booted up, the system is in multiple-channel display mode. See Figure 4-55.Please note the displayed window amount may vary. The following figure is for reference only. Please refer to chapter 1.3 Specifications for the window-amount your product supported.



Figure 4-55

### 4.3.1 Preview

If you want to change system date and time, you can refer to general settings (Main Menu->Setting->System->General). If you want to modify the channel name, please refer to the display settings (Main Menu->Camera->CAM name)

Please refer to the following sheet for detailed information.

SN	lcon	Function
1	8	When current channel is recording, system displays this icon.
2	*	When motion detection alarm occurs, system displays this icon.
3	?	When video loss alarm occurs, system displays this icon.
4	8	When current channel is in monitor lock status, system displays this icon.
5	৽	<ul> <li>When the device remotely connects Wi-Fi IPC, this icon is displayed on the screen of the corresponding channel.</li> <li>NOTE</li> <li>Only some devices support this function.</li> </ul>

#### <u>Tips</u>

- Preview drag: If you want to change position of channel 1 and channel 2 when you are previewing, you can left click mouse in the channel 1 and then drag to channel 2, release mouse you can switch channel 1 and channel 2 positions.
- Use mouse middle button to control window split: You can use mouse middle button to switch window split amount.

### 4.3.2 Navigation bar

On the preview interface, left click mouse, you can view the navigation bar. See Figure 4-56 or Figure 4-57.

Note

- Different series products may display different navigation bar icons. Refer to the actual product for detailed information.
- Go to the Main menu->Setting->System->General to enable navigation bar function; otherwise you cannot see the following interface.

		▼卷҈∆⇒≒≆≅⊜≜
	Figure 4-56	
	_	▼ @ Q & A ⇒ ∓ ≅ 8 8
	Figure 4-57	
4.3.2.1 Main Menu		
Click button to go to the main m	nenu interface.	
4.3.2.2 Dual-screen operation		

#### Important

This function is for some series only.

Click to select screen 2, you can view an interface shown as below. See Figure 4-58. It is a navigation bar for screen 2.

Figure 4-58

Click any screen split mode; HDMI2 screen can display corresponding screens. Now you can control two screens. See Figure 4-59.



Figure 4-59

# D Note

- Screen 2 function is null if tour is in process. Please disable tour function first,
- Right now, the screen 2 operation can only be realized on the navigation bard. The operations on the

right-click menu are for screen 1 only.

4.3.2.3 Output Screen
Click Click to select corresponding window-split mode and output channels.
4.3.2.4 Previous screen/next screen
Click to go back to the previous screen, click to go to the next screen. 4.3.2.5 Tour
Click button to enable tour, the icon becomes, you can see the tour is in process.
Note
Close the tour or the triggered tour operation has cancelled, device restore the previous preview video. 4.3.2.6 PTZ
Click , system goes to the PTZ control interface. Please refer to chapter 4.4.2 PTZ for detailed
information.
4.3.2.7 Color
Click button 🛞, system goes to the color interface. Please refer to chapter 4.3.6.1 Color for detailed
information.
Please make sure system is in one-channel mode.
4.3.2.8 Image
Click 😰 to go to the image interface. Please refer to chapter 4.2.4 Image for detailed information.
Please make sure system is in one-channel mode.
4.3.2.9 Search
Click button system goes to search interface. Please refer to chapter 4.6.2 Search for detailed
information.
4.3.2.10 Broadcast
Click to go to broadcast interface. Select a group name and then click to begin
broadcast. Please refer to chapter 4.10.5 Broadcast for detailed information.
4.3.2.11 Alarm Status
Click button A, system goes to alarm status interface. It is to view device status and channel status.
Please refer to chapter 4.10.2.3.1 Alarm status for detailed information. 4.3.2.12 Channel Info
Click button E, system goes to the channel information setup interface. It is to view information of the
corresponding channel See Figure 4.60

corresponding channel. See Figure 4-60.

Channel	Motion Detect	Video Loss	Tampering	Record Status	s Bit Rate(Kb/S)	Status	Record Mod
					3934	0	Continuous
2 4 6					4245	ŏ	Continuous
6					6159	0	Continuous
▲							•

Figure 4-60

#### 4.3.2.13 Registration

system goes to the registration interface. Please refer to chapter 0 Registration for detailed Click information.

#### 4.3.2.14 Network

Click system goes to the network interface. It is to set network IP address, default gateway and etc. Please refer to chapter 4.8 Network for detailed information.

#### 4.3.2.15 HDD Manager

System goes to the HDD manager interface. It is to view and manage HDD information. Click Please refer to chapter 4.9.1 HDD manager for detailed information.

#### 4.3.2.16 USB Manager

Click system goes to the USB Manager interface. It is to view USB information, backup and update. Please refer to chapter 4.10.8.1 File backup, chapter 4.10.8.3 Backup log, chapter 4.10.8.2 Import/export, and chapter 0 Upgrade for detailed information.

### 4.3.3 Preview Control Interface

Move you mouse to the top center of the video of current channel, you can see system pops up the preview control interface. See Figure 4-61. If your mouse stays in this area for more than 6 seconds and has no operation, the control bar automatically hides.



Figure 4-61

1) Instant playback

It is to playback the previous 5-60 minutes record of current channel.

Please go to the Main menu->Setting->->System->General to set real-time playback time. System may pop up a dialogue box if there is no such record in current channel.

#### 2) Digital zoom

It is to zoom in specified zone of current channel. It supports zoom in function of multiple-channel.

Click button S, the button is shown as S.

There are two ways for you to zoom in.

• Drag the mouse to select a zone, you can view an interface show as Figure 4-62.



Figure 4-62

• Put the middle button at the center of the zone you want to zoom in, and move the mouse, you can view an interface shown as in Figure 4-63.



Figure 4-63

Right click mouse to cancel zoom and go back to the original interface.

#### 3) Manual record function

It is to back up the video of current channel to the USB device. System cannot backup the video of multiple-channel at the same time.

Click button system begins recording. Click it again, system stops recoridng. You can find the record file on the flash disk.

#### 4) Manual Snapshot

Click **I** to snapshot 1-5 times. The snapshot file is saved on the USB device or HDD. You can go to the Search interface (chapter 4.5) to view.

#### 5) Bidirectional talk

If the connected front-end device supports bidirectional talk function, you can click this button. Click

button 🔛 to start bidirectional talk function the icon now is shown as 🖳 . Now the rest bidirectional talk buttons of digital channel becomes null too.

Click Zagain, you can cancel bidirectional talk and the bidirectional talk buttons of other digital

channels become as

#### 6) Registration

Shortcut menu. Click it to go to the registration interface to add/delete remote device or view its corresponding information. Please refer to chapter 4.2.2 for detailed information.

#### 7) Switch bit streams

Click *M* to switch the bit stream type of the main stream and sub stream.

- M: Main stream. Its bit streams are big and definition is high. It occupies large network bandwidth suitable for video wall surveillance, storage and etc.
- S: Sub stream. Its definition is low but occupies small network bandwidth. It is suitable for general surveillance, remote connection and etc. Some series products support two sub streams (S1, S2). Refer to chapter 4.2.5.1 Encode for detailed information.

### 4.3.4 Right Click Menu

After you logged in the device, right click mouse, you can see the short cut menu. Please see Figure 4-64 or Figure 4-65.

- Window split mode: You can select window amount and then select channels.
- Edit view (Sequence): Change channel display sequence on the preview window.
- Customized screen: Set customized screen split mode.
- PTZ: Click it to go to PTZ interface.
- Fisheye (optional): It is to realize fish eye operation.
- Auto focus: It is to set auto focus function. Please make sure the connected network camera supports this function.
- Color setting: Set video corresponding information.
- Search: Click it to go to Search interface to search and playback a record file.
- Record control: Enable/disable record channel.
- Alarm output: It is to set alarm output mode.
- Camera registration: Search and add a remote device.
- Alarm output: Generate alarm output signal manually.
- Main menu: Go to system main menu interface.

#### Tips:

Right click mouse to go back to the previous interface.

	View 1	Þ
	View 4	Þ
	View 8	١.
	View 9	١.
	View 16	
₹	PTZ	
3	Fish Eye	
53	Auto Focus	
æ	lmage	
0	Search	
۲	Manual	▶
-	Camera Registration	า
	Main Menu	

Figure 4-64



Figure 4-65

## 4.3.5 Edit View (Sequence)

It is to set customized view layout.



The preview layout restores default channel layout after Default operation. (Main menu->Setting->General->Default).

Step 1 On the preview interface, right click mouse and then click Edit view. Enter edit view interface. See Figure 4-66.

### Note

- Enter edit view interface, device automatically switches to the max split amount mode.
- The channel list on the edit view interface displays the added camera channel number and

channel name. 💟 means camera is online. 🗾 means camera is offline.

 In case the channel amount has exceeded the device max split amount, the edit view interface can display the max screen number amount and current screen number. In Figure

4-66, click or , switch the video from other channel.

	Sequence	
<ul> <li>D11</li> <li>D13</li> <li>D14</li> <li>D15</li> <li>D17</li> <li>D18</li> <li>D19</li> <li>D20</li> <li>D21</li> <li>D22</li> </ul>	CAM 13 CAM 1 CAM 15 CAM 17 CAM 18 CAM 1 CAM 20 CAM 21 CAM 22 CAM 23	
Арг	ply Cancel	



Step 2 On the edit view interface, drag the channel to the desired window, or drag on the preview window to switch the position.

Check the channel number at the right bottom corner to view the current channel sequence. See Figure 4-67.



Figure 4-67

- Step 3 Click Apply to save current channel sequence.
   After you change the channel sequence, click Cancel button or right click mouse, device pops up the dialogue box. See Figure 4-68.
  - Click OK to save current settings.
  - Click Cancel to exit without saving the settings.



Figure 4-68

### 4.3.6 Preview Display Effect Setup

#### 4.3.6.1 Video Color

Here you can set hue, brightness, contrast, saturation, gain, white level, color mode and etc. See Figure 4-69.

COLOR
Period
Effective Time 🖌 🕜 : 00 - 24 : 00
Sharpness 🔺 🦲 50
Brightness 🔅 50
Contrast 🕕 50
Saturation 🖆 🛁 📕 50
Gain 🔲 50
Color Mode Standard 🔻
Customized Default OK Cancel

Figure 4-69

Item	Note				
Period	There are two periods in one day. You can set different				
	sharpness, brightness, and contrast setup for different periods.				
Effective Time	Check the box here to enable this function and then set $\ensuremath{period}$				
	time.				
	The value here is to adjust the edge of the video. The value				
	ranges from 0 to 100. The larger the value is, the clear the edge				
Sharpness	is and vice versa. Please note there is noise if the value here is				
	too high. The default value is 50 and the recommended value ranges from 40 to 60.				
Brightness	It is to adjust monitor window bright. The value ranges from 0 to 100. The default value is 50.				
	The larger the number, the bright the video is. When you input				
	the value here, the bright section and the dark section of the				
	video will be adjusted accordingly. You can use this function				
	when the whole video is too dark or too bright. Please note the				
	video may become hazy if the value is too high. The				
	recommended value ranges from 40 to 60.				
Contrast	It is to adjust monitor window contrast. The value ranges from 0 to 100. The default value is 50.				
	The larger the number, the higher the contrast is. You can use				
	this function when the whole video bright is OK but the contrast				
	is not proper. Please note the video may become hazy if the				
	value is too low. If this value is too high, the dark section may				
	lack brightness while the bright section may over exposure .The				
	recommended value ranges from 40 to 60.				
Saturation	It is to adjust monitor window saturation. The value ranges from				

Item	Note
	0 to 100. The default value is 50.
	The larger the number, the strong the color is. This value has no effect on the general brightness of the whole video. The video color may become too strong if the value is too high. For the grey part of the video, the distortion may occur if the white balance is not accurate. Please note the video may not be attractive if the value is too low. The recommended value ranges from 40 to 60.
Gain	The gain adjust is to set the gain value. The default value may vary due to different device models. The smaller the value, the low the noise. But the brightness is also too low in the dark environments. It can enhance the video brightness if the value is high. But the video noise may become too clear.
Color mode	It includes several modes such as standard, color, bright, gentle. Select a color mode, the sharpness, brightness, contrast and etc can automatically switch to corresponding setup.

#### 4.3.6.2 Display

From Main Menu->Setting->System->Display->Display, you can go to the following interface. See Figure 4-70.

Here you can set menu and video preview effect. All you operation here does not affect the record file and playback effect.

	SETTING
SAMERA	77 NETWORK 📷 EVENT SYSTEM
GENERAL	
DISPLAY	Display Tour
VOICE PROMPT	Transparency <b></b> 0 %
ACCOUNT	Time Display
SECURITY	Channel Display 🕗
AUTO MAINTAIN	Image Enhance 🔲
IMP/EXP	IVS Rule 🔽
DEFAULT	Original Scale Set
UPGRADE	Resolution (1280×1024 💌
	Default OK Cancel Apply



Now you can set corresponding information.

- Display the intelligent rule(s): Check the box to enable IVS function, system can display IVS rule on the preview interface. Please note this function is for some series only.
- Resolution: There are five options: 1280×1024 (Default), 1280×720, 1920×1080, 1024×768 and 3840×2160. Please note the system needs to reboot to activate current setup. Please note 3840×2160 is for some series only.
- VGA+HDMI2: It is for dual-screen operation. Please select from the dropdown list according to your actual situation. Click Apply button, system needs to restart to activate new setup. For example, 32+4 means for VGA, system max supports 32-window split and for HDMI2, system max supports 4-window split. Please note this function is for some series only.
- Transparency: Here is for you to adjust menu transparency. The higher the value is, the better transparent the menu is.
- Time display: You can select to display time or not when system is playback.
- Channel display: You can select to channel name or not when system is playback.
- Image enhance: Check the box; you can optimize the margin of the preview video.
- Original scale: Check the box here to select a corresponding channel; it can restore video original scale.

Click OK button to save current setup.

4.3.6.3 TV adjust

# Note

Some series product supports TV adjust function. This function is disabled by default.

From Main Menu->Setting->System->Display->TV adjust; you can go to the following interface. See Figure 4-70. Here you can set margins and brightness.

	SETTING	
📆 CAMERA	🗃 NETWORK 📷 EVENT 🔤 STORAGE 🗖 SYSTE	м
GENERAL DISPLAY RS232 PTZ ACCOUNT AUTO MAINTAIN IMP/EXP DEFAULT UPGRADE	Display       TV Adjust       Tour         Top Margin       0         Bottom Margin       0         Left Margin       0         Right Margin       0         Brightness       128	Apply

Figure 4-71

Set preview display mode, channel display sequence and tour setup.

- Set preview display mode: On the preview interface, right click mouse, you can view right-click menu. Now you can select preview window amount and channel.
- Set channel display mode: On the preview interface, if you want to change channel 1 and channel 16 position, please right click channel 1 video window and then drag to the channel 16 video window, release button, you can change channel 1 and channel 16 position.
- Tour setup: Here you can set preview window channel display mode and interval. Please follow the steps listed below.

From Main menu->Setting->System->Display->Tour, you can see an interface shown as in Figure 4-72. Here you can set tour parameter.

- Enable tour: Check the box here to enable tour function. The general tour supports all types of window split mode.
- Interval: Input proper interval value here. The value ranges from 1-120 seconds.
- Motion tour type: System support 1/8-window tour. Please note you need to go to the main menu->Setting->Event->Video detect->Motion detect to enable tour function.
- Alarm tour type: System support 1/8-window tour. Please note you need to go to the main menu->Setting->Event->Alarm to enable tour function.
- Window split: It is to set window split mode.

	SETTING
SAMERA	7 NETWORK 📷 EVENT SYSTEM
GENERAL DISPLAY VOICE PROMPT ACCOUNT SECURITY AUTO MAINTAIN	Display     Tour       Video Detect     View 1       Enable Tour     Interval       Interval     5       Window Split     View 4       2     Window Split
IMP/EXP DEFAULT UPGRADE	
	Add Del Move up Move down
	Default OK Cancel Apply

Figure 4-72

#### Tips

On the navigation bar, click () to enable/disable tour.

Click Save button to save current setup.

4.3.6.5 Customized split

It is to set customized video split mode.

Note

• This function is for some series products. Please refer to the actual product for detailed information.

• Device max supports 5 customized videos.

From Main menu->Setting->System->Display->Custom split, you can see an interface shown as in Figure 4-73.

		SET	ITING			
	TWORK 👬	👼 EVEN	г 📴	STORAGE	SYST	EM
GENERAL DISPLAY RS232 PTZ POS BROADCAST VOICE PROMPT ACCOUNT AUTO MAINTAIN IMP/EXP DEFAULT UPGRADE	Display + Name Del Split25 X	Tour C	ustom Split			
		×		OK Can		ply

Figure 4-73



In regular mode, drag the mouse in the preview frame; you can merge several small windows to one window so that you can get you desired split mode.

After the setup, the selected window has the red frame. See Figure 4-74.

		5	ETTING				
		📆 EVE	NT	STORA	AGE	SYSTEI	м
GENERAL DISPLAY PTZ POS BROADCAST ACCOUNT AUTO MAINTAIN IMP/EXP DEFAULT UPGRADE	Display	Tour	Custom Sp				
		×	(	ок )	Cance		ply

Figure 4-74

Select the merging window, the frame is red; you can click to cancel the merge to restore regular mode.

Click Save to exit.

After the setup, you can go to the preview window, right click mouse and then select custom split. See Figure 4-75.



Figure 4-75

### 4.3.7 Fisheye (Optional)

#### Please note this function is for some series only.

4.3.7.1 Fisheye de-warp during preview interface

The fisheye camera (panoramic camera) has wide video of angle but its video is serious distorted. The de-warp function can present the proper and vivid video suitable for human eyes.

On the preview interface, select fisheye channel and then right click mouse, you can select fish eye. See Figure 4-76.

	View 1	►
	View 4	►
	View 8	►
	View 9	►
	View 16	
₹	PTZ	
3	Fish Eye 📐	
[+]	Auto Focus	
AD I		
æ	Image	
	Image Search	
O,	J	•_
<b>्</b> ●	Search	•
(°, ♦ 🖬	Search Manual	•

Figure 4-76

Now you can see an interface shown as in Figure 4-77. You can set fish eye installation mode and display mode.

Note

- For the non-fish eye channel, system pops up dialogue box to remind you it is not a fish eye channel and does not support de-warp function.
- If system resources are insufficient, system pops up the corresponding dialogue box too.





There are three installation modes: ceiling mount/wall mount/ground mount. The different installations modes have different de-warp modes.

Please refer to the following sheet for detailed information.

Installation modes	lcon	Note
(Ceiling mount)		360°panorama original view
	<b>←→</b>	1 de-warp window+1 panorama stretching
(Ground mount)	$\begin{array}{c} \uparrow \\ \uparrow \\ \hline \end{array}$	2 panorama stretching view
	Q	1 360° panorama view+3 de-warp windows
	Ω⊞	1 360°panorama view+4 de-warp windows
		4 de-warp windows+1 panorama stretching
	Q	1 360° panorama view+8 de-warp windows
	0	360°panorama original view
(Wall mount)	$\times$	Panorama stretching

	1 panorama unfolding view+3 de-warp windows
X	1 panorama unfolding view +4 de warp windows
X	1 panorama unfolding view +8 de warp windows



Figure 4-78

In Figure 4-78, you can adjust the color pane on the left pane or use your mouse to change the position of the small images on the right pane to realize fish eye de-warp.

4.3.7.2 Fish eye de-warp during playback

Step 1 On the main menu, click search button.

- Step 2 Select 1-window playback mode and corresponding fish eye channel, click 🕨 to play.
- Step 3 Right click the , you can go to the de-warp playback interface. For detailed information, please refer to chapter 4.3.7.1 fisheye de-warp during preview.

### 4.4 PTZ

### Note

Before you control the PTZ, please make sure the PTZ decoder and the NVR network connection is OK and the corresponding settings are right.

#### 4.4.1 PTZ Settings

#### **Cable Connection**

Please follow the procedures below to go on cable connection

- Connect the dome RS485 port to NVR RS485 port.
- Connect dome video output cable to NVR video input port.
- Connect power adapter to the dome.

In the main menu, from Setting->System->PTZ, you can see an interface is shown as in Figure 4-79. Here you can set the following items:

• Channel: Select the current camera channel.

- PTZ type: There are two types: local/remote. Please select local mode if you are connect RS485 cable to connect to the Speed dome (PTZ). Please select remote mode if you are connecting to the network PTZ camera.
- Protocol: Select corresponding PTZ protocol(such as PELCOD)
- Address: Default address is 1.
- Baud rate: Select corresponding baud rate. Default value is 9600.
- Data bit: Select corresponding data bits. Default value is 8.
- Stop bit: Select corresponding stop bits. Default value is 1.
- Parity: There are three options: odd/even/none. Default setup is none.

	SETTING		
🥰 CAMERA	📻 NETWORK 🛛 🔂 EVENT	STORAGE	SYSTEM
GENERAL DISPLAY RS232 PTZ POS BROADCAST VOICE PROMPT ACCOUNIT AUTO MAINTAIN IMP/EXP DEFAULT UPGRADE	Channel D3 • PTZ Type Local • Protocol NONE • Address 1 Baud Rate 9600 • Data Bit 8 • Stop Bit 1 • Parity None •		
	Default Copy	ОК	Cancel Apply

Figure 4-79

If you are connecting to network PTZ, the PTZ type shall be remote. See Figure 4-80.

	SETTING		
🥰 CAMERA	🐞 NETWORK 🛛 📆 EVENT	STORAGE	SYSTEM
GENERAL DISPLAY RS232 PTZ POS BROADCAST VOICE PROMPT ACCOUNT AUTO MAINTAIN IMP/EXP DEFAULT UPGRADE	Channel D1 • PTZ Type Remote •		
	Default Copy	ОК (	Cancel Apply

Figure 4-80

### 4.4.2 PTZ Control

After completing all the setting please click save button. Right click mouse (click "Fn" Button in the front panel or click "Fn" key in the remote control). The interface is shown as in Figure 4-81. Please note you can only go to the PTZ control interface when you are in 1-window display mode.

	View 1	►
	View 4	►
	View 8	Þ
	View 9	Þ
	View 16	•
25	View 25	►
36	View 36	
∎	PTZ	
	PTZ Auto Pocus	
5+3		
33 19	Auto Pocus	
€ <b>8</b> 0,	Auto Pocus Color Setting	<b>→</b>
E & O	Auto Pocus Color Setting Search	•



The PTZ setup is shown as in See Figure 4-82.

Please note the commend name is grey once device does not support this function.

The PTZ operation is only valid in one-window mode.

Here you can control PTZ direction, speed, zoom, focus, iris, preset, tour, scan, pattern aux function, light and wiper, rotation and etc.

Speed is to control PTZ movement speed. The value ranges from 1 to 8. The speed 8 is faster than speed 1. You can use the remote control to click the small keyboard to set.

You can click i and i f the zoom, focus and iris to zoom in/out, definition and brightness.

The PTZ rotation supports 8 directions. If you are using direction buttons on the front panel, there are only four directions: up/down/left/right.



Figure 4-82

In the middle of the eight direction arrows, there is a 3D intelligent positioning key. See Figure 4-83. Please make sure your protocol supports this function and you need to use mouse to control.

Click this key, system goes back to the single screen mode. Drag the mouse in the screen to adjust section size. The dragged zone supports 4X to 16X speeds. It can realize PTZ automatically. The smaller zone you dragged, the higher the speed.



Name	Function	function	Shortcut	Function	function	Shortcut
	key		key	key		key
Zoom	0	Near	ŀ	•	Far	*
Focus	•	Near	◀	•	Far	►
Iris	0	close	◀	•	Open	► II

In Figure 4-82, click to open the menu, you can set preset, tour, pattern, scan and etc. See Figure 4-84.



#### Figure 4-84

Please refer to the following sheet for detailed information.

Please note the above interface may vary due to different protocols. The button is grey and cannot be selected once the current function is null.

Right click mouse or click the ESC button at the front panel to go back to the Figure 4-82.

lcon	Function	lcon	Function
•	Preset	Œ	Flip
	Tour	Ð	Reset
~	Pattern		Aux
	Scan	0	Aux on-off button
Ð	Rotate	0	Go to menu

4.4.2.1 PTZ Function Setup

Click you can go to the following interface to set preset, tour, pattern, and scan. See Figure 4-85.

(	Р	TZ	
Preset	Tour	Pattern	Border
		Preset	1
		Del P	et) <sup>i</sup> reset



#### **Preset Setup**

In Figure 4-85, click preset button and use eight direction arrows to adjust camera to the proper position.

The interface is shown as in Figure 4-86.

Click Set button and then input preset number.

Click Set button to save current preset.

(	P	TZ	
Preset	Tour	Pattern	Border
		Preset	1
			et) Preset

Figure 4-86

#### Tour Setup

In Figure 4-85, click tour button.

Input tour value and preset No. Click Add preset button to add current preset to the tour. See Figure 4-87. **Tips** 

Repeat the above steps to add more presets to the tour. Click Del preset button to remove it from the tour. Please note some protocols do not support delete preset function.

	PTZ		
Preset	Tour	Pattern	Border
	K	Preset Patrol No Add F Del P Del <sup>-</sup>	Preset

Figure 4-87

#### Pattern Setup

In Figure 4-85, click Pattern button and input pattern number.

Click Begin button to start direction operation. Or you can go back to Figure 4-82 to operate zoom/focus/iris/direction operation.

In Figure 4-85, click End button.



Figure 4-88

#### Scan Setup

call.

**Call Tour** 

In Figure 4-85, click Scan button.

Use direction buttons to set camera left limit and then click Left button.

Use direction buttons to set camera right limit and then click Right button. Now the scan setup process is complete.



In Figure 4-84, input tour value and then click to call a tour. Click again

#### **Call Scan**

In Figure 4-84, input Scan value and then click

#### Rotate



In Figure 4-84, click to enable the camera to rotate.

System supports preset, tour, pattern, scan, rotate, light and etc function.

#### Note:

- Preset, tour and pattern all need the value to be the control parameters. You can define it as you • require.
- You need to refer to your camera user's manual for Aux definition. In some cases, it can be used for • special process.

#### Aux

Click system goes to the following interface. The options here are defined by the protocol. The aux number is corresponding to the aux on-off button of the decoder. See Figure 4-90.



Figure 4-90

### 4.5 Record File

Device adopts 24-hour continuous record by default. It supports customized record period and record type. Refer to chapter 4.1.4.6 Schedule for detailed information.

### 4.6 Playback and Search

#### 4.6.1 Instant Playback

Please refer to chapter 4.3.2 for real-time playback information.

#### 4.6.2 Search Interface

From Main menu->Search, or on the preview interface right click mouse and then select search item, you can go to the following interface. See Figure 4-91 or Figure 4-92.



to call a tour. Click again



to stop call.



Figure 4-91



Figure 4-92

Please refer to the following sheet for more information.

SN	Name	Function
	Display	Here is to display the searched picture or file.
1	1 window	<ul> <li>Support 1/4/9/16-window playback. (It depends on the product channel amount).</li> </ul>
2	Search type	<ul> <li>Here you can select to search the picture or the recorded file.</li> <li>You can select to play from the read-write HDD, from peripheral device or from redundancy HDD.</li> <li>Before you select to play from the peripheral device, please connect the corresponding peripheral device. You can view all record files of the root directory of the peripheral device. Click the Browse button; you can select the file you want to play.</li> <li>Important</li> <li>Redundancy HDD does not support picture backup function, but it supports picture playback function. You can select to play from redundancy HDD.</li> </ul>
3	Calendar	<ul> <li>The blue highlighted date means there is picture or file. Otherwise, there is no picture or file.</li> <li>In any play mode, click the date you want to see, you can see the corresponding record file trace in the time bar.</li> </ul>
4	Playback mode and channel selection pane.	<ul> <li>Playback mode:1/4/9/16. (It may vary due to different series.)</li> <li>In 1-window playback mode: you can select 1-X channels (X depends on the product channel amount).</li> <li>In 4-window playback mode: you can select 4 channels according to your requirement.</li> <li>In 9-window playback mode, you can switch between 1-8, 9-16 and etc channels.</li> <li>In 16-window playback mode, you can switch between1-16, 17-32 and etc channels.</li> <li>The time bar will change once you modify the playback mode or the channel option.</li> </ul>
5	Card number search	The card number search interface is shown as below. Here you can view card number/field setup bar. You can implement advanced search. <b>Current series product supports this function.</b>
6	Face list	You can search when it is in 1-channel playback mode. Click it, system can filter all human faces and generate human face list. Double click the file; system begins playback the record or image of the corresponding human face.
7	Mark file list button	Click it to go to mark file list interface. You can view all mark information of current channel by time. Please refer to chapter 4.6.4 for detailed information. Please note only the product of this icon supports mark function.

8	File list switch button	<ul> <li>Double click it, you can view the picture/record file list of current day.</li> <li>The file list is to display the first channel of the record file.</li> <li>The system can display max 128 files in one time. Use the &lt;   and   ▶ or the mouse to view the file. Select one item, and then double click the mouse or click the ENTER button to playback.</li> <li>You can input the period in the following interface to begin accurate search.</li> <li>File type:R—regular record; A—external alarm record; M—Motion detect record.</li> <li>Lock file. Click the file you want to lock and click the button  to lock. The file you locked will not be overwritten.</li> </ul>
		• Search locked file: Click the button to view the locked file.
	Playback control pane.	<ul> <li>Play/Pause There are three ways for you to begin playback.</li> <li>The play button</li> <li>Double click the valid period of the time bar.</li> <li>Double click the item in the file list.</li> <li>In slow play mode, click it to switch between play/pause.</li> </ul>
		■ Stop
		<ul> <li>Backward play</li> <li>In normal play mode, left click the button, the file begins backward play.</li> <li>Click it again to pause current play.</li> <li>In backward play mode, click ►/ II to restore normal play.</li> </ul>
9		<ul> <li>In playback mode, click it to play the next or the previous section. You can click continuously when you are watching the files from the same channel. In normal play mode, when you pause current play, you can click ◀ and   ► to begin frame by frame playback. In frame by frame playback mode, click ►/II to restore normal playback.</li> <li>Slow play In playback mode, click it to realize various slow play modes such as slow play 1, slow play 2, and etc.</li> <li>Fast forward</li> <li>In playback mode, click to realize various fast play modes such as fast play 1 fast play 2 and etc.</li> </ul>
		play 1, fast play 2 and etc.
		Note: The actual play speed has relationship with the software version.
		Smart search
		he volume of the playback

	1		
		<ul> <li>Click the snapshot button in the full-screen mode, the system can snapshot 1 picture.</li> <li>System supports custom snap picture saved path. Please connect the peripheral device first, click snap button on the full-screen mode, you can select or create path. Click Start button, the snapshot picture can be saved to the specified path.</li> <li>Mark button.</li> <li>Please note this function is for some series product only. Please make sure there is a mark button in the playback control pane. You can refer to chapter 4.6.4 for detailed information.</li> </ul>	
		In 1-channel playback mode, click it to enable/disable display IVS rule information on the video.	
10	Time bar	<ul> <li>It is to display the record type and its period in current search criteria.</li> <li>In 4-window playback mode, there are corresponding four time bars. In other playback mode, there is only one time bar.</li> <li>Use the mouse to click one point of the color zone in the time bar, system begins playback.</li> <li>The time bar is beginning with 0 o'clock when you are setting the configuration. The time bar zooms in the period of the current playback time when you are playing the file.</li> <li>The green color stands for the regular record file. The red color stands for the external alarm record file. The yellow stands for the motion detect record file.</li> </ul>	
11	Time bar unit	<ul> <li>The option includes: 24hr, 2hr, 2hr, 2hr, 2hr, 20min, . The smaller the unit, the larger the zoom rate. You can accurately set the time in the time bar to playback the record.</li> <li>The time bar is beginning with 0 o'clock when you are setting the configuration. The time bar zooms in the period of the current playback time when you are playing the file.</li> </ul>	
12	Backup	<ul> <li>Select the file(s) you want to backup from the file list. You can check from the list. Then click the backup button, now you can see the backup menu. System supports customized path setup. After select or create new folder, click the Start button to begin the backup operation. The record file(s) will be saved in the specified folder.</li> <li>Check the file again you can cancel current selection. System max supports to display 32 files from one channel.</li> <li>After you clip on record file, click Backup button you can save it.</li> <li>For one device, if there is a backup in process, you cannot start a new backup operation.</li> </ul>	
13	Clip	<ul> <li>It is to edit the file.</li> <li>Please click to play the file you want to edit.</li> <li>Select clip start time on the time bar and then Click to start clip.</li> </ul>	

	Record	<ul> <li>Select clip stop time on the time bar and then click is to stop clip.</li> <li>Click is, system pops up file backup dialogue box for you to save.</li> <li>Please note:</li> <li>Clip function is for one-channel mode/multiple-channel mode.</li> <li>System max supports 1024 files backup at the same time.</li> <li>You cannot operate clip operation if there is any file has been checked in the file list.</li> </ul>
14	type	In any play mode, the time bar will change once you modify the search type.
		Other Functions
15	Motion detection search	<ul> <li>When system is playing, you can select a zone in the window to begin motion detection search. Click the motion detect button to begin play.</li> <li>Once the motion detect play has begun, click button again will terminate current motion detect file play.</li> <li>There is no motion detect zone by default.</li> <li>If you select to play other file in the file list, system switches to motion detect play of other file.</li> <li>During the motion detect play process, you cannot implement operations such as change time bar, begin backward playback or frame by frame playback.</li> </ul>
16	Other channel synchroni zation switch to play when playback	When playing the file, click the number button, system can switch to the same period of the corresponding channel to play.
17	Digital zoom	When the system is in full-screen playback mode, left click the mouse in the screen. Drag your mouse in the screen to select a section and then left click mouse to realize digital zoom. You can right click mouse to exit.
18	Manually switch channel when playback	During the file playback process, you can switch to other channel via the dropdown list or rolling the mouse. This function is null if there is no record file or system is in smart search process.

# III Note

All the operations here (such as playback speed, channel, time and progress) have relationship with hardware version. Some series NVRs do not support some functions or playback speeds. 4.6.2.1 Playback Control

The playback control interface is shown as below. See Figure 2-37.


# Figure 4-93

Please refer to the following sheet for more information.

lcon	Function
	Play/Pause
	In slow play mode, click it to switch between play/pause.
	Backward play
	• In normal play mode, left click the button, the file begins backward
	play. Click it again to pause current play.
	<ul> <li>In backward play mode, click bor II to restore normal play.</li> </ul>
	Display previous frame/next frame.
	• When pause the normal playback file, click $\blacktriangleleft$ or $\blacktriangleright$ to
	playback frame by frame.
	<ul> <li>In frame by frame playback mode, click b or II to resume</li> </ul>
	normal playback mode.
	Slow play
	In playback mode, click it to realize various slow play modes such as
	slow play 1, slow play 2, and etc.
	Fast forward
	In playback mode, click to realize various fast play modes such as
	fast play 1,fast play 2 and etc.
	Adjust the volume of the playback
	Smart search .
x	You can refer to chapter 4.6.3 for detailed information.
	Click the snapshot button in the full-screen mode, the system can
	snapshot 1 picture.
0	System supports custom snap picture saved path. Please connect the
	peripheral device first, click snap button on the full-screen mode, you
	can select or create path. Click Start button, the snapshot picture can
	be saved to the specified path.
	Mark button.
	Please note this function is for some series product only. Please make
	sure there is a mark button in the playback control pane.
	You can refer to chapter 4.6.4 for detailed information.
POS	Display/hide POS information. In 1-channel playback mode, you can click it to display/hide POS
	information on the video.

Icon	Function
	Note
<b>(+</b>	This function is for some series only.
	In 1-channel playback mode, click it to enable/disable display IVS rule
	information on the video.

### 4.6.2.2 Clip

This function allows you to clip some footages to a new file and then save to the USB device. See Figure 2-39. Please follow the steps listed below.





### D Note

- Clip function is for one-channel/multiple-channel.
- Max save 1024 files at the same time.
- This function is not for the file already checked in the file list.

### 4.6.2.3 Record Backup

This function is to backup files you checked in the file list, or the file you just clip.

Click E, enter the following interface. See Figure 4-95.

	_		Backup	
1	Name(Type)	Free	e Space/Total Space	Device Status
1	⊡ sda1(USB I	DISK) 64	5.25 MB/14.45 GB	Ready
2	🗸 СН Туре	 Start Time	End Time	Size(KB)
1	✓ 8 R		17-04-19 13:48:44	
2	✓ 8 R ✓ 8 R	17-04-19 13:51:26	17-04-19 14:07:51	510336
				evice or file.

Figure 4-95

Click Backup to begin the process.

### 4.6.3 Smart Search Playback

# Note

This function is for some series product only.

During playback process, it can analyze the motion detect zone in the scene and give the analysis result.

This function is for channel that already enabled motion detect function (main menu->Setting->Event->Video detect->Motion detect).

Please follow the steps listed below.

Nou can view the grids on the playback Select a channel to playback video and then click Step 1 video.

# D Note

- This function is for one-channel playback mode.
- If you are in multiple-channel playback mode, double click a channel first to switch to one-channel playback mode.
- Left click mouse and then drag to select smart search zones(22\*18 (PAL), 22\*15 (NTSC)). Step 2
- to go to smart search and playback. System is going to playback all motion detect Step 3 Click record footages.

again to stop smart search function. Step 4 Click

### 4.6.4 Mark Playback

Please make sure your purchased device support this function. You can use this function only if you can see the mark playback icon on the Search interface (Figure 4-91 or Figure 4-92).

When you are playback record, you can mark the record when there is important information. After playback, you can use time or the mark key words to search corresponding record and then play. It is very easy for you to get the important video information.

### Add Mark

When system is playback, click Mark button, you can go to the following interface. See Figure 4-96.

Add Mark
Mark Time (2013-09-27 10:01:08 Mark Name (
Default OK Cancel



### Playback Mark

During 1-window playback mode, click mark file list button in Figure 4-91 or Figure 4-92, you can go to mark file list interface. Double click one mark file, you can begin playback from the mark time.

• Play before mark time

Here you can set to begin playback from previous N seconds of the mark time.

### Note

Usually, system can playbacks previous N seconds record if there is such kind of record file. Otherwise, system playbacks from the previous X seconds when there is such as kind of record.

Mark Manager

Click the mark manager button on the Search interface (Figure 4-91 or Figure 4-92); you can go to Mark Manager interface. See Figure 4-97. System can manage all the record mark information of current channel by default. You can view all mark information of current channel by time.

	Marks Manager	
Start Time	(1) (2013 - 09 - 27   00 : 00 : 00 (2013 - 09 - 28   00 : 00 : 00 CH Mark Time	Search
	1 2013-09-27 10:00:12	report
	• 	
Delete		Exit

Figure 4-97

### Modify

Double click one mark information item, you can see system pops up a dialogue box for you to change mark information. You can only change mark name here.

### Delete

Here you can check the mark information item you want to delete and then click Delete button, you can remove one mark item. .

# Note

- After you go to the mark management interface, system needs to pause current playback. System resume playback after you exit mark management interface.
- If the mark file you want to playback has been removed, system begins playback from the first file in the list.

### 4.6.5 Playback Image

Here you can search and play the image. Please follow the steps listed below.

- Step 1 From main menu->Search, or on the preview window right click mouse and then click Search, you can go to the search interface.
- Step 2 At the top right corner, select image and then input playback interval.

Step 3 Select date and channel, click 🕨 to play.

### 4.6.6 Splice Playback

For the large record file, you can use splice playback function to play the same file in several sections at the same time. It is very convenient for you to find the video footages you desire.

On the main menu, click Search button, or right click mouse and then select Search. You can go to Figure 4-91 or Figure 4-92

On the right pane, check the box to enable splice playback function, and then set channel, date, split mode. The splice playback interface is shown as below. Each section has a small triangle; you can adjust



Figure 4-98

### III Note

Select split mode, so that the record can be spliced in several sections.

Select splice file.

- Click Playback, system playbacks from the first of current date by default.
- Click time bar, system playbacks from the time you click.
- Click I, you can select on the file list.

# D Note

- The splice playback is for 1-window playback mode.
- System supports 1/4/8/16-split mode. Slight different may be found here. The 4-channel series product supports 4-split mode. The 8-channel series product support 8-split mode. The 16-channel or higher series product supports 16-split mode.
- The min period of each section is 5 minutes. For the record is less than 20 minutes, if you select 4-split mode (or more than 4-split mode), system can auto adjust so that the each section period is 5 minutes. In this situation, some channel may have no video.

### 4.6.7 Smart Playback

It is to search and playback the IVS file, human face file and plate recognition record.

D Note

- There are two types to realize intelligent analytics function.
- Smart network camera supports intelligent functions: Some smart camera supports the intelligent functions. For NVR, it just displays the intelligent alarm information from the smart network camera and set or playback the record file.
- NVR supports intelligent functions: The connected network camera does not support intelligent video analytics function. The NVR supports the analytics function.
- This function is to playback the intelligent record file of the smart camera.

### 4.6.7.1 IVS File

IVS extracts the key information in video based on image processing and analysis, and matches it with the preset detection rules. You can screen out and play the videos matching the rules.

Step 1 From main menu->Operation->Smart Play->IVS.

Enter the IVS interface. See Figure 4-99.

	_	SMART PLAY
IVS		
FACE DETECT		
FACE RECOG ANPR	Channel	
HUMAN BODY	Start Time	2018 - 03 - 14 00 : 00 : 00
	End Time	2018 - 03 - 14 23 : 59 : 59
	Event Type	All
	*	
		Smart Search Cancel

Figure 4-99

Step 2Select Channel, Start Time, End Time and Event Type. Click Smart Search.<br/>The search results are displayed. See Figure 4-100.



Figure 4-100

- Step 3 Click the picture to play the video file.
  - Select the file, click is and select the backup catalog in the backup interface. Select backup type and file type, choose the file and click Start to save the file to an external storage device. See Figure 4-101.

	MB(Space	ISK)/NVR/2 Needed)	5.84 GB/7.22 GB(Free/	Total)		Browse
✓ \	/ideo	🔲 Pic		File Type(	DAV 🕝	
4	🗸 🔽 Char	nnel Type	Start Time	End Time	Size(KB)	]
1	✓ 3	R	18-03-14 15:52:47	18-03-14 15:53:06	9776	
2	✓ 2	1	18-03-14 15:52:47	18-03-14 15:53:06	5281	
3	<b>√</b> 3	R	18-03-14 16:59:52	18-03-14 17:00:11	10091	
4	✓ 2	1	18-03-14 16:59:52	18-03-14 17:00:11	5423	
						Start
				ł		

• Select the file and click is to lock the file. The locked file will not be overwritten.

• Select the file and click it to mark the time of the detected event.

### 4.6.7.2 Search Human Face (Optional)

Human face detection is to analyze the video from the camera and check there is any human face or not. It is to search and playback human face record.

Step 1 From main menu->Operation->Smart Play->Face Detection. Enter the Face Detection interface. See Figure 4-102.

INS   FACE DECOC   AIPP   MUMAN BODY     Channel   D   Stat Time   Q13   03   14   2013   03   14   2013   03   14   2013   03   14   2013   03   14   2013   03   14   2013   03   14   2013   03   14   2013   03   14   2013   03   14   2013   03   14   2013   03   14   2013   14   2013   15   16   17   18   18   19                     10   10   11   12   13   14   15                              16   17   18   18   19	_	SMART PLAY
FACE DETECT   FACE RECOG   ANPR   HUMAN BODY     Channel   D1   Start Time   2018 - 03 - 14   01 00 : 00 : 00     End Time   2018 - 03 - 14   Gender   All   Age   All   Beard   All   Mask     All		
FACE RECOG       Channel       D1       •         ANPR       Start Time       2018 - 03 - 14       00 : 00 : 00         HUMAN BODY       End Time       2018 - 03 - 14       23 : 59 : 59         Gender       All       •         Age       All       •         Beard       All       •         Mask       All       •		
ANPR HUMAN BODY Start Time 2018 - 03 - 14 00 : 00 : 00 End Time 2018 - 03 - 14 23 : 59 : 59 Gender All • Age All • Glasses All • Mask All •		
HUMAN BODY       Start Time       2018 - 03 - 14 00 : 00 : 00         End Time       2018 - 03 - 14 23 : 59 : 59         Gender       All         Age       All         Glasses       All         Mask       All	Channel	( <u>D1</u> )
Gender All Classes	Start Time	2018 - 03 - 14   00 : 00 : 00
Age All Glasses All Beard All Mask All V	End Time	(2018 -03 -14   23 : 59 : 59
Glasses All Beard All Mask All	Gender	All
Beard All Mask All	Age	All
Mask All	Glasses	All
<b>h</b>	Beard	All
	Mask	(All )
		7
Smart Search Cancel		
		Smart Search

Figure 4-102

Step 2 Select Channel, Start Time and End Time, and choose the details for face detection as needed, such as gender, age, wearing glasses or not, wearing mask or not and with beard or not. Click Smart Search.

The search results are displayed. See Figure 4-103.



#### Figure 4-103

### 

The black blocks in the above picture is for privacy protection which will not appear in actual snapped images.

Step 3 Click the image; you can view the record file.

- Select the file, click is and select the backup catalog in the backup interface. Select backup type and file type, choose the file and click Start to save the file to an external storage device.
- Select a file and then click <sup>[1]</sup>, you can lock current file in case it will be overwritten in the future
- Select a file and then click *integral*, you can mark the time of the detected event.
- For more details, please refer to face properties and human details.

### 4.6.7.3 Plate Recognition

It is to search and playback the record file containing the plate number.

Step 1 From main menu->Operation->Smart Play->ANPR. Enter the ANPR interface. See Figure 4-104.

		SMART PLAY		
IVS				
FACE DETECT				
FACE RECOG	Channel	D1 ,		
ANPR HUMAN BODY	Start Time	(2018 -03 -14   00 :00 :00 )		
HUMAN BODT				
	End Time	(2018 - 03 - 14   23 : 59 : 59		
	License			
		₹		
			Smart Search Cancel	
				_

Figure 4-104

Step 2 Set plate number, channel number, start time, end time.

# 🛄 Note

Device supports fuzzy plate number search function. Device searches all plate numbers by default if you do not input plate number information.

Step 3 Click Smart Search. Device displays the corresponding image. See Figure 4-105.





- Step 4 Click the image; you can view the record file.
  - Click E. Select Device Name and Address in the Browse interface and click OK to export plate information. See Figure 4-106.

		Browse				
Device Name Total Space	(sdb1(USB DISK)))	Refresh Free Space	(5.84 GB			
Address	(/NVR/PlateList/					
Name	st_20180309_eng.csv		Size	Type Folder 38 B File	Del 🗙	
				<b>k</b>		
	_	_	_		Cancel	
		Figure 4-106	6			
lect a file and	then click	ou can save c	urrent file to	peripheral s	torage device.	

- Select a file and then click , you can lock current file in case it will be overwritten in the future
- Select a file and then click , you can mark the time of the detected event.

### 4.6.8 File List

•

Click III, system displays file list. It displays the first channel of the record. See Figure 4-107.

1       2       3       4         StartTime Type       •         00:00:00 R       •         00:34:00 R       •         02:00:00 R       •         03:00:00 R       •         05:00:00 R       •         06:00:00 R       •         07:00:00 R       •         09:00:00 R       •         09:00:00 R       •         10:50:35 R       •         10:56:50 R       •         10:59:47 R       •         11:21:14 R       •         11:26:34 R       •         11:27:00 R       •         11:32:37 R       •
00:00:00 R 00:34:00 R 02:00:00 R 03:00:00 R 04:00:00 R 05:00:00 R 06:00:00 R 07:00:00 R 07:00:00 R 09:00:00 R 10:50:35 R 10:54:11 R 10:56:50 R 10:59:47 R 11:26:34 R 11:26:34 R 11:27:00 R
00:34:00 R 02:00:00 R 03:00:00 R 04:00:00 R 05:00:00 R 06:00:00 R 07:00:00 R 07:00:00 R 09:00:00 R 10:50:35 R 10:54:11 R 10:56:50 R 10:59:47 R 11:26:34 R 11:26:34 R 11:27:00 R
02:00:00 R 03:00:00 R 04:00:00 R 05:00:00 R 06:00:00 R 07:00:00 R 08:00:00 R 09:00:00 R 10:50:35 R 10:50:35 R 10:54:11 R 10:56:50 R 10:59:47 R 11:26:50 R 11:21:14 R 11:26:34 R 11:27:00 R
03:00:00 R 04:00:00 R 05:00:00 R 06:00:00 R 07:00:00 R 08:00:00 R 09:00:00 R 10:50:35 R 10:54:11 R 10:56:50 R 10:59:47 R 11:26:34 R 11:26:34 R 11:27:00 R
04:00:00 R 05:00:00 R 06:00:00 R 07:00:00 R 09:00:00 R 10:00:00 R 10:50:35 R 10:54:11 R 10:56:50 R 10:59:47 R 11:26:34 R 11:26:34 R 11:27:00 R
05:00:00 R 06:00:00 R 07:00:00 R 08:00:00 R 09:00:00 R 10:00:00 R 10:50:35 R 10:54:11 R 10:56:50 R 10:59:47 R 11:02:38 R 11:21:14 R 11:26:34 R 11:26:34 R 11:27:00 R
06:00:00 R 07:00:00 R 08:00:00 R 09:00:00 R 10:00:00 R 10:50:35 R 10:54:11 R 10:56:50 R 10:59:47 R 11:02:38 R 11:21:14 R 11:26:34 R 11:26:34 R 11:27:00 R
07:00:00 R 08:00:00 R 09:00:00 R 10:50:35 R 10:54:11 R 10:56:50 R 10:59:47 R 11:02:38 R 11:21:14 R 11:26:34 R 11:27:00 R
08:00:00 R 09:00:00 R 10:00:00 R 10:50:35 R 10:54:11 R 10:56:50 R 10:59:47 R 11:02:38 R 11:21:14 R 11:26:34 R 11:26:34 R 11:27:00 R
09:00:00 R 10:00:00 R 10:50:35 R 10:54:11 R 10:56:50 R 10:59:47 R 11:02:38 R 11:21:14 R 11:26:34 R 11:27:00 R
10:00:00 R 10:50:35 R 10:54:11 R 10:56:50 R 10:59:47 R 11:02:38 R 11:21:14 R 11:26:34 R 11:26:34 R 11:27:00 R
10:50:35 R 10:54:11 R 10:56:50 R 10:59:47 R 11:02:38 R 11:21:14 R 11:26:34 R 11:26:34 R 11:27:00 R
10:54:11 R 10:56:50 R 10:59:47 R 11:02:38 R 11:21:14 R 11:26:34 R 11:27:00 R
10:56:50 R 10:59:47 R 11:02:38 R 11:21:14 R 11:26:34 R 11:27:00 R
10:59:47 R 11:02:38 R 11:21:14 R 11:26:34 R 11:27:00 R
☐ 11:21:14 R ☐ 11:26:34 R ☐ 11:27:00 R
□ 11:26:34 R □ 11:27:00 R
11:27:00 R
🗌 11:32:37 R
□ 11:34:52 R
11:37:33 R
Start Time
16-06-23 00:00:00
End Time
16-06-23 00:34:00
Size(KB) 1064960

Figure 4-107

- Check a file name, double click file or click log to play.
- Input accurate time at the top column, you can search records of current day.
- System max displays 128 record files in one list.
- Click to go back to the calendar/channel selection interface.

### Lock or Unlock File

In Figure 4-107, select a file first and then click

# Note

NVR cannot lock a file when it is writing or overwriting.

# Click you can view the locked file. See Figure 4-108.

			FIL	E LOCKED	
3	СН	Tumo	Start Time	End Time	
	<u> </u>	Type R	2016-06-23 10:00:00	2016-06-23 10:33:44	Size(KB) 539136
	1	R	2016-06-23 10:50:35		
23	1	R	2016-06-23 10:56:50	2016-06-23 10:58:11	2048
		R	2010-00-23 10.30.30	2010-00-23 10.36.11	2040
					Unlock Cancel

Figure 4-108

Select a file in the above figure and then click Unlock, you can unlock it.

### 4.6.9 Other Aux Functions

4.6.9.1 Digital Zoom

In 1-window playback mode, left click mouse to select any zone on the screen, you can zoom in current zone. Right click mouse to exit.

4.6.9.2 Switch Channel

During playback mode, select from the dropdown list to switch playback channel. This function is not for the channel of no record. The smart search channel does not support this function either.

### 4.7 Event Manager

### 4.7.1 Video Detect

The video detect adopts the computer image and graphics process technology. It can analyze the video and check there is considerable changing degree or not. Once video has changed considerably (such as there is any moving object, video is distorted), system can trigger the corresponding alarm activation operations.

In the main menu, from Setting to Detect, you can see motion detect interface. See Figure 4-109.There are four detection types: motion detection, video loss, tampering and scene changing.

### 4.7.1.1 Motion Detect

After analysis video, system can generate a motion detect alarm when the detected moving signal reached the sensitivity you set here.

Detection menu is shown as below. See Figure 4-109.

- Event type: From the dropdown list you can select motion detection type.
- Channel: Select a channel from the dropdown list to set motion detect function.

- Enable: Check the box here to enable motion detect function.
- Region: Click select button, the interface is shown as in Figure 4-110. Here you can set motion detection zone. There are four zones for you to set. Please select a zone first and then left drag the mouse to select a zone. The corresponding color zone displays different detection zone. You can click Fn button to switch between the arm mode and disarm mode. In arm mode, you can click the direction buttons to move the green rectangle to set the motion detection zone. After you completed the setup, please click ENTER button to exit current setup. Do remember click save button to save current setup. If you click ESC button to exit the region setup interface system will not save your zone setup.
- Sensitivity: System supports 6 levels. The sixth level has the highest sensitivity.
- Anti-dither: Here you can set anti-dither time. The value ranges from 5 to 600s. The anti-dither time refers to the alarm signal lasts time. It can be seem as the alarm signal activation stays such as the buzzer, tour, PTZ activation, snapshot, channel record. The stay time here does not include the latch time. During the alarm process, the alarm signal can begin an anti-dither time if system detects the local alarm again. The screen prompt, alarm upload, email and etc will not be activated. For example, if you set the anti-dither time as 10 second, you can see the each activation may last 10s if the local alarm is activated. During the process, if system detects another local alarm signal at the fifth second, the buzzer, tour, PTZ activation, snapshot, record channel will begin another 10s while the screen prompt, alarm upload, email will not be activated again. After 10s, if system detects another alarm signal, it can generate an alarm since the anti-dither time is out.
- Period: Click set button, you can see an interface is shown as in Figure 4-112. Here you can set motion detect period. System only enables motion detect operation in the specified periods. It is not for video loss or the tampering. There are two ways for you to set periods. Please note system only supports 6 periods in one day.
- ♦ In Figure 4-112, Select icon of several dates, all checked items can be edited together. Now

the icon is shown as . Click to delete a record type from one period.

- ♦ In Figure 4-112. Click button after one date or a holiday, you can see an interface shown as in Figure 4-113. There are four record types: regular, motion detection (MD), Alarm, MD & alarm.
- Alarm output: when an alarm occurs, system enables peripheral alarm devices.
- Latch: when motion detection complete, system auto delays detecting for a specified time. The value ranges from 1-300(Unit: second)
- Show message: System can pop up a message to alarm you in the local host screen if you enabled this function.
- Alarm upload: System can upload the alarm signal to the network (including alarm center) if you • enabled current function.
- Send email: System can send out email to alert you when an alarm occurs.
- Record channel: System auto activates motion detection channel(s) to record once an alarm occurs. Please make sure you have set MD record in Schedule interface(Main Menu->Setting->Schedule) and schedule record in manual record interface(Main Menu->Advanced->Manual Record)
- PTZ activation: Here you can set PTZ movement when an alarm occurs. Such as go to preset, tour &pattern when there is an alarm. Click "select" button, you can see an interface is shown as in Figure 4-111.

- Record Delay: System can delay the record for specified time after alarm ended. The value ranges from 10s to 300s.
- Tour: Here you can enable tour function when alarm occurs. System one-window tour.
- Snapshot: You can enable this function to snapshot image when a motion detect alarm occurs.
- Video matrix Check the box here to enable this function. When an alarm occurs, SPOT OUT port displays device video output. It displays video (1-window tour) from alarm activation channel you select at the Record channel item.
- Buzzer: Highlight the icon to enable this function. The buzzer beeps when alarm occurs.

Please highlight icon use to select the corresponding function. After all the setups please click save button, system goes back to the previous menu.

### Note:

In motion detection mode, you cannot use copy/paste to set channel setup since the video in each channel may not be the same.

In Figure 4-110, you can left click mouse and then drag it to set a region for motion detection. Click Fn to switch between arm/withdraw motion detection. After setting, click enter button to exit.

		SETTING		
ST CAMERA	<b>T</b> NETWORK	📷 EVENT	STORAGE	SYSTEM
VIDEO DETEC SMART PLAN IVS FACE DETECTI	Motion Detect Via Channel Region	deo Loss Tamperi D1	ng Scene Chan nable 🗍	
PEOPLE COUN HEAT MAP VEHICLE REC AUDIO DETECT ALARM ABNORMALITY ALARM OUTPUT POS	Period Alarm Out Show Message Record Channel PTZ Activation Tour Snapshot Log Voice Prompts	Setup Alarm Upload Setup Setup Setup Setup	Anti-Dither (5 Latch (10 Send Email Post-Record (10	Sec.
	Default	Copy Copy	n) (OK) (	Cancel Apply

Figure 4-109





		PTZ Activation		
D1	None 🔽 1	D2	None 🕤 (1	
D3	None 🔻 1	D4	None 🔻 🕇	
D5	None 🔽 1	D6	None 🔻 🕇	
D7	None 🔻 1	D8	None 🔻 1	
D9	None 🔻 1	D10	None 🔻 🕇	
D11	None 🔻 1	D12	None 🔻 🕇	
D13	None 🔻 1	D14	None 🔻 1	
D15	None 🔻 1	D16	None 🕤 (1	
D17	(None ) 1	D18	None 🔻 🕤 🚺	
D19	(None ) 1	D20	None 🔻 🕤 (1	
D21	None	D22	None 🔻 🕄	
D23	None  (None	D24	None 🔍 (1	
			ок о	Consec
			UK (	Cancel







Time Period
Current Date: Sun
Period 1 00 : 00 - 24 : 00
Period 2 00 : 00 - 24 : 00
Period 3 00 : 00 - 24 : 00
Period 4 00 : 00 - 24 : 00
Period 5 00 : 00 - 24 : 00
Period 6 00 : 00 - 24 : 00
Copy
🗋 All 👘 Sun 🗋 Mon 🗋 Tue 🗋 Wed 🗍 Thu 🗍 Fri 🗋 Sat
Save

Figure 4-113

Motion detect here only has relationship with the sensitivity and region setup. It has no relationship with other setups.

### 4.7.1.2 Tampering

When someone viciously masks the lens, or the output video is in one-color due to the environments light change, the system can alert you to guarantee video continuity. Tampering interface is shown as in Figure 4-114. You can enable "Alarm output "or "Show message" function when tampering alarm occurs.

• Sensitivity: The value ranges from 1 to 6. It mainly concerns the brightness. The level 6 has the higher sensitivity than level 1. The default setup is 3.

#### Tips:

You can enable preset/tour/pattern activation operation when video loss occurs.

Please refer to chapter 4.7.1.1 motion detection for detailed information.

# D Note

- In Detect interface, copy/paste function is only valid for the same type, which means you cannot copy a channel setup in video loss mode to tampering mode.
- About Default function. Since detection channel and detection type may not be the same, system can only restore default setup of current detect type. For example, if you click Default button at the tampering interface, you can only restore default tampering setup. It is null for other detect types.
- System only enables tampering function during the period you set here. It is null for motion detect or video loss type.

	SETTING
R CAMERA	TRACE SYSTEM
VIDEO DETEC SMART PLAN IVS FACE DETECTI PEOPLE COUN HEAT MAP AUDIO DETECT ALARM ABNORMALITY ALARM OUT	Motion Detect       Video Loss       Tampering       Scene Chan         Channel       D1       Enable       Image: Channel         Period       Set       Alarm Out       1       2       Latch       10       s         Alarm Out       1       2       Latch       10       s       s       Show Message       Alarm Upload       Send Email         Record Channel       D1       D2       D3       D4       D5       D6       D7       D8         PTZ Activation       Set       Post Record       10       s       Tour       D1       D2       D3       D4       D5       D6       D7       D8       Snapshot       D1       D2       D3       D4       D5       D6       D7       D8       Snapshot       D1       D2       D3       D4       D5       D6       D7       D8       Sender       Sender

Figure 4-114

### 4.7.1.3 Video Loss

After connected the system to the remote device, system can generate an alarm once the remote device has lost the video. System can trigger the corresponding alarm operations.

In Figure 4-109, select video loss from the type list. You can see the interface is shown as in Figure 4-115. This function allows you to be informed when video loss phenomenon occurred. You can enable alarm output channel and then enable show message function.

You can refer to chapter 4.7.1.1 Motion detect for detailed information.

### Tips:

You can enable preset/tour/pattern activation operation when video loss occurs.

CAMERA 👘 NETWORK 🙀 EVENT 🍕 SYSTEM
VDEO DETEC       Motion Detect Video Loss Tampering Scene Change         SMART PLAN       NS         IVS       Channel       D2         FACE DETECTI       Period       Setup         PEOPLE COUN       Period       Setup         VEHICLE REC       Other Message       Alarm Upload       Send Email         AUDIO DETECT       Record Channel       Setup       Delay 10       Sec.         ALARM       PTZ Activation       Setup       Other Setup       Delay 10       Sec.         ALARM OUTPUT       Snapshot       Setup       Setup       Delay 10       Sec.         Voice Prompts       File Name None       Buzzer       Buzzer       Default       Copy       Refresh       OK       Cancel       Apply

Figure 4-115

4.7.1.4 Scene Changing

When the detected scene has changed, system can generate an alarm.

From main menu->Setting->Event->Video detect->Scene change, the interface is shown as in Figure 4-116.

Please refer to chapter 4.7.1.1 Motion detect for detailed information.

	_	SETTING		
SAMERA	<b>T</b> NETWORK	📷 EVENT	STORAGE	SYSTEM
CAMERA VIDEO DETEC SMART PLAN IVS FACE DETECTI PEOPLE COUN HEAT MAP VEHICLE REC AUDIO DETECT ALARM ABNORMALITY ALARM OUTPUT		deo Loss Tamperin D2 T En Setup 1 2 3 4 ( Alarm Upload		Sec.
	Default	Refresh	OK (	Cancel Apply

Figure 4-116

### 4.7.2 Smart Plan

The smart plan is for the smart network camera. If you do not set a rule here, you cannot use the intelligent functions in IVS (Chapter 4.7.3), Face detection (Chapter 4.7.4) and People counting (Chapter 4.7.5) when you are connecting to a smart network camera.

There are two types to realize intelligent analytics function.

# Note

- Smart network camera supports intelligent functions: Some smart camera supports the intelligent functions. For NVR, it just displays the intelligent alarm information from the smart network camera and set or playback the record file.
- NVR supports intelligent functions: The connected network camera does not support intelligent video analytics function. The NVR supports the analytics function.

In this interface, you can quickly add an intelligent rule for one preset. The intelligent rule includes human face detection, behavior analytics and people counting.

From main menu->Setting->Event->Smart plan, the interface is shown as below. See Figure 4-117.

		SETTING		
😋 CAMERA		📷 EVENT	STORAGE	SYSTEM
VIDEO DETEC SMART PLAN	Channel D11			
IVS FACE DETECTI PEOPLE COUN HEAT MAP VEHICLE REC AUDIO DETECT ALARM ABNORMALITY ALARM OUTPUT				
	Refresh		ОК	Cancel Apply

Figure 4-117

Please select a channel number and a preset. Click Add. The preset is now on the list. See Figure 4-118.

# D Note

Some smart camera does not need to add the preset. Please refer to the actual product for detailed information.



Figure 4-118

Select a smart plant from the dropdown list and then click the corresponding intelligent plan icon. See Figure 4-118.

III Note

- The NVR supports general behavior analytics (IVS), human face detection, heat map, and people counting. Different network camera supports different smart plans. Please refer to the actual product for detailed information.
- The general behavior analytics (IVS) and human face detection function cannot be valid at the same time. For example, when add the IVS plan to the preset 1, the human face detection icon becomes grey.

Click OK to complete the setup.

### 4.7.3 IVS (General Behavior Analytics) (Optional)

The general behavior analysis refers to the system to analyze and process the video and extract the key information from the video. Once the video can match the previously set detection rule, system can trigger the corresponding alarm operations.



- This function is for some series product only. Please refer to the actual product for detailed information.
- The IVS function and the human face detection function cannot be valid at the same time.

The IVS function environment shall meet the following requirements:

- The object total size shall not be more than 10% of the whole video.
- The object size on the video shall not be more than 10pixels\*10 pixels. The abandoned object size shall be more than 15pixels\*15 pixels (CIF resolution). The object width shall not be more than 1/3 of the video height and width. The recommended height is 10% of the video.
- The object and the background brightness different shall be more than 10 grey levels.
- The object shall remain on the video for more than 2 seconds. The moving distance is larger than its own width and shall not be smaller than 15pixels (CIF resolution).
- The surveillance environment shall not be too complicated. The IVS function is not suitable for the environment of too many objects or the changing light.
- The surveillance environment shall not contain glasses, reflection light from the ground, and water. Free of tree branches, shadow, mosquito and bugs. Do not use the IVS function in the backlight environment, avoid direct sunlight.

From main menu->Setting->Event->Behavior Analytics, you can go to the behavior analytics interface. Here you can set general behavior analytics rule. System can generate an alarm as the mode you previously set once there is any object violates the rule. See Figure 4-119.

		SETTIN	G	)					
	<b>TWORK</b>	🔂 EVENT	S 🛃	TOF	RAGE		SYSTEM	Л	
VIDEO DETEC SMART PLAN IVS	Channel (D8								
FACE DETECTI	10 Enable	Name	Туре		Preset	Draw	Trigger		
PEOPLE COUN		line1	Tripwire			<ul> <li>/</li> </ul>	Ö	×	
HEAT MAP	2	line2 line3	Tripwire	-			Ö	×	
VEHICLE REC	4	line3	Tripwire Tripwire	• •		//	000000000000000000000000000000000000000	× × × × × × × × ×	
	5	area1	Intrusion			/	2	$\hat{\mathbf{v}}$	
AUDIO DETECT	6	object1	Aband			/	×	x	
ALARM	7	FastMoving1	Fast-M			1	ŏ	×	
		ParkingDete	Parking			1	ö	×	
ABNORMALITY	8 🗌 9	PeopleGath	Crowd			1	ö	×	
ALARM OUTPUT	10 🗌	LoiteringDet	Loiteri			1	٠	×	
	(Global Config)	Refresh		A	.dd (	Canc	el ) (_	Apply	

Figure 4-119

Select a channel from the dropdown list.

Click Add button to add a rule and then select a rule type from the dropdown list.

Set corresponding parameters.

Click Apply button to complete the setup.

4.7.3.1 Tripwire (Optional)

System generates an alarm once there is any object crossing the tripwire in the specified direction.

- The tripwire supports customized setup. It can be a straight line or a curve.
- Support one-direction or dual-direction detection.

- Support several tripwires at the same scene suitable for complicated environment.
- Support object size filter.

From main menu->Setting->Event->Behavior analytics, the interface is shown as below. See Figure 4-120.

	(	SETTIN	G					
		📷 EVENT	S.	TORAGE	5	SYSTEM	1	
VIDEO DETEC SMART PLAN IVS	Channel (D8			_				
FACE DETECTI PEOPLE COUN HEAT MAP VEHICLE REC AUDIO DETECT ALARM ABNORMALITY ALARM OUTPUT	10         Enable           1         2           3         4           5         6           7         8           9         1           10         1	<ul> <li>Name</li> <li>line1</li> <li>line2</li> <li>line3</li> <li>line4</li> <li>area1</li> <li>object1</li> <li>FastMoving1</li> <li>ParkingDete</li> <li>PeopleGath</li> <li>LoiteringDet</li> </ul>	Type Tripwire Tripwire Tripwire Intrusion Aband Fast-M Parking Crowd Loiteri	Preset	Draw / / / / / / / / / / / / / / / / / / /	Trigger O O O O O O O O O	Delete  X X X X X X X X X X X X X X X X X X	
	<ul> <li>Global Config) (</li> </ul>	Refresh_)	(	Add	Canc	el) (	Apply	

Figure 4-120

Click Draw button *L* to draw the tripwire. See Figure 4-121.



Figure 4-121

Select direction, and then input customized rule name.

- Preset: Select a preset you want to use behavior analytics.
- Name: Input customized rule name.
- Direction (A→B/B→A/A↔B): System can generate an alarm once there is any object crossing in the specified direction.
- Target filter: Click , you can set filter object size. Each rule can set two sizes (min size/max size).

Once the object is smaller than the min size or larger than the max size, there is no alarm. Please make sure the max size is larger than the min size.

Now you can draw a rule. Left click mouse to draw a tripwire. The tripwire can be a direct line, curve or polygon. Right click mouse to complete.

Tips

Click K to delete the corresponding rule.

Click Click

You can refer to the following information to set other parameters.

- Channel: Select a channel from the dropdown list to set tripwire function.
- Enable: Check the box here to enable tripwire function.
- Rule: input customized rule name here.
- Period: Click set button, you can see an interface is shown as in Figure 4-112. Here you can set tripwire period. System only enables tripwire operation in the specified periods. There are two ways for you to set periods. Please note system only supports 6 periods in one day.

♦ In Figure 4-112, Select icon of several dates, all checked items can be edited together.

Now the icon is shown as . Click to delete a record type from one period.

- ♦ In Figure 4-112. Click button after one date or a holiday, you can see an interface shown as in Figure 4-113.
- Alarm output: when an alarm occurs, system enables peripheral alarm devices.
- Latch: when tripwire complete, system auto delays detecting for a specified time. The value ranges from 1-300(Unit: second)
- Show message: System can pop up a message to alarm you in the local host screen if you enabled this function.
- Alarm upload: System can upload the alarm signal to the network (including alarm center) if you enabled current function.
- Send email: System can send out email to alert you when an alarm occurs.
- Record channel: System auto activates tripwire channel(s) to record once an alarm occurs. Please
  make sure you have set intelligent record in Schedule interface(Main Menu->Setting->Schedule)
  and schedule record in manual record interface(Main Menu->Advanced->Manual Record)
- PTZ activation: Here you can set PTZ movement when an alarm occurs. Such as go to preset, tour &pattern when there is an alarm. Click "select" button, you can see an interface is shown as in Figure 4-111.
- Record Delay: System can delay the record for specified time after alarm ended. The value ranges from 10s to 300s.
- Tour: Here you can enable tour function when an alarm occurs. System one-window tour.
- Snapshot: You can enable this function to snapshot image when a motion detect alarm occurs.
- Buzzer: Highlight the icon to enable this function. The buzzer beeps when an alarm occurs.

		Ingger			
Period	Setup				
Alarm Out	123456	Latch (10	)Sec.		
	Alarm Upload	Send Email			
Record Channel	Setup	Delay (10	)Sec.		
PTZ Activation	Setup				
Tour	Setup				
Snapshot	Setup				
✓Log					
Voice Prompts	File Name None	$\mathbb{D}$			
Buzzer					
Default				ОК	Cancel

Figure 4-122

		PTZ Activation		
D1	None 7			None 🔽 1
D3	None 🔽 1		D4	None 🔽 1
D5	None 7		D6	None 🔻 1
D7	None 7		D8 (	None 🔻 1
D9	None 🔻 1		D10	None 🔻 1
D11	None 🔻 1		D12	None 🔻 1
D13	None 🔻 1		D14	None 🔻 1
D15	None 🔻 1		D16	None 🔻 1
D17	None 7		D18	None 🔻 1
D19	None 7		D20	None 🔻 1
D21	None 7		D22	None 🔻 1
D23	None 🔻 1		D24	None 🔻 1
				OK Cancel
				Cancer

Figure 4-123

Figure 4-124

Time Period
Current Date: Sun
Period 1 (00 : 00 - 24 : 00)
Period 2 00 :00 - 24 : 00
Period 3 (00 : 00 - 24 : 00 )
Period 4 (00 : 00 - 24 : 00 )
Period 5 00 : 00 - 24 : 00
Period 6 (00 : 00 - 24 : 00)
Copy
🗌 All 👘 Sun 🗋 Mon 🗋 Tue 🗋 Wed 🗍 Thu 🗍 Fri 🗍 Sat
Save

Figure 4-125

After you set the corresponding parameters, click OK button in Figure 4-122., and then click the Apply button in Figure 4-120 to complete the setup.

4.7.3.2 Intrusion (Cross warning zone) (Optional)

System generates an alarm once there is any object entering or exiting the zone in the specified direction. From main menu->Setting->Event->Behavior analytics, click Add button and then select type as intrusion, the interface is shown as below. See Figure 4-126.

- System supports customized area shape and amount.
- Support enter/leave/both detection.
- Can detect the moving object operation in the specified zone, customized trigger amount and staying time.
- Support objects filter function.

		SETTIN	G				
	TWORK 📷	Devent	ST	ORAGE		SYSTE	VI
VIDEO DETEC SMART PLAN IVS	Channel (D8	〕 〕					
FACE DETECTI	10 Ena	ble Name	Түре	Preset	Draw	Trigger	Delete
PEOPLE COUN		line1	Tripwire	<ul><li>▼</li></ul>	/	<u> </u>	×
HEAT MAP	2	line2	Tripwire		/	Ö	×
	3   4 5   6 7   7 8   9 10	line3	Tripwire	<b>*</b> -	/	Ö	×
VEHICLE REC		line4	Tripwire		/	Ö	×
AUDIO DETECT	5	area1	Intrusion		/	Ö	×
ALARM	6	object1 FastMoving1	Aband Fast-M		1	<u>.</u>	× × × × ×
	8	ParkingDete	Parking		1	<u></u>	$\hat{\mathbf{v}}$
ABNORMALITY	9	PeopleGath	Crowd		1	ž	x
ALARM OUTPUT	10	LoiteringDet	Loiteri		1	0000000	×
							•
	(Global Config)	Refresh	C	Add (	Canc	el) (	Apply )

Figure 4-126

Click draw button **I** to draw the zone. See Figure 4-127.



Figure 4-127

Select direction, and then input customized rule name.

- Preset: Select a preset you want to use behavior analytics.
- Name: Input customized rule name.
- Direction (A→B/B→A/A↔B): System can generate an alarm once there is any object crossing in the specified direction.
- Target filter: Click , you can set filter object size. Each rule can set two sizes (min size/max size).

Once the object is smaller than the min size or larger than the max size, there is no alarm. Please make sure the max size is larger than the min size.

Now you can draw a rule. Left click mouse to draw a warning zone. Right click mouse to complete the setup.

#### Tips

Click to delete the corresponding rule.

Click (you can refer to chapter 4.7.3.1 to set other parameters.

Click Apply to complete the setup.

#### 4.7.3.3 Abandoned Object Detect (Optional)

System generates an alarm when there is abandoned object in the specified zone.

From main menu->Setting->Event->Behavior analytics, select the type as abandoned object, the object interface is shown as below. See Figure 4-128.

- System supports customized area shape and amount.
- Support duration setup.
- Support objects filter function.

		SETTIN	G					
		EVENT	S.	TORAGE		SYSTEM	Л	
VIDEO DETEC SMART PLAN IVS	Channel (D8							
FACE DETECTI PEOPLE COUN HEAT MAP VEHICLE REC AUDIO DETECT ALARM ABNORMALITY ALARM OUTPUT	10     Enable       1     2       3     4       5     6       7     8       9     10	Name line1 line2 line3 line4 area1 object1 FastMoving1 ParkingDete PeopleGath LoiteringDet	Type Tripwire Tripwire Tripwire Intrusion Aband Fast-M Parking Crowd Loiteri	Prese	t Draw	Trigger O O O O O O O O O O	Delete  X X X X X X X X X X X X X X X X X X	
	(Global Config)	Refresh	(	Add	) (Canc	el ) (	Apply )	

Figure 4-128

Click draw button *L* to draw the zone. See Figure 4-129.



Figure 4-129

- Preset: Select a preset you want to use behavior analytics.
- Name: Input customized rule name.
- Duration: System can generate an alarm once the object is in the zone for the specified period.
- Target filter: Click , you can set filter object size. Each rule can set two sizes (min size/max size).

Once the object is smaller than the min size or larger than the max size, there is no alarm. Please make sure the max size is larger than the min size.

Now you can draw a rule. Left click mouse to draw a zone, until you draw a rectangle, you can right click mouse.

#### Tips

Click K to delete the corresponding rule.

Click (), you can refer to the chapter 4.7.3.1 to set other parameters.

Click Apply to complete the setup.

#### 4.7.3.4 Missing Object Detection (Optional)

System generates an alarm when there is missing object in the specified zone.

From main menu->Setting->Event->Behavior analytics, select the type as abandoned object, the object interface is shown as below. See Figure 4-130.

- System supports customized area shape and amount.
- Support duration setup.
- Support objects filter function.

	SETTING
	👘 NETWORK 🛛 👼 EVENT 🛛 💁 SYSTEM
VIDEO DETEC SMART PLAN IVS	Channel D8
FACE DETECTI	10 🗌 Enable Name Type Preset Draw Trigger Delete
PEOPLE COUN	1 line1 Tripwire 🔻 - 🦯 🔅 🗙
HEAT MAP	2 line2 Tripwire ▼ - ✓ ☆ × 3 line3 Tripwire ▼ - ✓ ☆ ×
VEHICLE REC	4       line4       Tripwire       -       / 🔅       ×         5       area1       Intrusion       -       / 🔅       ×         6       object1       Aband       -       / 🔅       ×         7       FastMoving1       Fast-M       -       / 🔅       ×         8       ParkingDete       Parking       -       / 🔅       ×         9       PeopleGath       Crowd       -       / 🔅       ×         10       LoiteringDet       Loiteri       -       / 🔅       ×
AUDIO DETECT	6 object1 Aband / 👸 🗙
ALARM	6object1 Aband ▼ - ✓ ở × 7FastMoving1 Fast-M ▼ - ✓ ở ×
ABNORMALITY	8 ParkingDete Parking / 🔅 × 9 PeopleGath Crowd / 😋 ×
	9 PeopleGath Crowd ▼ - ✓ ☆ × 10 LoiteringDet Loiteri ▼ - ✓ ☆ ×
ALARM OUTPUT	10 🗌 LoiteringDet Loiteri 🔻 - 🧪 🔅 🗙
	Global Config) Refresh Add Cancel Apply

Figure 4-130

Click Draw button *logical to draw a zone.* See Figure 4-131.


- Preset: Select a preset you want to use behavior analytics.
- Name: Input customized rule name.
- Duration: System can generate an alarm once the object in the zone is missing for the specified period.
- Target filter: Click , you can set filter object size. Each rule can set two sizes (min size/max size).

Once the object is smaller than the min size or larger than the max size, there is no alarm. Please make sure the max size is larger than the min size.

Now you can draw a rule. Left click mouse to draw a zone, until you draw a rectangle, you can right click mouse.

### Tips

Click kollete the corresponding rule.

Click (2014), you can refer to the chapter 4.7.3.1 to set other parameters.

Click Apply to complete the setup.

#### 4.7.3.5 Loitering Detection (Optional)

System can generate an alarm once the object is staying in the specified zone longer than the threshold. From main menu->Setting->Event->Behavior analytics, select the type as loitering, the object interface is shown as below. See Figure 4-132.

- System supports customized area shape and amount.
- Support duration setup.
- Support objects filter function.



Figure 4-132

Click draw button *L* to draw the zone. See Figure 4-133.



Figure 4-133

- Preset: Select a preset you want to use behavior analytics.
- Name: Input customized rule name.
- Duration: System can generate an alarm once the object is in the zone for the specified period.
- Target filter: Click , you can set filter object size. Each rule can set two sizes (min size/max size).

Once the object is smaller than the min size or larger than the max size, there is no alarm. Please make sure the max size is larger than the min size.

Now you can draw a rule. Left click mouse to draw a zone, until you draw a rectangle, you can right click mouse.

### Tips

Click to delete the corresponding rule.

Click (), you can refer to the chapter 4.7.3.1 to set other parameters.

Click Apply to complete the setup.

#### 4.7.3.6 Crowd Gathering Detection (Optional)

System can generate an alarm once the people amount gathering in the specified zone is larger than the threshold.

From main menu->Setting->Event->Behavior analytics, select the type as crowd gathering detect, the interface is shown as below. See Figure 4-134.

- Customized zone and amount setup.
- Duration setup.
- Sensitivity setup.
- Min gathering zone setup.

		SETTING					
SAMERA		EVENT	STOR	AGE	S`	YSTEM	
VIDEO DETEC SMART PLAN IVS	Channel (D8	Ð					
FACE DETECTI PEOPLE COUN HEAT MAP VEHICLE REC AUDIO DETECT ALARM ABNORMALITY ALARM OUTPUT	8 Pa 9 Pe	line2 T line3 T area1 In object1 A astMoving1 F irkingDete P eopleGath C	Type ripwire • ripwire • ripwire • htrusion • band • fast-M • fast-M • fast-M • fast-M • fast-M • fast-M •	Preset [ - - - - - - - - - - - - -	Draw Ti // // // // //		Delete × × × × × × × × × × × × × ×
	(Global Config) (Refr			id (	Cancel		vpply

Figure 4-134

Click draw button *local* to draw the zone. See Figure 4-135.



Figure 4-135

- Preset: Select a preset you want to use behavior analytics.
- Name: Input customized rule name.
- Duration: System can generate an alarm once the object is in the zone for the specified period.
- Sensitivity: It is to set alarm sensitivity. The value ranges from 1 to 10. The default setup is 5.
- Target filter: Click , you can set filter object size. Each rule can set two sizes (min size/max size).

Once the object is smaller than the min size or larger than the max size, there is no alarm. Please make sure the max size is larger than the min size.

Now you can draw a rule. Left click mouse to draw a zone, until you draw a rectangle, you can right click mouse.

### Tips

Click K to delete the corresponding rule.

Click 🔯, you can refer to the chapter 4.7.3.1 to set other parameters.

Click Apply to complete the setup.

### 4.7.3.7 Fast moving (Optional)

It is to detect the fast moving object in the specified zone.

From main menu->Setting->Event->Behavior analytics, select the type as fast moving, the interface is shown as below. See Figure 4-136.

		SETTIN	G				
CAMERA	TWORK 📷	Devent	ST	ORAGE		SYSTE	VI
VIDEO DETEC SMART PLAN IVS	Channel (D8						
FACE DETECTI	10 Ena	ble Name	Түре	Preset	Draw	Trigger	Delete
PEOPLE COUN		line1	Tripwire	<ul><li>▼</li></ul>	/	<u> </u>	×
HEAT MAP	2	line2	Tripwire		/	Ö	×
	3   4 5   6 7   7 8   9 10	line3	Tripwire	<b>*</b> -	/	Ö	×
VEHICLE REC		line4	Tripwire		/	Ö	×
AUDIO DETECT	5	area1	Intrusion		/	Ö	×
ALARM	6	object1 FastMoving1	Aband Fast-M		1	<u>.</u>	× × × × ×
	8	ParkingDete	Parking		1	<u></u>	$\hat{\mathbf{v}}$
ABNORMALITY	9	PeopleGath	Crowd		1	ž	x
ALARM OUTPUT	10	LoiteringDet	Loiteri		1	0000000	×
							•
	(Global Config)	Refresh	C	Add (	Canc	el) (	Apply )

Figure 4-136

Click draw button **I** to draw the zone. See Figure 4-137.



Figure 4-137

- Preset: Select a preset you want to use behavior analytics.
- Name: Input customized rule name.
- Sensitivity: It is to set alarm sensitivity. The value ranges from 1 to 10. The default setup is 5.
- Target filter: Click , you can set filter object size. Each rule can set two sizes (min size/max size).

Once the object is smaller than the min size or larger than the max size, there is no alarm. Please make sure the max size is larger than the min size.

Now you can draw a rule. Left click mouse to draw a zone, until you draw a rectangle, you can right click mouse.

#### Tips

Click K to delete the corresponding rule.

Click (), you can refer to the chapter 4.7.3.1 to set other parameters.

Click Apply to complete the setup.

### 4.7.3.8 Global Setup (Optional)

After set one horizontal gauge and three vertical gauge and the actual distances between each gauge, the system can estimate the network camera internal parameters(internal geometrical features and optical properties) and external parameters (the network camera position and direction on the actual environment), it can confirm the actual distance on the current surveillance environment.

From main menu->Setting->Event->IVS (Behavior analytics), enter the following interface. See Figure

		SETTIN	G				
SAMERA	<b>TWORK</b>	Devent	s 🛃	TORAG	e 🏼 🌉	SYSTE	Л
VIDEO DETEC SMART PLAN	Channel (D8						
FACE DETECTI	10 Enable		Туре		eset Draw	Trigger	
PEOPLE COUN		line1	Tripwire		- 🧹	0	×
HEAT MAP		line2 line3	Tripwire Tripwire	-	- 🧹	<u>0</u>	×
	4	line3	Tripwire	<b>*</b>	- /	õ	× ×
VEHICLE REC	5	area1	Intrusion	• •	- /	0000000	$\hat{\mathbf{Q}}$
AUDIO DETECT	6	object1	Aband			×	× × × × × ×
ALARM		FastMoving1	Fast-M		- / - / - /	ă	×
	8	ParkingDete	Parking		- 🧳	õ	×
ABNORMALITY	7    8    9    10	PeopleGath	Crowd		- 🧹	ö	×
ALARM OUTPUT	10	LoiteringDet	Loiteri		- /	ö	×
							<b>\</b>
	(Global Config)	Refresh )	C	Add	Canc	el) (	Apply )



Click Global config button, the interface is shown as below. See Figure 4-139.

- Channel: Please select a channel from the dropdown list.
- Preset: Select a preset you want to set the rule. Please note, you need to add a preset first, otherwise, you cannot see the preset dropdown list. If there is no preset, you can draw a rule in current channel.
- Calibration zone:
- ♦ Click Add zone , you can draw a calibration zone at the left pane of the interface. Select a zone and then click Delete zone button; you can remove the selected zone.
- Select gauge type (horizontal/tilt), you can set the corresponding length. You can draw three tilt gauges and one horizontal gauge at the left pane of the interface.
- Select Width/Height and then click Verify, you can draw a line in the calibration zone, and then you can see its actual length.
- Refresh preset: Click it to get the latest preset setup.



Figure 4-139

### 4.7.4 Face Detect (Optional)

System processes and analyzes the video from the camera. System can generate an alarm when it detects there is any human face information.

From main menu->Setting->Event->Face detect, the interface is shown as in Figure 4-140.

• Face ROI: Check the box here, system can enhance the human face display pane.

## Note

Make sure the connected camera supports human face detect function if you want to use face ROI function.

• Log: Check the box here, system can record face detect log.

You can refer to the chapter 4.7.1.1 Motion detect to set other parameters.

		SETTING		
😽 CAMERA		Tage EVENT	STORAGE	SYSTEM
VIDEO DETEC SMART PLAN IVS FACE DETECTI PEOPLE COUN HEAT MAP VEHICLE REC AUDIO DETECT ALARM ABNORMALITY ALARM OUTPUT	Channel Face ROI Setup Period Alarm Out Record Channel PTZ Activation Tour Snapshot Voice Prompts Buzzer	RULE Setup 1234 Alarm Upload	nable	Sec. nail Sec.
	Default Ref	resh	ОК	Cancel Apply

Figure 4-140

### 4.7.5 People Counting (Optional)

System adopts video image and graphics analysis technology. System can calculate the entry/exit people amount in the specified zone on the video. It can generate an alarm when the amount has exceeded the threshold.

From main menu->Setting->Event->People counting, you can see an interface shown as in Figure 4-141.

- Enable: Check the box to enable people counting function.
- OSD overlay: Check the box here; you can view the people amount on the surveillance video.
- Rule setup: Click Set button, you can set people counting zone, name, and direction (entry/exit).
- Entry No.: It is to set people entry amount. System can generate an alarm once the amount has exceeded the threshold.
- Exit No.: It is to set people exit amount. System can generate an alarm once the amount has exceeded the threshold.
- Remaining No.: It is to set people staying amount in the zone. System can generate an alarm once the amount has exceeded the threshold.

You can refer to the chapter 4.7.1.1 motion detect to set other parameters. Click OK to complete the setup.

	(	SETTING		
		DEVENT		SYSTEM
VIDEO DETEC SMART PLAN IVS FACE DETECTI PEOPLE COUN HEAT MAP	Channel Setup OSD Overlay People Counting	RULE	ave No. (0) Strande	ed No. (0
VEHICLE REC AUDIO DETECT ALARM ABNORMALITY ALARM OUTPUT To Sn Vo	Period Alarm Out Record Channel PTZ Activation Tour Snapshot Voice Prompts Buzzer	Setup 1 2 3 4 Alarm Upload Setup Setup Setup Setup File Name (None	56 Latch 0 Send En Delay (10	Sec. nail Sec.
	(Default) (Refi	resh	OK	Cancel Apply

Figure 4-141

After you set the people counting function, from main menu->Info->Event->People counting, you can view people counting statistics report. Please refer to chapter 4.7.1.1 Motion detect for detailed information.

### 4.7.6 Heat Map

Heat map technology can monitor the active objects distribution status on the specified zone during a period of time, and use the different colors to display on the heat map.

Step 1 From main menu->Setting->Event->Heat map. Enter heat map interface. See Figure 4-142.

	_	SETTING		
SAMERA		📷 EVENT	STORAGE	SYSTEM
VIDEO DETEC SMART PLAN	Channel	D2 Er	able	
IVS FACE DETECTI PEOPLE COUN HEAT MAP VEHICLE REC AUDIO DETECT ALARM ABNORMALITY ALARM OUTPUT	Period	Setup		
	(Default) (Ref	resh	OK (	Cancel Apply

Figure 4-142

- Step 2 Select a channel number and then check the box to enable the function.
- Step 3 Click Setup button.

Enter setup interface. See Figure 4-143.





Step 4 Set arm/disarm period. Refer to chapter 4.7.1.1 Motion detect for detailed setup information.

Step 5 Click Apply button to complete setup.

Note

After set the heat map parameters, go to main menu->Info->Event->Heat map to view heat map report. Refer to chapter 4.10.2.3.3 for detailed setup information.

### 4.7.7 Plate Recognition

4.7.7.1 Plate recognition settings

Device can generate an alarm when it detects the corresponding plate information.

Please follow the steps listed below.

Step 1 From main menu->Setup->Event->Vehicle Recognition-> Vehicle Recognition. Enter Vehicle Recognition interface. See Figure 4-144.

		SETTING		
CAMERA	<b>NETWORK</b>	DEVENT	STORAGE	SYSTEM
VIDEO DETEC SMART PLAN	VEHICLE RE B	/W List		
IVS	Channel	(D2 ) Er	nable 🗌	
FACE DETECTI	Setup	RULE		
PEOPLE COUN				
HEAT MAP	Regular	Blacklist Whi	telist	
VEHICLE REC	Period	Setup		
AUDIO DETECT	Alarm Out	1234	56 Latch (10	Sec.
ALARM		Alarm Upload	Send Em	ail
ABNORMALITY	Record Channel	Setup	Delay (10	Sec.
ALARM OUTPUT	PTZ Activation	Setup		
	Tour	Setup		
	Snapshot	Setup		
	✓Log			
	☐Voice Prompts	File Name (None		
	Buzzer			
	Default	Refresh	ОКС	Cancel Apply

#### Figure 4-144

- Step 2 Check Enable to enable plate recognition function.
- Step 3 Select a channel number and then click the Rule to set the plate recognition name and detection zone.
- Step 4 Click Regular, blacklist, whitelist to set.

### III Note

Before use blacklist alarm or whitelist alarm function, please add the corresponding plate information. Refer to chapter 4.7.7.2 B/W list for detailed information.

• Regular: In this interface, device triggers an alarm when it detects all plate numbers.

• Blacklist: In this interface, device triggers an alarm when it detects plate number in the blacklist.

 Whitelist: In this interface, device triggers an alarm when it detects plate number in the whitelist.

### 4.7.7.2 B/W List

It is to set the blacklist and the whitelist. It includes add, delete, import, export blacklist/whitelist.

After setting the blacklist/whitelist, in the plate snapshot list on the preview interface, the blacklist plate number is red, the whitelist plate number is green, the regular plate number is white.

### Add blacklist/whitelist

Step 1 From main menu->Setting->Event->Vehicle Recognition->B/W list. Enter B/W list interface. See Figure 4-145.

	_	SETTING		
SAMERA	TWORK 📷	Devent	STORAGE	E 🛃 SYSTEM
VIDEO DETEC SMART PLAN IVS FACE DETECTI		B/W List		pe (Whitelist ) Add Search
PEOPLE COUN HEAT MAP VEHICLE REC AUDIO DETECT ALARM ABNORMALITY ALARM OUTPUT		cense *		Del
		Export	1/1 🕨	Go To 1 Page(s) Delete Clear

Figure 4-145

Step 2 Set plate number and then select type as blacklist or whitelist.

Step 3 Click Add button.

#### Delete blacklist/whitelist

Set type as blacklist, whitelist or all, click Search button, device displays the corresponding information.

- Check the box before the plate number and then click Delete or 🔀 to delete a plate number.
- Click Clear to delete all plate information in the blacklist/whitelist.

#### Import/export blacklist/whitelist

Device supports blacklist/whitelist import/export function via the USB device. The import file supports .csv

and xlsx. The export file is .csv.

- Import blacklist/whitelist: Set the type as blacklist or whitelist and then click Import button. Select the corresponding file and then click Open button to import.
- Export blacklist/whitelist: Set the type as blacklist or whitelist and then click Export button. The Browse interface is displayed. See Figure 4-146. Select the file save path, enter the encryption password, and then click Save.

	_	Browse			_	
Device Name Total Space	(sda1(USB DISK)) • (7.53 GB	Refresh Free Space (2.1	17 GB			
Address	(/NVR/PlateList/					$\supset$
Name			Size	Type Folder	Del	
🖌 File Backu	p Encryption Set Passw	vord				
It is 6 to 32-digi	t containing letter(s), nu	mber(s), symbol(s). It con	tains at least tw	o types.		
				ОК	Cance	

Figure 4-146

### 

Backup encryption is enabled by default when exporting the black/white list.

- If file backup encryption is enabled, the extension name of the exported file is .backup.
- If the backup encryption is disabled, the extension name of the exported file is .csv. It might lead to data leakage.

### 4.7.8 Audio Detect (Optional)

System can generate an alarm once it detect the audio is not clear, the tone color has changed or the is abnormal or audio volume changes.

From main menu->Setting->Event->Audio detect, you can see an interface shown as in Figure 4-147.

- Input abnormal: Check the box here, system can generate an alarm once the audio input is abnormal.
- Intensity change: Check the box here, system can generate an alarm once the audio volume becomes strong.
- Sensitivity: It refers to the audio recognition sensitivity. The higher the value is, the higher the sensitivity is.

- Threshold: It is to set intensity change threshold. The smaller the value is, the higher the sensitivity is.
- Log: Check the box here, system can record audio detect alarm log.

Refer to the chapter 4.7.1.1 Motion Detect to set other parameters.

		SETTING		
😋 CAMERA		Devent	STORAGE	SYSTEM
VIDEO DETEC SMART PLAN IVS FACE DETECTI PEOPLE COUN HEAT MAP VEHICLE REC AUDIO DETECT ALARM ABNORMALITY ALARM OUTPUT	Channel Sensitivity Threshold Period Alarm Out Record Channel PTZ Activation Tour Snapshot Voice Prompts Buzzer	D2 In Setup 1 2 3 4 Alarm Upload Setup Setup Setup Setup	put Abnormal Intensity C 1 (1 - 100) 1 (1 - 100) 5 6 Latch 10 Send Email Delay 10	Change
	Default Ref	resh	OK Ca	ancel Apply

Figure 4-147

### 4.7.9 Alarm Settings

In the main menu, from Setting->Event->Alarm, you can see alarm setup interface.

• Alarm in: Here is for you to select channel number.

In the main menu, from Setting->Event->Alarm, you can see alarm setup interface. See Figure 4-148. There are four alarm types. See Figure 4-148 to Figure 4-151.

- ♦ Local alarm: After connect the alarm device to the NVR alarm input port, system can trigger the corresponding alarm operations when there is alarm signal from the alarm input port to the NVR.
- ♦ Network alarm: NVR trigger corresponding alarm operations when it receives the alarm signal via the network transmission.
- ♦ IPC external alarm: When the network camera connected peripheral device has triggered an alarm, it can upload the alarm signal to the NVR via the network transmission. The system can trigger the corresponding alarm operations.
- IPC offline alarm: When the network connection between the NVR and the network camera is off, the system can trigger the corresponding alarm operations.
- Enable: Please you need to highlight this button to enable current function.
- Type: normal open or normal close.
- Period: Click set button, you can see an interface is shown as in Figure 4-153. There are two ways for you to set periods. There are max 6 periods in one day. There are four record types: regular,

motion detection (MD), Alarm, MD & alarm.

- ♦ In Figure 4-153, Select icon of several dates, all checked items can be edited together.
  - Now the icon is shown as . Click to delete a record type from one period.
- In Figure 4-153. Click button after one date or a holiday, you can see an interface shown as in Figure 4-154. There are four record types: regular, motion detection (MD), Alarm, MD & alarm.
- PTZ activation: When an alarm occurred, system can activate the PTZ operation. The PTZ activation lasts an anti-dither period. See Figure 4-152.
- Anti-dither: Here you can set anti-dither time. The value ranges from 5 to 600s. The anti-dither time refers to the alarm signal lasts time. It can be seem as the alarm signal activation stays such as the buzzer, tour, PTZ activation, snapshot, channel record. The stay time here does not include the latch time. During the alarm process, the alarm signal can begin an anti-dither time if system detects the local alarm again. The screen prompt, alarm upload, email and etc will not be activated. For example, if you set the anti-dither time as 10 second, you can see the each activation may last 10s if the local alarm is activated. During the process, if system detects another local alarm signal at the fifth second, the buzzer, tour, PTZ activation, snapshot, record channel will begin another 10s while the screen prompt, alarm upload, email will not be activated again. After 10s, if system detects another alarm signal, it can generate an alarm since the anti-dither time is out.
- Alarm output: The number here is the device alarm output port. You can select the corresponding ports(s) so that system can activate the corresponding alarm device(s) when an alarm occurred.
- Latch: When the anti-dither time ended, the channel alarm you select in the alarm output may last the specified period. The value ranges from 1 to 300 seconds. This function is not for other alarm activation operations. The latch is still valid even you disable the alarm event function directly.
- Show message: System can pop up a message to alarm you in the local host screen if you enabled this function.
- Alarm upload: System can upload the alarm signal to the network (including alarm center and the WEB) if you enabled current function. System only uploads the alarm channel status. You can go to the WEB and then go to the Alarm interface to set alarm event and alarm operation. Please go to the Network interface to set alarm center information.
- Send email: System can send out the alarm signal via the email to alert you when alarm occurs. Once you enable the snap function, system can also send out an image as the attachment. Please go to the Main Menu->Setting ->Network->Email interface to set.
- Record channel: you can select proper channel to record alarm video (Multiple choices).
  - You need to set alarm record mode as Schedule in Record interface (Main Menu->Advanced->Record). Please note the manual record has the highest priority. System record all the time no matter there is an alarm or not if you select Manual mode.
  - Now you can go to the Schedule interface (Main Menu->Setting->Schedule) to set the record type, corresponding channel number, week and date. You can select the record type:Regular/MD/Alarm/MD&Alarm. Please note, you cannot select the MD&Alarm and MD(or Alarm) at the same time.
  - Now you can go to the Encode interface to select the alarm record and set the encode parameter (Main Menu->Setting->Encode).

- Finally, you can set the alarm input as the local alarm and then select the record channel. The select channel begins alarm record when an alarm occurred. Please note system begins the alarm record instead of the MD record if the local alarm and MD event occurred at the same time.
- Tour: Here you can enable tour function when an alarm occurs. System supports 1/8-window tour. Please go to chapter4.3.6.2 Display for tour interval setup. Please note the tour setup here has higher priority than the tour setup you set in the Display interface. Once there two tours are both enabled, system can enable the alarm tour as you set here when an alarm occurred. If there is no alarm, system implements the tour setup in the Display interface.
- Snapshot: You can enable this function to snapshot image when an alarm occurs.
- Buzzer: Highlight the icon to enable this function. The buzzer beeps when an alarm occurs.

	SETTING
STAMERA	👼 NETWORK 🔯 EVENT 📴 STORAGE 📑 SYSTEM
VIDEO DETEC SMART PLAN	Local Net IPC Ext IPC Offline
IVS	Alarm In 🛛 🚺 👻 Enable 🗹 Type NO 👻
FACE DETECTI PEOPLE COUN	Alarm Name
HEAT MAP	Period Setup Anti-Dither 5 Sec.
VEHICLE REC	Alarm Out 123456 Latch (10 Sec.
AUDIO DETECT	Show Message Alarm Upload Send Email
ALARM	Record Channel Setup Delay 10 Sec.
ABNORMALITY	PTZ Activation Setup
ALARM OUTPUT	Tour Setup
	Snapshot Setup
	Voice Prompts File Name None
	Buzzer
	Default Copy OK Cancel Apply

Figure 4-148

	SETTING
🇓 CAMERA	TINETWORK 🙀 EVENT
VIDEO DETECT ALARM ABNORMALITY ALARM OUT	IPC Ext Alarm       IPC Offline Alarm       Local Alarm       Net Alarm         Channel       1       Enable       Image: Second         Image: Alarm Out       123       Latch       10       Second         Image: Alarm Out       123       Latch       10       Second         Image: Alarm Out       12345678910112314       Second       Image: Alarm Out       Image: Alarm Out         Image: Alarm Out       12345678910112314       Second       Image: Alarm Out       Image
	V rour     I 234567891111314       Buzzer         Default     Copy         Save     Cancel         Apply

Figure 4-149

SETTING							
ST CAMERA		EVENT	STORAGE	SYSTEM			
VIDEO DETEC SMART PLAN	Local	Net IPC Ext	IPC Offline				
IVS	Channel	D2 The Enal	ole 🗌 Type (NC	$\mathbb{D}$ $  $			
FACE DETECTI PEOPLE COUN	Alarm Name						
HEAT MAP	Period	Setup	Anti-Dither (	5 Sec.			
VEHICLE REC	Alarm Out	1234	56 Latch (10	Sec.			
AUDIO DETECT	Show Message	Alarm Upload	Send Em	ail			
ALARM	Record Channel	Setup	Delay (10	Sec.			
ABNORMALITY	PTZ Activation	Setup					
ALARM OUTPUT	Tour	Setup					
	Snapshot	Setup					
	✓Log						
	☐Voice Prompts	File Name None					
	Buzzer						
	Default	Copy Refresh	) с	Cancel Apply			
	Default	Copy Refresh	) (	Cancel Apply			

Figure 4-150

		SETTING	
		📷 EVENT	STORAGE 🛃 SYSTEM
VIDEO DETEC SMART PLAN IVS FACE DETECTI	Local Channel	Net IPC Ext	IPC Offline
PEOPLE COUN HEAT MAP VEHICLE REC AUDIO DETECT ALARM ABNORMALITY ALARM OUTPUT	Alarm Out Show Message Record Channel PTZ Activation Tour Snapshot Log Voice Prompts	1234 Alarm Upload Setup Setup Setup Setup	5 6 Latch 10 Sec. Send Email Delay 10 Sec.
	Buzzer Default	Сору	OK Cancel Apply

### Figure 4-151

		PTZ Activation		
		_		
D1	None 🕤 (1	$\supset$	D2	None 🔻 1
D3	None 🔻 1	$\supset$	D4	None 🔽 1
D5	None 🔻 1	$\supset$	D6	None 🔽 1
D7	None 🔻 🕇		D8	None 🔻 1
D9	None 🔻 1		D10	None 🔻 1
D11	None 🔻 1		D12	None 🔻 1
D13	None 🔻 1		D14	None 🔻 1
D15	(None ) (1		D16	None  T
D17	(None ) (1	$\supset$	D18	None
D19	(None ) (1	$\supset$	D20	None 1
D21	(None 🔻 1	$\supset$	D22	None
D23	(None 🔻 1	$\supset$	D24	None 7 1
				OK Cancel
				Currour Currour

Figure 4-152



Figure 4-153

Time Period
Current Date: Sun
Period 1 (00 : 00 - 24 : 00 )
Period 2 (00 : 00 - 24 : 00 )
Period 3 (00 : 00 - 24: 00 )
Period 4 $(00:00 - 24:00)$
Period 5 (00 : 00 - 24 : 00 )
Period 6 (00 : 00 - 24 : 00 )
Copy
All Sun () Mon () Tue () Wed () Thu () Fri () Sat
Save

Figure 4-154

Please highlight icon <a>
 </a>
 to select the corresponding function. After setting all the setups please click save button.

### 4.7.10 Abnormality

There are three types: Disk/Network/User.

- ♦ Disk: Disk error, no disk, no space. See Figure 4-155.
- ♦ Network: Disconnection, IP conflict, MAC conflict. See Figure 4-156.
- ♦ User: Illegal login. Figure 4-157.

- Alarm output: Please select alarm activation output port (multiple choices).
- Less than: System can alarm you when the HDD space is less than the threshold you set here (For HDD no space type only).
- Attempts: In user interface, select illegal login from the dropdown list. Here you can set login attempts. The value ranges from 1 to 10.
- Lock time: In user interface, select illegal login from the dropdown list. Here you can set account lock time. The value ranges from 1 to 30 minutes.
- Latch: Here you can set corresponding delaying time. The value ranges from 1s-300s. System automatically delays specified seconds in turning off alarm and activated output after external alarm cancelled.
- Show message: system can pop up the message in the local screen to alert you when alarm occurs.
- Alarm upload: System can upload the alarm signal to the network (including alarm center) if you enabled current function. For disconnection event, IP conflict event and MAC conflict event, this function is null.
- Send email: System can send out email to alert you when alarm occurs.
- Buzzer: Highlight the icon to enable this function. The buzzer beeps when an alarm occurs.

	SETTING
	TRACE SYSTEM
VIDEO DETEC SMART PLAN IVS FACE DETECTI PEOPLE COUN HEAT MAP VEHICLE REC AUDIO DETECT ALARM ABNORMALITY ALARM OUTPUT	HDD Network Username Event Type No HDD Enable Alarm Out 123456 Latch 10 Sec. Show Message Alarm Upload Send Email Voice Prompts File Name None Buzzer CLog
	OK Cancel Apply

Figure 4-155

	SETTING
STAMERA	7 NETWORK 😹 EVENT STORAGE 🛃 SYSTEM
VIDEO DETEC SMART PLAN IVS FACE DETECTI PEOPLE COUN HEAT MAP VEHICLE REC AUDIO DETECT ALARM ABNORMALITY ALARM OUTPUT	HDD Network Username Event Type Disconnect Enable Alarm Out 123456 Latch 10 Sec. Show Message Send Email Voice Prompts File Name None Buzzer Log
	OK Cancel Apply

Figure 4-156

	SETTING
STAMERA	TRACE SYSTEM
VIDEO DETEC SMART PLAN	HDD Network Username
IVS FACE DETECTI PEOPLE COUN HEAT MAP	Event Type (Illegal Login V Enable Attempt(s) (5 Lock Time (5 Min.
VEHICLE REC AUDIO DETECT ALARM	Alarm Out 123456 Latch 10 Sec. Send Email
ABNORMALITY ALARM OUTPUT	☐Buzzer ✔Log
	OK Cancel Apply

Figure 4-157

### 4.7.11 Alarm output

From Main menu->Setting->Event->Alarm output, you can see an interface shown as in Figure 4-158.

Here is for you to set proper alarm output (Auto/manual/stop). Connect the alarm device to the system alarm output port, and set the mode as auto, system can trigger the corresponding operations when an alarm occurs.

- Auto: Once an alarm event occurs, system can generate an alarm.
- Manual: Alarm device is always on the alarming mode.
- Stop: Disable alarm output function.

Click OK button of the alarm reset, you can clear all alarm output status.

		SETTING		
STAMERA		Devent	STORAGE	SYSTEM
VIDEO DETEC SMART PLAN IVS FACE DETECTI PEOPLE COUN HEAT MAP	Alarm Out Auto Manual Stop Status	All 1 2 3 4 5 • • • • • • • • • • • • • • • • • • •		
VEHICLE REC AUDIO DETECT ALARM ABNORMALITY ALARM OUTPUT	Alarm Release	ОК		
			ОК	Cancel Apply

Figure 4-158

Please highlight icon to select the corresponding alarm output. After all the setups please click OK button.

### 4.7.12 POS

Connect the device with the POS, the device can receive the POS information and overlay corresponding info on the video.

### Note

- For the local-end, this function supports 1/4-window display and 1-window playback.
- This function is for the cashier of the supermarket and etc. The device can get the information from the POS and then overlay the txt information on the video.

Step 1 From main menu->Setting->System->POS, the interface is shown as below. See Figure 4-159.

		(	SETT	ING			
CAMERA	NETWO	ORK	📆 EVENT		STORAGE	SYS	ТЕМ
GENERAL DISPLAY RS232 PTZ POS BROADCAST VOICE PROMPT ACCOUNT AUTO MAINTAIN IMP/EXP DEFAULT UPGRADE	0 Add	Name	State	Modify	Delete C	Connect Type	Protocol Typ

Figure 4-159

Step 2 Click Add button, the interface is shown as below. See Figure 4-160. Set parameters.

- Enable: Check the box to enable POS function.
- Name: Set POS name.
  - 1. Click 온
  - 2. Input POS name on the pop-up dialogue box.
  - 3. Click OK button.

Note

The POS name shall be unique.

System max supports 64 English letters.

• Event: Set POS arm/disarm period, record channel and etc. Click Setup to go to the interface. For detailed information, please refer to chapter 4.7.1.1 motion detect.

• Privacy: After enable this function, once the overlay information contain the privacy character, it displays as \*. For example, the privacy character is 12,56,89, the local preview and WEB surveillance information is shown as \*\*34\*\*7\*\* if the overlay information is 123456789. For detailed information, please refer to chapter 4.7.12.1 privacy setup.

- Protocol type: The default setup is POS.
- Connection type: It is to set and NVR connection mode. It includes UDP,TCP,RS232,RS485. After set the connection type, please click the Setup button to set the corresponding parameters. For detailed information, please refer to chapter 4.7.12.2 connection type.
- Convert: It is to set font type.
- Overlay: It is to set overlay mode. It includes turn and roll.

- ♦ Turn: Once the overlay information has reached 8 lines, NVR turn to the next page.
- Roll: Once the overlay information has reached 8 lines, NVR displays the next new line and delete the oldest line.

• Network overtime: Once there is no POS data for the specified period, NVR automatically deletes POS information after specified period.

- Font size: The overlay font size.
- Color: The overlay font color.
- POS Info: Check the box to overlay information on the local preview window.
- Advanced: Click it to enter advanced settings interface.

• Transaction start/transaction end: It is to set transaction start and end character. The overlay information only displays the character after the start string and before the end string. For example, the start character is 12 and the end character is 90, NVR displays 34567 on local preview and Web preview interface if the sending out information is 123456789.

• Line delimiter: After set the line delimiter, the overlay information after the delimiter is displayed in the new line. For example, the line delimiter is 45 and the overlay information is 123456789, NVR displays 123 in the first line and displays 6789 in the second line.

- Hex: Check the Hex to switch ASCII code.
- Case insensitive: Check the box to enable case insensitive function.

♦ When this function is enabled, set the start character as "aa", NVR cannot distinguish the upper and lower case when sending out information "11aA23456". The NVR overlays information is "23456" on local surveillance and Web preview.

♦ When this function is disabled, set the start character as "aa", NVR can distinguish the upper and lower case when sending out information "11aA23456". The NVR does not overlay information local surveillance and Web preview.

- 4.7.12.1 Privacy Setup
- Step 1 Click Setup

Enter Setup interface. See Figure 4-160,

	Config
Enable 🔲	
Name	pos
Connect Type	NETWORK V Setup
Protocol Type	PC America 🔹
Transaction Start	
Transaction End	
Line Delimiter	
Ignored String	
	Case Insensitive
Network Overtime	(30 (5s-900s)
Time Display	(120 (5s-600s)
(CHANNEL SET)	
	OK Cancel

Figure 4-160

- Step 2 Set privacy information.
- Step 3 Click OK button.
- 4.7.12.2 Connection type

### • Connection type is UDP or TCP.

Step 1 Click Setup.

Enter Setup interface. See Figure 4-161.



Figure 4-161

Step 2 Source IP and port refers to POS IP address and port.

### III Note

Destination IP and port refers to NVR IP address and port. System can auto get and display. Step 3 Click OK to complete setup.

### • Connection mode is RS232 or RS485.

Step 1 Click Setup.

Enter Setup interface. See Figure 4-162.

	Config	
Enable	(Net     •       POS     •	
Ignore	Browse	
	2346678910112131416 OK Cancel	
(CHANNEL SET)		
_	Save Cancel	

Figure 4-162

Step 2 Set address, baud rate, data bit, stop bit and parity.

### D Note

Make sure the parameters here are the same with the POS setup.

Step 3 Click OK to complete setup.

### 4.8 Network

### 4.8.1 Network Settings

4.8.1.1 TCP/IP

The single network adapter interface is shown as in Figure 4-163 and the dual network adapters interface is shown as in Figure 4-164.

- Network Mode : Includes multiple access, fault tolerance, and load balancing
  - Multiple-address mode: eth0 and eth1 operate separately. You can use the services such as HTTP, RTP service via eth00 or the eth1. Usually you need to set one default card (default setup is etho) to request the auto network service form the device-end such as DHCP, email, FTP and etc. In multiple-address mode, system network status is shown as offline once one card is offline.

- Network fault-tolerance: In this mode, device uses bond0 to communicate with the external devices. You can focus on one host IP address. At the same time, you need to set one master card. Usually there is only one running card (master card).System can enable alternate card when the master card is malfunction. The system is shown as offline once these two cards are both offline. Please note these two cards shall be in the same LAN.
- Load balance: In this mode, device uses bond0 to communicate with the external device. The eth0 and eth1 are both working now and bearing the network load. Their network load are general the same. The system is shown as offline once these two cards are both offline. Please note these two cards shall be in the same LAN.
- Default Network Card: Please select eth0/eth1/bond0(optional) after enable multiple-access function
- Main Network Card: Please select eth0/eth1 (optional).after enable multiple access function.

# Note: The dual-Ethernet port series support the above three configurations and supports functions as multiple-access, fault-tolerance and load balancing.

- IP Version: There are two options: IPv4 and IPv6. Right now, system supports these two IP address format and you can access via them.
- MAC address: The host in the LAN can get a unique MAC address. It is for you to access in the LAN. It is read-only.
- IP address: Here you can use up/down button (▲▼) or input the corresponding number to input IP address. Then you can set the corresponding subnet mask the default gateway.
- Default gateway: Here you can input the default gateway. Please note system needs to check the validity of all IPv6 addresses. The IP address and the default gateway shall be in the same IP section. That is to say, the specified length of the subnet prefix shall have the same string.
- DHCP: It is to auto search IP. When enable DHCP function, you cannot modify IP/Subnet mask /Gateway. These values are from DHCP function. If you have not enabled DHCP function, IP/Subnet mask/Gateway display as zero. You need to disable DHCP function to view current IP information. Besides, when PPPoE is operating, you cannot modify IP/Subnet mask /Gateway.
- MTU: It is to set MTU value of the network adapter. The value ranges from 1280-7200 bytes. The default setup is 1500 bytes. Please note MTU modification may result in network adapter reboot and network becomes off. That is to say, MTU modification can affect current network service. System may pop up dialog box for you to confirm setup when you want to change MTU setup. Click OK button to confirm current reboot, or you can click Cancel button to terminate current modification. Before the modification, you can check the MTU of the gateway; the MTU of the NVR shall be the same as or is lower than the MTU of the gateway. In this way, you can reduce packets and enhance network transmission efficiency.

The following MTU value is for reference only.

- ♦ 1500: Ethernet information packet max value and it is also the default value. It is the typical setup when there is no PPPoE or VPN. It is the default setup of some router, switch or the network adapter.
- ♦ 1492: Recommend value for PPPoE.
- ♦ 1468: Recommend value for DHCP.
- Preferred DNS server: DNS server IP address.
- Alternate DNS server: DNS server alternate address.
- Transfer mode: Here you can select the priority between fluency/video qualities.
- LAN download: System can process the downloaded data first if you enable this function. The download speed is 1.5X or 2.0X of the normal speed.

• LAN download: System can process the downloaded data first if you enable this function. The download speed is 1.5X or 2.0X of the normal speed.

After completing all the setups please click save button, system goes back to the previous menu.

		Setup		
🗓 CAMERA		To EVENT	STORAGE	SYSTEM
CAMERA  CCP/IP  PORT  GG  PORT  GG  PPPoE  DDNS  UPnP  SYNC TIME RIG  EMAIL  SNMP  MULTICAST  ALARM CENTER  REGISTER  SWITCH  Wi-Fi  P2P	MTU IP Version MAC Address IP Address Subnet Mask Default Gateway Preferred DNS Alternate DNS	1500         LAN Download         (IPv4 •         90:02:A9:B9:5B:E0         10 · 15 · 6 ·         255 · 255 · 0 ·         10 · 15 · 0 ·         8 · 8 · 8 ·         8 · 8 · 4 ·		
	Default		Save	Cancel Apply

Figure 4-163

		SETTING	
🗓 CAMERA		🕞 EVENT 🛛 🛃 STO	RAGE 🔤 SYSTEM
TCP/IP	Nes Marda		
PORT	Net Mode	(Multi-address ) Default Ethernet	Port Ethernet1
3G	Ethernet Card	Ethernet1 Version	IPv4
PPPoE	MAC Address	(20:13:10:13:16:33	
DDNS	Mode	STATIC O DHCP	
UPnP	IP Address	10 . 15 . 6 . 145	
SYNC TIME RIG	Subnet Mask		
EMAIL	Default Gateway		
SNMP	Preferred DNS		
MULTICAST	Alternate DNS		
ALARM CENTER	MTU	(1500	
REGISTER		LAN Download	
SWITCH			
Wi-Fi			
P2P			
·	Defeuit		
	Default		Save Cancel Apply



The connection setup interface is shown as in Figure 4-165.

- Max connection: The max client login amount (such as WEB, platform, cellphone and etc). The value ranges from 1 to 128(default).
- TCP port: Default value is 37777.
- UDP port: Default value is 37778.
- HTTP port: Default value is 80.
- HTTPS port: Select the Enable check box and configure the port according to your actual needs. The default value is 443. After HTTPS is enabled, HTTP will be switched to HTTPS by force to transmit data in a safer way.
- RTSP port: Default value is 554.

# 

System needs to reboot after you changed and saved any setup of the above ports. Make sure the port values here do not conflict.

		Setup		
N CAMERA		D EVENT	STORAGE	SYSTEM
TCP/IP PORT 3G PPPoE DDNS	Max Connection TCP Port UDP Port HTTP Port HTTPS Port	37777         (1)           37778         (2)           80         (2)	L~128) L025~65535) L025~65535) L~65535) L~65535) L~65535) 🚺 Enable	
UPnP SYNC TIME RIG EMAIL SNMP MULTICAST ALARM CENTER REGISTER	RTSP Port POS Port		1~65535) 1~65535)	
SWITCH Wi-Fi P2P	Default		ОК	Cancel Apply

Figure 4-165

### 4.8.1.3 Wi-Fi AP

### Note

This function is available only for NVR devices with built-in Wi-Fi module. See the actual situation. 4.8.1.3.1 General Settings

The Wi-Fi AP interface is shown as below. See Figure 4-166. Here you can set Wi-Fi hotspot, so that the network camera can use the hotspot to connect to the network.

- 2.4GHz: Please check the box to enable the function.
- SSID: It is to set SSID name. You can use this name to search the device.
- Password: It is to set SSID password. You can use this password to connect to the network.

- Encryption Type: Select encryption type from the dropdown list.
- Channel: Please select a channel from the dropdown list. The default setup is auto.
- Gain: There are three options: High/middle/low. Please select from the dropdown list.

		SETTING	
N CAMERA		To EVENT	SYSTEM
TCP/IP Port	General	Advanced	
REPEATER	2.4GHz		
WIFI AP	SSID	(NVR-2.4G_4C	
DDNS	Encryption Type	WPA2 PSK	
EMAIL	Password	(12345678	
REGISTER	Channel	Auto	
P2P	Gain	(Middle )	
	Default		Apply

Figure 4-166

#### 4.8.1.3.2 Advanced

Click Advanced and you can see an interface shown as below. See Figure 4-167.

- IP Address: Input Wi-Fi AP IP address.
- Subnet Mask: Input Wi-Fi AP subnet mask.
- Default Gateway: Input Wi-Fi AP gateway.
- Start IP/End IP: Input start IP and end IP of the network cameras. The NVR can allocate the IP addresses in the range you specified here.
- Upgrade: Click it to upgrade Wi-Fi AP module.

	SETTING
SAMERA	TRANSPORT TRANSPORT
CAMERA TCP/IP Port REPEATER WIFI AP DDNS EMAIL REGISTER P2P	IP Config   IP Config   IP Address   22   1   Subnet Mask   255   255   25   Default Gateway   22   1   1   DHCP Server   Start IP   22   1   1   Dygrade   Build Date   2018-4-11 14:17:04   WIFI AP   Upgrade   Please insert USB device and then click update button to begin update, or you can select update file and then begin upgrade operation. Do not turn off the
	device during the upgrade process!           Default         OK         Cancel         Apply

Figure 4-167

### 4.8.1.4 Wi-Fi

The Wi-Fi interface is shown as below. See Figure 4-168.

- Enable: Check the box here to enable Wi-Fi function.
- Refresh: You can click it to search the hotspot list again. It can automatically add the information such as the password if you have set it before.
- Disconnect: Here you can click it to turn off the connection.
- Connect: Here you can click it to connect to the hotspot. System needs to turn off current connection and then connect to a new hotspot if there is connection of you selected one.

	Setup			
CAMERA				
TCP/IP PORT	Enable			
3G	0 SSID Signal Intensity WIFI Working Info			
PPPoE	Current Hotspot No Connection			
DDNS				
UPnP	IP Address			
SYNC TIME RIG	Subnet Mask			
EMAIL				
SNMP	Default Gateway			
MULTICAST				
ALARM CENTER				
REGISTER				
SWITCH				
Wi-Fi				
P2P				
	Refresh     Connect     Disconnect     OK     Cancel     Apply			

Figure 4-168

• Wi-Fi working status: Here you can view current connection status.

Please note:

- After successful connection, you can see Wi-Fi connection icon at the top right corner of the preview interface.
- When the hotspot verification type is WEP, system displays as AUTO since the device cannot detect its encryption type.
- System does not support verification type WPA and WPA2. The display may become abnormal for the verification type and encryption type.

After device successfully connected to the Wi-Fi, you can view the hotspot name, IP address, subnet mask, default gateway and etc. Right now system support TOTOLINK\_N2200UP module. 4.8.1.5 Repeater

The device supports repeater function for front-end IPCs to effectively extend video transmission distance and range.

Only some devices support this function.

Repeater is available for devices with built-in Wi-Fi module and the front-end IPC shall support repeater.

### **Binding Repeater**

Step 1 Turn on the NVR device and IPCs, and then directly connect all the IPCs to the NVR device via Wi-Fi.

Step 2 Enter from main menu > Setting > Network > Repeater.

Step1 The Repeater interface is displayed. See Figure 4-169.

When the connection line is green, the channel has conneted to Wi-Fi IPC successfully.





Step 3 Click for after the channel you want to set the repeater function. System displays the icon to add channel. See Figure 4-170.

		SETTI	NG		
S CAMERA		Tag EVENT			SYSTEM
TCP/IP Port REPEATER WIFI AP DDNS EMAIL REGISTER P2P	NVR CH CH CH CH CH2 CH3 Refresh	CH1 CH2 CH3 CH3 CH4 CH4 CH5 CH6 CH7 CH8 Kb/s 0 66 66 66		OK	
	Reliesit				Cancel Apply

Figure 4-170

Step 4 Click



 $\checkmark$  and select the channel you want to add.

After the adding is successful, system displays the following interface. See Figure 4-171.



Figure 4-171

### 

To take Figure 4-171 as an example, the IPC connected to CH1 is the primary repeater and the IPC connected to CH2 is the secondary repeater. Each primary repeater can connect 2 Wi-Fi IPCs at most in series or in parallel.

- When connecting IPCs in series, the IPC in CH2 works as a secondary repeater to connect the IPC in CH3. See Figure 4-172.
- When connecting IPCs in parallel, the IPC in CH1 works as a primary repeater to connect the IPCs in CH2 and CH3. See Figure 4-173.


Figure 4-172



Figure 4-173

Step 5 Click Apply or OK to save the configuration.

# **Unbinding Repeater**

If you want to unbind the repeater, click the corresponding channel and the IPC in this channel will connect to the NVR device directly.

# D NOTE

You can delete repeater IPC only from the last level

### 4.8.1.6 3G

3G setup interface is shown as below. See Figure 4-174.

Please refer to the following contents for the parameter information.

- Pane 1: Display 3G signal intensity after you enabled 3G function.
- Pane 2: Display 3G module configuration information after you enabled 3G function.
- Pane 3: Display 3G module status information after you enabled 3G function.

It is to display current wireless network signal intensity such as EVDO, CDMA1x, WCDMA, WCDMA, EDGE and etc.

- 3G module: It is to display current wireless network adapter name.
- 3G Enable/Disable: Check the box here to enable 3G module.
- Network type: There are various network types for different 3G network modules. You can select according to your requirements.
- APN: It is the wireless connection server. It is to set you access the wireless network via which method.
- AUTH: It is the authentication mode. It supports PAP/CHAP.
- Dial number: Please input 3G network dialup number you got from your ISP.
- User name: It is the user name for you to login the 3G network.
- Password: It is the password for you to login the 3G network.
- Pulse interval: You can set dialup duration. Once you disable the extra stream, the connection time begins. For example, if you input 5 seconds here, then 3G network connection period is 5 seconds. The device automatically disconnect when time is up. If there is no extra stream, 3G network connection is valid all the time. If the alive time is 0, then the 3G network connection is valid all the time.
- Dial: Here you can enable or disable 3G network connection/disconnection manually.
- 3G wireless network: Here is to display wireless network status, SIM card status, dial status. If the 3G connection is OK, then you can see the device IP address the wireless network automatically allocates.

		Setup				
🗓 CAMERA	TWORK	D EVENT	STORAGE	SYSTEM		
TCP/IP CONNECTION WIFI 3G	Enable Signal Intensity N					1
PPPOE DDNS UPNP IP FILTER EMAIL	3G Network APN AUTH Dial No. User Name		work Type (NOSER)	<u>/ICE</u> )		2
FTP SNMP MULTICAST ALARM CENTER	Pulse Interval 0 3G Wireless Netw Module State - SIM State -	rork IP A	ddress - net Mask -	Dial		
AUTO REGISTER P2P SETTING EASY SPACE SWITCH	PPP State -	Def	ault Gateway -			3
	Default		ОК	Cancel Ap	ply	

Figure 4-174

## 4.8.1.7 PPPoE

PPPoE interface is shown as in Figure 4-175.

Input "PPPoE name" and "PPPoE password" you get from your ISP (Internet service provider).

Click save button, you need to restart to activate your configuration.

After rebooting, NVR will connect to internet automatically. The IP in the PPPoE is the NVR dynamic value. You can access this IP to visit the unit.

		Setup		
CAMERA		D EVENT	STORAGE	SYSTEM
TCP/IP PORT 3G PPPOE DDNS UPnP SYNC TIME RIG EMAIL SNMP MULTICAST ALARM CENTER REGISTER SWITCH Wi-Fi P2P .	Enable User Name ( Password ( IP Address (			
	Default		ОК	Cancel Apply

Figure 4-175

## 4.8.1.8 DDNS

DDNS (Dynamic Domain Name Server) is to dynamically refresh the DNS domain name and IP address if the device IP address has changed frequently. The user can use the domain to access the device.

#### Preparation

Before the operation, make sure the device supports DNS type and go to the DDNS service provider website to register the domain name via the PC.

After you register the device and log in the DDNS website, you can view all connected device information of the current user.

Step 1 Enter from main memu > Setup > Network > DDNS. DDNS setup interface is shown as in Figure 4-176.

	_	SETTING		
🥰 CAMERA		📆 EVENT	STORAGE	SYSTEM
TCP/IP PORT 3G PPPoE DDNS	Enable After DDNS Type Host IP Domain Name	r enabling DDNS fund (NO-IP DDNS (dynupdate.nd		may collect your devic
UPnP SYNC TIME RIG EMAIL SNMP MULTICAST ALARM CENTER REGISTER SWITCH	Username Password Interval	(1440	Min.	
Wi-Fi P2P	Default 1	- est	ОК	) Cancel Apply

Figure 4-176

Step 2 Select the Enable check box to enable DDNS function.

When DDNS is enabled, the third-party server might collect your device information.

Step 3 Configure the DDNS parameters according to practical situation.

- Type/address:
- ♦ Dyndns DDNS is members.dyndns.org.
- ♦ NO-IP DDNS is dynupdate.no-ip.com.
- ♦ CN99 DDNS is members.3322.org.
- Domain: The domain name registered on the DDNS service provider website.
- User name/password: Input the user name and password got from the DDNS service provider. Make sure you have logged in the DDNS service provider website to register an account (user name and password).
- Interval: After DDNS boots up, it sends out refresh query regularly. The unit is minute.

Step 4 Click Apply or Save to complete setup.

- Step 5 Open a browser and input domain name, click Enter key.
  - The setting is right if you can view device WEB interface. Otherwise, please check the parameters.

# 4.8.1.9 UPnP

The UPNP protocol is to establish a mapping relationship between the LAN and the WAN. Please input the router IP address in the LAN in Figure 4-163. See Figure 4-177.

• UPNP on/off :Turn on or off the UPNP function of the device.

- Status: When the UPNP is offline, it shows as "Unknown". When the UPNP works it shows "Success"
- Router LAN IP: It is the router IP in the LAN.
- WAN IP: It is the router IP in the WAN.
- Port Mapping list: The port mapping list here is the one to one relationship with the router's port mapping setting.
- List:
  - ♦ Service name: Defined by user.
  - ♦ Protocol: Protocol type
  - $\diamond$  Internal port: Port that has been mapped in the router.
  - ♦ External port: Port that has been mapped locally.
- Default: UPNP default port setting is the HTTP, TCP and UDP of the NVR.
- Add to the list: Click it to add the mapping relationship.
- Delete: Click it to remove one mapping item.

Double click one item; you can change the corresponding mapping information. See Figure 4-178.

#### Important:

When you are setting the router external port, please use 1024~5000 port. Do not use well-known port 1~255 and the system port 256~1023 to avoid conflict.

For the TCP and UDP, please make sure the internal port and external port are the same to guarantee the proper data transmission.

		Setup			
N CAMERA	<b>TWORK</b>	To EVENT	STORAGE	SYSTEM	
TCP/IP PORT 3G PPPoE	Enable Status Disable	e 0 . 0 . 0			
DDNS UPnP	WAN IP 0 . Port Mapping Lis	0.0.0			
SYNC TIME RIG EMAIL SNMP MULTICAST ALARM CENTER REGISTER SWITCH Wi-Fi P2P		rice Name Protocol P TCP UDP P UDP P UDP P TCP 1P UDP	Internal Port 80 37777 37778 554 554 161 443	External Port 80 37777 37778 554 554 161 443	
	Add ( Default	Delete	ОК	Cancel Apply	)

Figure 4-177

	PORT INFO
Service Name Protocol Internal Port	TCP (80
External Port	(80 OK Cancel

Figure 4-178

#### 4.8.1.10 Email

The email interface is shown as below. See Figure 4-179.

- SMTP server: Please input your email SMTP server IP here.
- Port: Please input corresponding port value here.
- User name: Please input the user name to login the sender email box.
- Password: Please input the corresponding password here.
- Sender: Please input sender email box here.
- Title: Please input email subject here. System support English character and Arabic number. Max 32-digit.
- Receiver: Please input receiver email address here. System max supports 3 email boxes. System automatically filters same addresses if you input one receiver repeatedly.
- SSL enable: System supports SSL encryption box.
- Interval: The send interval ranges from 0 to 3600 seconds. 0 means there is no interval.
- Health email enable: Please check the box here to enable this function. This function allows the system to send out the test email to check the connection is OK or not.
- Interval: Please check the above box to enable this function and then set the corresponding interval. System can send out the email regularly as you set here. Click the Test button, you can see the corresponding dialogue box to see the email connection is OK or not.

Please note system will not send out the email immediately when the alarm occurs. When the alarm, motion detection or the abnormity event activates the email, system sends out the email according to the interval you specified here. This function is very useful when there are too many emails activated by the abnormity events, which may result in heavy load for the email server.

	Setup
CAMERA	TINETWORK THE EVENT STORAGE SYSTEM
TCP/IP PORT 3G PPPoE DDNS UPnP SYNC TIME RIG EMAIL SNMP MULTICAST ALARM CENTER REGISTER SWITCH Wi-Fi P2P	Enable          SMTP Server       MailServer       Port       25         Anonymous         User Name       Password         Receiver         Sender         Subject       NVR ALERT       Attachment         Encrypt Type       NONE       •         Interval       120       sec.         Health Enable       Interval       60         Interval       60       min.
	Default OK Cancel Apply

Figure 4-179

### 4.8.1.11 SNMP

SNMP is an abbreviation of Simple Network Management Protocol. It provides the basic network management frame of the network management system. SNMP is widely used in various scenarios, network devices, software and systems.

#### Preparation:

- Install SNMP monitor and management tool, such as MIB Builder and MG-SOFT MIB Browser.
- Obtain the corresponding MIB file from the technical support.
- Step 1 Enter from main menu > Setup > Network > SNMP.

The SNMP interface is displayed. See Figure 4-180.

	SETTING
SAMERA	TINETWORK TAGE EVENT SYSTEM
TCP/IP PORT 3G	Enable Version V1 V2 V3 (Recommended)
PPPoE DDNS UPnP	SNMP Port (1 <sup>65535</sup> ) Read Community Write Community
SYNC TIME RIG EMAIL SNMP	Trap Address
MULTICAST ALARM CENTER REGISTER SWITCH	Authentication Type     MD5     Authentication Type     MD5       Authentication Password     Authentication Password     CBC-DES     Encryption Type       Encryption Password     Encryption Password     Encryption Password
Wi-Fi P2P	
	Default OK Cancel Apply

Figure 4-180

- Step 2 Select the SNMP check box.
- Step 3 Configure the parameyers. For details, see the following table.

Parameter	Description				
	Select the check box of the corresponding version.				
Version	D NOTE				
	System selects V3 by default. There might be risks for V1 and V2.				
SNMP Port	Enter the SNMP port number.				
Read					
Community/Write	The read community/write community string supported by the program.				
Community					
Trap Address	Enter the IP address of the PC installed with MG-SOFT MIB Browser. It				
Hap Addless	is the destination address to receive trap information from the device.				
Trap Port	The destination port to receive trap information from the device.				
Read Only User	Enter the read only username to access the NVR device.				
Read/Write User	Enter the read/write username to access the NVR device.				
Authentication	It includes MD5 and SHA. System automatically recognizes it after it is				
Authentication	enabled.				
Password	Enter the password for encryption and authentication. The password				
F 455WUIU	shall be no less than 8 characters.				
Encryption Type	Select the encryption type. The default type is CBC-DES.				

Step 4 Click OK to complete the configuration.

- Step 5 View device info.
  - 1) Run MIB Builder and MG-SOFT MIB Browser.

- 2) Compile the two MIB files with MIB Builder.
- 3) Load the compiled module to the software with MG-SOFT MIB Browser.
- 4) Enter the PC IP address into MG-SOFT MIB Browser and select the version to search.
- 5) Expand the tree list in MG-SOFT MIB Browser to view the device configuration information, such as channel number and program version.

#### 4.8.1.12 Multicast

When multiple users preview the video of a channel through the network at the same time, due to network bandwidth limitation, they might be unable to preview. You can set a multicast IP for NVR device (224.0.0.0 - 238.255.255.255) and adopt the way of multicast protocol access to solve the problem. Step 6 Enter from main menu > Setup > Network > Multicast.

The Multicast interface is shown as in Figure 4-181.

CAMERA IP NETWORK EVENT IN CONTROL INTERVICIA INTERVICIA IN CONTROL INTERVICIA INTERVICI	STORAGE 🛃 SYSTEM
PORT 3G IP Address 239 · 255 · 42 · 42 PPPoE Port 36666 DDNS	
SYNC TIME RIG EMAIL SNMP	
MULTICAST ALARM CENTER REGISTER SWITCH Wi-Fi P2P	OK Cancel Apply

Figure 4-181

- Step 7 Select the Enable check box to enable this function.
- Step 8 Configure the parameters. For details, see the following table.

Parameter	Descrip	otion							
IP Address	Enter (224.0.	the 1.0-238	multicast 3.255.255.25	IP 5).	address	to	access	the	device
Port	Enter th	Enter the multicast port number to access the device (1025-65000).							

Step 9 Click Apply or OK to complete the setting.
 After configuring the multicast, you can log in Web with multicast.
 Log in Web. In the Type drop-down list, select Milticast. See Figure 4-182. System will automatically obtain the multicast address and join the multicast goup. Open the monitor and you can view the video in multicast way.

alhua		
Username:	admin	
Password:		Plain Text
Туре:	TCP TCP (UDP MULTICAST	Forgot password?
	Login Cancel	

Figure 4-182

### 4.8.1.13 Alarm Centre

This interface is reserved for you to develop. See Figure 4-183.

		Setup		
N CAMERA	<b>TWORK</b>	To EVENT	STORAGE	SYSTEM
TCP/IP PORT 3G PPPoE DDNS UPnP SYNC TIME RIG EMAIL SNMP MULTICAST ALARM CENTER REGISTER SWITCH Wi-Fi P2P	Enable Protocol Type ( Host IP ( Port ( Self-report Time (Everyday	ALARM CENTER 10 . 1 . 0 . 1	2	
	Default		OK	Cancel Apply

Figure 4-183

#### 4.8.1.14 Auto register

This function allows the device to auto register to the proxy you specified. In this way, you can use the client-end to access the NVR and etc via the proxy. Here the proxy has a switch function. In the network service, device supports the server address of IPv4 or domain.

Please follow the steps listed below to use this function.

Please set proxy server address, port, and sub-device name at the device-end. Please enable the auto register function, the device can auto register to the proxy server.

1) The setup interface is shown as in Figure 4-184.

#### Important

Do not input network default port such as TCP port number.

		Setup		
🗓 CAMERA		To EVENT	STORAGE	SYSTEM
CAMERA TCP/IP PORT 3G PPPoE DDNS UPnP SYNC TIME RIG EMAIL SNMP MULTICAST ALARM CENTER REGISTER	Enable No. Host IP Port Sub-device ID	EVENT (1) (0.0.0) (0.0.0 (0.0.0) (0.0.0	STORAGE	SYSTEM
SWITCH Wi-Fi P2P	Default		ОК	Cancel Apply
	Delault			Cancel Apply

Figure 4-184

2) The proxy server software developed from the SDK. Please open the software and input the global setup. Please make sure the auto connection port here is the same as the port you set in the previous step.

3) Now you can add device. Please do not input default port number such as the TCP port in the mapping port number. The device ID here shall be the same with the ID you input in Figure 4-184. Click Add button to complete the setup.

4) Now you can boot up the proxy server. When you see the network status is Y, it means your registration is OK. You can view the proxy server when the device is online.

#### Important

The server IP address can also be domain. But you need to register a domain name before you run proxy device server.

#### 4.8.1.15 P2P

You can use your cell phone to scan the QR code and add it to the cell phone client.

Via the SN from scanning the QR code, you can access the device in the WAN. Please refer to the P2P operation manual included in the resources CD.

From main menu->Setting->Network->P2P, you can go to the following interface, the P2P interface is shown as in Figure 4-185.



Figure 4-185

Here we use cell phone APP to continue.

1.

- Step 1 Use cell phone to scan the QR code and download the APP.
- Step 2 After installation, run the APP and Live Preview, enter the main interface. Now you can add device to the APP.



- Open App; tap to go to the Live preview.
- 2. Tap  $\stackrel{:=}{=}$  at the top left corner, you can see the main menu.
- 3. Tap Device manager button, you can use several modes (P2P/DDNS/IP and etc.) to add

the device. Click		to save current setup.	Тар	Start Live	preview to	view	all-channe
video from the con	necte	ed device. See Figure 4	186.				

••••• 中国移动 令	13:18	
	P2P	
Register Mode:		P2P
Name:		
SN:		<b>]</b> 99
Username:		admin
Password:		•••••
Live Preview:		Extra >
Playback:		Extra >
D.		Check VTO
Start	Live Pre	view

Figure 4-186

#### 4.8.1.16 Easy Space

This function allows you to upload motion detect record or snapshot image to the dropbox and etc.

The easy space interface is shown as below. See Figure 4-187.

Please select the easy space address from the dropdown list and then input corresponding user name and password.

		Setup		
CAMERA	TWORK	To EVENT	STORAGE	SYSTEM
TCP/IP CONNECTION WIFI 3G PPPOE DDNS UPNP EMAIL FTP SNMP MULTICAST ALARM CENTER AUTO REGISTER P2P SETTING EASY SPACE SWITCH	Enable	ropbox	Test	
	Default		ОК	Cancel Apply

Figure 4-187

- The uploaded file is for sub stream only. Please go to record control interface (main stream->setting->Storage->Record) and then select sub stream.
- The easy space function uses upload bandwidth. Usually the recommended upload bandwidth shall be more than 512kbps and please make sure the network is stable.
- The easy space upload data adopts safe SSL encryption connection. Please enable 1-channel to upload in case this function occupies too much CPU.

#### 4.8.1.17 SWITCH

When connect a network camera to the PoE port of the NVR, NVR can automatically allocate the IP address according to the specified IP segment. The network camera can automatically register to the NVR.

It is for you to set IP address, subnet mask, gateway and etc of the Switch. See Figure 4-188.



- This function is for product of PoE port.
- Do not connect switch to the PoE port, otherwise the connection may fail.
- The SWITCH function of the NVR is enabled by default. The IP segment is 10.1.1.1. Usually we
  recommend the default setup.
- For the camera from the third party, make sure the camera supports ONVIF and DHCP function is enabled.

		Setup			
🗓 CAMERA	<b>TWORK</b>	To EVENT	STORAGE	SYSTEM	-
TCP/IP PORT 3G PPPoE DDNS UPnP SYNC TIME RIG EMAIL SNIMP MULTICAST ALARM CENTER REGISTER SWITCH Wi-Fi P2P	IP Address Subnet Mask Default Gateway	$\begin{array}{c ccccccccccccccccccccccccccccccccccc$	1		
	Default		ОК	Cancel Appl	у

Figure 4-188

Refer to the following table for PoE notice.

Type Note
-----------

Туре	Note
Connect	After connect the camera to the PoE, NVR allocate an IP address in the
camera to the	specified IP segment to the camera. NVR tries to use arp ping to set. If the
PoE	NVR has enabled the DHCP function, it uses DHCP to set.
	• After successfully set IP address, NVR can send out broadcast via the
	switch and get the corresponding response. Now The camera has
	registered to the NVR. Go to the preview interface, the corresponding
	channel has been used and there is a small PoE icon at the top left
	corner.
	• Go to the Register interface to view the connected device list, you can
	see the PoE channel number, PoE port information and etc. Click IP
	search to display or refresh the information.
Remove	After remove the camera network cable from the PoE port, the channel
camera from	displays "Cannot find the network host". On the registration interface, the IP
the PoE port	address is shown as offline.
The mapping	The PoE port and the channel window is one to one correspondence. For
policy when	example, connect a network camera to PoE port 1, it register to channel 1 by
connect a	default.
camera to the	
PoE port.	

# 4.8.2 Network Test

In this interface, you can see network test and network load information.

4.8.2.1 Network Test

From main menu->Info-Network->Test, the network test interface is shown as in Figure 4-189.

- Destination IP: Please input valid IPV4 address and domain name.
- Test: Click it to test the connection with the destination IP address. The test results can display average delay and packet loss rate and you can also view the network status as OK, bad, no connection and etc.
- Network Sniffer backup: Please insert USB2.0 device and click the Refresh button, you can view the device on the following column. You can use the dropdown list to select peripheral device. Click Browse button to select the snap path. The steps here are same as preview backup operation.

You can view all connected network adapter names (including Ethernet, PPPoE, Wi-Fi, and 3G), you can

click the button **I** on the right panel to begin Sniffer. Click the grey stop button to stop. Please note system cannot Sniffer several network adapters at the same time.

After Sniffer began, you can exit to implement corresponding network operation such as login WEB,

monitor. Please go back to Sniffer interface to click stop Sniffer. System can save the packets to the specified path. The file is named after "Network adapter name+time". You can use software such as Wireshark to open the packets on the PC for the professional engineer to solve complicated problems.

SYSTEM     EVENT     Inetwork     LOG       ONLINE USERS     Inetwork     Inetwork     Inetwork       LOAD     TEST     Destination IP     Inetwork       Test Result     Test Result     Inetwork     Inetwork			INFC		
LOAD     TEST       Destination IP     Test	SYSTEM	📆 EVENT		🐚 LOG	
Network Sniffer Packet Backup   Device Name   sdc1(USB DISK)     Address     (     Browse     Name   IP   Sniffer Packet Size   Sniffer Packet Backup     LAN1     10.15.6.143     OKB	ONLINE USERS	TEST Destination IP ( Test Result Network Sniffer P Device Name ( Address ( Name II	Packet Backup sdc1(USB DISK) /		Browse Sniffer Packet Backup



# 4.8.2.2 Network Load

From main menu->Info-Network->Load, network load is shown as in Figure 4-190. Here you can view the follow statistics of the device network adapter.

Here you can view information of all connected network adapters. The connection status is shown as offline if connection is disconnected. Click one network adapter, you can view the flow statistics such as send rate and receive rate at the top panel.

# D Note

- It is to display LAN1 network load by default.
- View one LAN network load by one time.



Figure 4-190

# 4.9 Storage

Here you can view HDD information such as type, status, total capacity, record time and etc. The operation includes format, resume from error, change HDD property (Read write, Read-only). Here you can also set alarm and HDD storage position.

## 4.9.1 Basic

It is to manage HDD storage space.

Step 1 From main menu->Setup->Storage->Basic. Enter Basic interface. See Figure 4-191.

, 		SETTING		
SAMERA		To EVENT		SYSTEM
BASIC SCHEDULE HDD MANAGE FTP RECORD ADVANCED HDD DETECT	HDD Full Pack Duration Auto-Delete Ol (Never	Overwrite <ul> <li>60</li> <li>Min.</li> <li>d Files</li> </ul>		
	Default		OK	Cancel Apply

Figure 4-191

Step 2 Set parameters.

- HDD full: It is to select working mode when hard disk is full. There are two options: stop recording or rewrite.
- Pack duration: It is to specify record duration. The max length is 120 minutes.
- Auto delete old files:
- ♦ Never: Do not auto delete old files.
- ♦ Customized: input customized period here and system can auto delete corresponding old files.
- $\diamond$  The deleted file cannot be restored.

Step 3 Click Apply or Save to complete setup.

# 4.9.2 Schedule

It is to set schedule record and schedule snapshot. NVR can record or snapshot as you specified. For detailed information, please refer to chapter 0 schedule record and 0 schedule snapshot.

# 4.9.3 HDD

It is to view and sett HDD properties and format HDD.

It is to view current HDD type, status, capacity and etc. The operation includes format HDD, and change HDD property (read and write/read-only/redundancy).

- To prevent files be overwritten in the future, you can set HDD as read-only.
- To backup recorded video file, you can set HDD as redundant HDD.

Step 1 From Mani-menu->Setting->Storage->HDD Manager, you can go to HDD management interface.

See Figure 4-192.

		SETTING		
STAMERA		To EVENT	STORAGE	SYSTEM
BASIC SCHEDULE HDD MANAGE FTP RECORD ADVANCED HDD DETECT	Name	Physical Position	Туре	HDD Group

Figure 4-192

- Step 2 Select a HDD and then select an time from the dropdown list. Click Execute button.
- Step 3 Click OK button to complete the setup. You can see system needs to restart to activate current setup if you want to format the HDD.

# 4.9.4 FTP

It is to backup record file or image to the FTP to storage or view.

Before the operation, please download or purchase the FTP service tool and install on the PC.

# D Note

For the FTP user, please set FTP folder write right, otherwise system cannot upload the image.

Step 1 From main menu->Setting->Storage->FTP, enter FTP interface. See Figure 4-193.

Step 2 Select the Enable check box to enable FTP function. Select FTP type.

FTP transmits data with clear text mode and SFTP transmits data with encrypted mode. SFTP is recommended.

Step 3 Set parameters.

Here you can input FTP server address, port and remote directory. When remote directory is null, system automatically creates folders according to the IP, time and channel.

- IP address: The host IP you have installed the FTP server.
- Port: The default SFTP port number is 22 and the default FTP port number is 21.

- User name/Password: The account for you to access the FTP server.
- Remote directory: The folder you created under the root path of the FTP according to the corresponding rule.
  - If there is no remote directory, system can auto create different directories according to the IP, time and channel.
  - ♦ If there is remote directory, system can create corresponding folder under the FTP root path and then create different folders according to IP address, time and channel.
- File length: File length is upload file length. When setup is larger than the actual file length, system will upload the whole file. When setup here is smaller than the actual file length, system only uploads the set length and auto ignore the left section. When interval value is 0, system uploads all corresponding files.
- Image upload interval: It is the image upload interval. If the image upload interval is larger than the image snapshot frequency, system just uploads the lasted image.
  - If the image interval is 5 seconds and the snapshot frequency is 2 seconds, system will send out the latest image at the buffer at 5 seconds.
  - If the image upload interval is smaller than the snapshot frequency, system will upload at the snapshot frequency. For example, if the image interval is 5 seconds and the snapshot frequency is 10 seconds, system will send out the image at 10 seconds.
  - ♦ From main menu->Setting->Camera->Encode->Snapshot to set snapshot frequency.
- Channel: Select a channel from the dropdown list and then set week, period and record type.
- Week day/Period: Please select from the dropdown list and for each day, you can set two periods.
- Type: Please select uploaded record type (Alarm/intelligent/motion detect/regular). Please check the box to select upload type.
- Step 4 Click the Test button, you can see the corresponding dialogue box to see the FTP connection is OK or not.
- Step 5 Click Apply or Save to complete setup.

	SETTING
🥰 CAMERA	TRANSPORT TRANSPORT
BASIC SCHEDULE HDD MANAGER	■ Enable ○ FTP ● SFTP (Recommended)
FTP	Host IP 0 . 0 . 0 Port (22 (1~65535)
RECORD	Username
ADVANCED	Password Anonymous
HDD DETECT	Remote Directory File Size 0 M
	Image Upload Interval 2 s Channel D1 Weekday Wed ALA Motion Regular Period 00:00 - 24:00 Period 00:00 - 24:00 Test
	Default OK Cancel Apply

### Figure 4-193

# 4.9.5 Record Control

After you set schedule record or schedule snapshot function, please set auto record/snapshot function so that the NVR can automatically record or snapshot. For detailed information, please refer to chapter 0 record control.

# 4.9.6 HDD Information

Here is to list hard disk type, total space, free space, and status. See Figure 4-194.

 $\circ$  means current HDD is normal.. - means there is no HDD.

If disk is damaged, system shows as "?". Please remove the broken hard disk before you add a new one.

	INFO
SYSTEM	
ESYSTEM HDD RECORD BPS VERSION	Image: Network     LOG       1*     Device Name Type     Free Space/Total Space Status     S.M.A.R.T       -     All     0.00 MB / 232.79 GB       1*     SATA-1     Read/Write 0.00 MB / 232.79 GB     Normal

Figure 4-194

In Figure 4-194, click one HDD item, the S.M.A.R.T interface is shown as in Figure 4-195.

Modle ST. Serial No. W1 Status Err Describe: Smart ID 1						
Status Err Describe: Smart ID	or					
Describe: Smart ID						
Smart ID	Attribute					
	Attribute					
1		Threshol	d Value	Worst	Status	-
	Read Error Rate	6	120	99	OK	
3	Spin Up Time	0	97	96	OK	
4	Start/Stop Count	20	100	100	OK	
5	Reallocated Sector Count	10	100	100	OK	
7	Seek Error Rate	30	59	55	OK	
9	Power On Hours Count	0	100	100	OK	
10	Spin-up Retry Count	97	100	100	OK	
12	Power On/Off Count	20	100	100	OK	
184	Unkown Attribute	99	100	100	OK	
187	Reported Uncorrect	0	100	100	OK	
188	Unkown Attribute	0	100	100	OK	
189	High Fly Writes	0	96	96	OK	
190	Airflow Temperature Cel	45	61	43	Error	
191	G-Sense Error Rate	0	100	100	OK	
192	Power-Off Retract Cycle	0	100	100	OK	L,
102	Lead/Unlead Custe Count	^	100	100		

Figure 4-195

Parameter	Function		
SATA	1 here means there is 1 HDD.		
	For different series product, the max HDD amount may vary,		
	When HDD is working properly, system is shown as O "_" means there is no HDD.		
SN	You can view the HDD amount the device connected to;		
	* means the second HDD is current working HDD.		
Туре	The corresponding HDD property.		
Total space The HDD total capacity.			
Free space	The HDD free capacity.		
Status HDD can work properly or not.			
Bad track	Display there is bad track or not.		
Page up	Click it to view previous page.		
Page down	Click it to view the next page.		
View recording time	Click it to view HDD record information (file start time and end time).		
View HDD type and capability	Click it to view HDD property, status and etc,		

# 4.9.7 HDD Group

It is to set HDD group, and HDD group setup for main stream, sub stream and snapshot operation.



When you are setting HDD group, please set a HDD for each channel, otherwise NVR cannot save current setup.

The main stream is shown as in Figure 4-196.

- HDD: Here you can view the HDD amount the device can support.
- Group: It lists the HDD Group number of current hard disk.

	SETTING
STAMERA	TRANSPORT TRANSPORT
BASIC SCHEDULE HDD MANAGE FTP	Main Stream       Sub Stream       Snapshot         Set All Channels       •       •       All         CH       HDD Group       CH       HDD Group       CH       HDD Group
RECORD ADVANCED HDD DETECT	CH HDD Group CH HDD Group CH HDD Group CH HDD Group D1 • D2 • D3 • D4 • • D5 • D6 • D7 • D8 • •
	OK Cancel Apply

Figure 4-196

Please select the correspond group from the dropdown list and then click Apply button. Click sub stream/snapshot button to set corresponding HDD group information.

# 4.9.8 HDD Detect

# Note

This function is for some series product only.

The HDD detect function is to detect HDD current status so that you can clearly understand the HDD performance and replace the malfunction HDD.

There are two detect types:

- Quick detect is to detect via the universal system files. System can quickly complete the HDD scan. If you want to use this function, please make sure the HDD is in use now. If the HDD is removed from other device, please make sure the write-data once was full after it installed on current device.
- Global detect adopts Windows mode to scan. It may take a long time and may affect the HDD

that is recording.

# 4.9.8.1 Manual Detect

From main menu->Setting->Storage->HDD Detect->Manual Detect, the interface is shown as below. See Figure 4-197.

Please select detect type and HDD. Click start detect to begin. You can view the corresponding detect information.



Figure 4-197

# 4.9.8.2 Detect Report

After the detect operation, you can go to the detect report to view corresponding information.

From main menu->Setting->Storage->HDD Detect->Manual Detect, the interface is shown as below. See Figure 4-198.



Figure 4-198

Click View, you can see the detailed information such as detect result, backup and S.M.A.R.T. See Figure 4-199 and Figure 4-200.

	Details		
Detect Results S.M.A.R.T			
Type Quick Detect  Backup to USB Devices			
		<ul> <li>Good </li> <li>Bad</li> <li>\$29 MB</li> </ul>	Block
	C	Detected HDD No.	1
	7	Fotal Space	1863.02 GB
	E	Error	0
	+	HDD Port No.	1
			_

Figure 4-199

<sup>&gt;</sup> ort Modle	main board-1 ST2000VX007-2AY102				
Serial I	No. W9800B3Q				
Status	ОК				
Descri	be:				
Smart	ID Attribute	Thresh	nold Value	Worst Value	5
1	Read Error Rate	6	100	64	C
3	Spin Up Time	0	98	98	C
4	Start/Stop Count	20	100	100	C
5	Reallocated Sector Count	10	100	100	C
7	Seek Error Rate	30	72	60	C
9	Power On Hours Count	0	100	100	
10	Spin-up Retry Count	97	100	100	C
12	Power On/Off Count	20	100	100	C
183	Runtime Bad Block	0	100	100	C
184	End-to-End Error	99	100	100	C
187	Reported Uncorrect	0	100	100	¢,
•					



# 4.9.9 RAID Manager

RAID (redundant array of independent disks) is a data storage virtualization technology that combines multiple physical HDD components into a single logical unit for the purposes of data redundancy, performance improvement, or both.

# Note

- RAID function is for some series product only. Slight difference may be found on the user interface.
- Right now, NVR supports RAID0, RAID1, RAID5, RAID6, and RAID 10. Local hotspare supports RAID1, RAID5, RAID6, and RAID10.
- Refer to the following table for detailed information.

RAID Type	HDD Amount
RAID0	At least 2 HDDs.
RAID1	Only 2 HDDs.
RAID5	At least 3 HDDs. Usually recommend the RAID5 consists of 4 to 6 HDDs.
RAID6	At least 4 HDDs.
RAID10	At least 4 HDDs.

# 4.9.9.1 RAID Config

It is for you to manage RAID HDD. It can display RAID name, type, free space, total space, status and etc. Here you can add/delete RAID HDD.

Click Add button to select RAID type and then select HDDs, click OK button to add. See Figure 4-201.

### One click to create RAID

- Click it to automatically create RAID5.
- For create RAID function, you can select the physical HDD that does not included in the RAID group or the created disk array to create a RAID5. You can refer to the following situations:
- There is no RAID, no hotspare disk: System directly creates the RAID5 and creates one hotspare disk at the same time.
- There is no RAID, but there is a hotspare disk: System creates the RAID5 only. It uses previous hotspare disk.
- There is RAID: System cancel the previous RAID setup and then create the new RAID5. System creates the hotspare disk if there is no one. System uses previous hotspare disk if there is hotspare disk available.
- The background will format the virtual disk.

### **Create manually**

- Step 1 Select RAID type first and then follow the prompts to set HDD amount.
- Step 2 Click Create Manually button, system pops up dialogue box to warning you it is going to clear all data.
- Step 3 Click OK button to complete the operation.



Figure 4-201

## 4.9.9.2 Hotspare disks

When a HDD of the RAID group is malfunction or abnormal, the hotspare HDD can replace the malfunction or abnormal HDD in case there is any data loss. It is to guarantee storage system reliability. Click Hotspare disks tab name, you can add the hot spare HDD. See Figure 4-202. The type includes two options:

- Global: It is global hotspare disk. When any RAID becomes degrading, it can replace and build the RAID.
- Local: It is local hotspare disk. When the specified RAID becomes degrading, it can replace and build the RAID.

Select a hot spare device and then click Delete button. Click Apply button to delete.

			SETTING				
🗓 CAMERA		👼 E'	VENT	STORAGE		SYSTEM	
SCHEDULE HDD MANAGER RECORD ADVANCE RAID MANAGER	Raid Config New Hots Type Globa Sub disk Disk5	Dare	Physical SATA-5				
	O Delete Ho	Ispare	Capacity	Raid name	Type ) Cance	a) (Appi	

Figure 4-202

# 4.10 Device Maintenance and Manager

#### 4.10.1 Account

It is to manage users, user group and ONVIF user, set admin security questions.



- For the user name, the string max length is 31-byte, and for the user group, the string max length is 15-byte. The user name can only contain English letters, numbers and "\_", "@", ".".
- The default user amount is 64 and the default group amount is 20. System account adopts two-level management: group and user. The user authorities shall be smaller than group authorities (The **admin** user authorities are set by default).
- For group or user management, there are two levels: admin and user. The user name shall be unique and one user shall only belong to one group.

#### 4.10.1.1 User

4.10.1.1.1 Add User

Step 1 From main menu->Setting->System->Account->User. Enter user interface. See Figure 4-203.

	SETTING
SAMERA	TRANSPORT TRANSPORT
GENERAL DISPLAY	User Group Secure Ques ONVIF User
VOICE PROMPT	1 User Group Name Modify Delete Memo
ACCOUNT	1 admin admin 🦯 🗙 admin 's account
IMP/EXP	
DEFAULT	
UPGRADE	
	Add User

Figure 4-203

Step 2 Click Add user button in Figure 4-203. The interface is shown as in Figure 4-204.

	Add User
User Name Password Memo Group admin Period Setting Authority	Confirm Password
	NT 🔽 NETWORK 🔽 CAMERA
	Save Cancel

# Figure 4-204

Step 3 Input the user name, password, select the group it belongs to from the dropdown list. Then you

can check the corresponding rights for current user.

# Note

For convenient user management, usually we recommend the general user right is lower than the admin account.

Step 4 Click the Set button after the period, you can set valid period to use current account. See Figure 4-205.





- Step 5 Click Set button, you can set six periods in one day. See Figure 4-206.
- Step 6 Check the box after the period, you can enable current setup.

# Note

Check the box before the week; it is to save period settings to selected week day.

	Period
Current Date: Sunday	
Period 1 (00 : 00 - 24 : 00 )	
Period 2 (00 : 00 - 24 : 00	
Period 3 (00 : 00 - 24 : 00	
Period 4 (00 : 00 - 24 : 00	
Period 5 (00 : 00 - 24 : 00	
Period 6 (00 : 00 - 24 : 00	
Copy	
	esday 🗋 Wednesday 🗍 Thursday 🗍 Friday 🗍 Saturday
	OK

Figure 4-206

Step 7 Click OK button.

# 4.10.1.1.2 Modify user

From main menu->Setting->System->Account->User, click //, you can go to the following interface to change user information. See Figure 4-207.

	Modify User
User Name 1	User MAC
Modify Password  Old Password New Password	Group (admin ) Memo
Confirm Password Confir	
System Playback Monitor	
<ul> <li>✓ AII</li> <li>✓ ACCOUNT</li> <li>✓ SYSTEM</li> <li>✓ STORAGE</li> <li>✓ EVENT</li> <li>✓ SECURITY</li> <li>✓ BACKUP</li> </ul>	<ul> <li>✓ SYSTEM INFO</li> <li>✓ MANUAL CONT</li> <li>✓ NETWORK</li> <li>✓ CAMERA</li> <li>✓ DEVICE MAINT</li> </ul>
	Save Cancel

#### Figure 4-207

For **admin** user, you can change the email, enable/disable unlock pattern, change password prompt question, set security questions. See Figure 4-208.

		Modify User
User Name (admi	n 🔻	User MAC
Modify Password 📃		Email Address
Old Password		Group (admin 🔻
New Password		Memo (admin 's account )
Confirm Password		🗹 Unlock Pattern 🛛 🛱
Prompt Question (c111	1111	Security Questions
Authority		
System Playba	ack Monitor	
	SYSTEM	SYSTEM INFO MANUAL CONT
	VENT	
	BACKUP	
		Save Cancel

Figure 4-208

- Input email information and then click Save, it is to set/change email address.
- Check the box to enable unlock pattern and then click , click Save to change unlock pattern.
- Set security question

Step 1 Click Security question, enter the following interface. See Figure 4-209.

	Security Questions
Successfully	v set. Please delete it first if you want to reset security question again.
Question 1	(What is your favorite children's book?
Answer	
Question 2	(What was the first name of your first boss?
Answer	
Question 3	(What is the name of your favorite fruit?
Answer	
	Setting Delete

Figure 4-209

Step 2 Input answers and then click Save button.

After successfully set security questions, you can answer the security questions to reset admin password.



Select security questions from the dropdown list and then input the proper answers, click Delete button to reset security questions and answers again.

#### 4.10.1.1.3 Change Password

In Figure 4-207, check the Modify password box, you can change password. Please input old password, and then input new password twice to confirm.

• Password/confirm password: The password ranges from 8 to 32 digitals. It can contain letters, numbers and special characters (excluding "!", "!", ";", "&"). The password shall contain at least two categories. Usually we recommend the strong password.



STRONG PASSWORD RECOMMENDED-For your device own safety, please create a strong password of your own choosing. We also recommend you change your password periodically especially in the high security system.

#### 4.10.1.2 Modify Group

Step 1 From main menu->Setting->System->Account->Group. Enter add group interface. See Figure 4-210.

SETTING						
😋 CAMERA		K 🔂 EVENT	STORAGE	SYSTEM		
GENERAL DISPLAY	User	Group	ONVIF User			
VIDEO MATRIX RS232 PTZ POS VOICE ACCOUNT SECURITY AUTO MAINTAIN IMP/EXP DEFAULT UPGRADE	1 ad 2 us		Delete Memo	gronb		
	(Add Group	<u></u>				

Figure 4-210

- Step 2 Click add group button in Figure 4-210. Enter Add group the interface. See Figure 4-211.
- Step 3 Input group name and then input some memo information if necessary. Check the box to select authorities.

Group Name	_	_		Add Group	
System       Playback       Monitor         All	*				
AII AII ACCOUNT SYSTEM SYSTEM SYSTEM INFO MANUAL CONT STORAGE EVENT NETWORK CAMERA	Authority				
ACCOUNT     SYSTEM     SYSTEM INFO     MANUAL CONT       STORAGE     EVENT     NETWORK     CAMERA	System	Playback	Monitor		
	ACC	RAGE			

Figure 4-211

# 4.10.1.3 Security Question

# Note

# This function is for **admin** user only.

Here you can change security questions. After you successfully answered security questions, you can reset admin account password.

From main menu->Setting->System->Account->Security question, the interface is shown as below. See Figure 4-212. Input correct security answers and then click Delete button at the bottom of the interface, you can reset security questions and answers.

SETTING						
	💏 NETWORK		STORAC	GE	SYSTEM	
GENERAL DISPLAY VIDEO MATRIX RS232 PTZ POS VOICE ACCOUNT AUTO MAINTAIN IMP/EXP DEFAULT UPGRADE	User Please set a sect	Group urity question so t at's your favorite p	Secure Question hat you can find the p bet?	ONVIF	User	
				C	Set Delet	

Figure 4-212

# 4.10.1.4 ONVIF User

When the camera from the third party is connected with the NVRvia the ONVIF user, please use the verified ONVIF account to connect to the DVR. Here you can add/delete/modify user

# D Note

The default ONVIF user is **admin**. It is created after you initialize the DVR.

Step 1 From main menu->Setting->System->Account->ONVIF User. Enter ONVIF interface. See Figure 4-213.
	_	SETI	ING	_	_	_
R CAMERA	葥 NETWORK		STORAG	ie 📑 🧕 S	YSTEM	
GENERAL DISPLAY	User	Group	Secure Question	ONVIF User		
VIDEO MATRIX RS232 PTZ POS VOICE ACCOUNT AUTO MAINTAIN IMP/EXP DEFAULT UPGRADE		User Name admin	Group Name admin	Modify	Delete ×	
	(Add User)					

Figure 4-213

Step 2 Click Add User button.

Enter Add User interface. See the following figure.

Add User
User 123 Password Confirm Password Group admin
Save Cancel

Figure 4-214

Step 3 Set user name, password and then select group from the dropdown list.Step 4 Click Save to complete setup.

D Note



### 4.10.1.5 Online User

Here is for you manage online users connected to your NVR. See Figure 4-215.

You can click button **I** to disconnect or block one user if you have proper system right.

System detects there is any newly added or deleted user in each five seconds and refresh the list automatically.



Figure 4-215

### 4.10.2 System Info

4.10.2.1 Version

From main menu->Info->System->version, you can go to version interface.

It is to view NVR version information. Slight different may be found on the user interface. 4.10.2.2 BPS

Here is for you to view current video bit rate (kb/s) and resolution. See Figure 4-216.

			INFO				
SYSTEM	📆 EVENT				LOG		
HDD	Channel	Kb/S	Resolution	Wave			
RECORD	D8	4065	1920*1080	h			
BPS	D11	6562	1920*1080	h			
VERSION	D13	4245	1920*1080	h			
	D14	2276	800*480	Ъ.			
	D15	0		1			
	D17	0		1			
	D18	0	0*0	1			
	D19	0		1			
	D20	0		1			
	D21	0		1			
	D22	0		1			
	D23	0		1			
	D24	0		1			

Figure 4-216

### 4.10.2.3 Event Information

#### 4.10.2.3.1 Alarm Status

From main menu->info-Event, here you can view the channel status of the remote device, connection log and etc. See Figure 4-217.

	INFO	
SYSTEM	EVENT SNETWORK 📡 LOG	
ALARM STATUS PEOPLE COUN HEAT MAP	Device Status Device(NIC No 1 HDD No 1)	
	Channel Status Channel(CH:24,External Alarm:16) External Alarm Video Loss Tampering Motion Detection IPC External Alarm IPC Offline Alarm D18 D23	

Figure 4-217

### 4.10.2.3.2 People Counting

This function allows system to detect the people flow amount in the specified zone and display the people amount statistics image.

From main menu->Info->Event->People Counting, you can go to the following interface. See Figure 4-218.

Channel: Please select a channel from the dropdown list.

- Type: Please select report type from the dropdown list. It includes daily report/monthly report/annual report. You can click to select histogram or polygon chart.
- Start time/end time: Input start time and end time of the people counting.
- Enter: Check to search enter amount.
- Exit: Check the box to search exit amount.
- Display No.: Check the box, system can display enter and exit people amount in the report.

	INFO
SYSTEM	
ALARM STATUS PEOPLE COUN HEAT MAP	Channel       D8         Type       Daily Report       * Daily report max range is 24 hours.         Start Time       2017 - 04 - 20       00 : 00 : 00         End Time       2017 - 04 - 21       00 : 00 : 00         Search       Export
	People Counting Stati Histogram/ Polygon People No. People No. 10 6 4 2 0 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20 21 22 23 Hour

Figure 4-218

4.10.2.3.3 Heat Map

It is to search and view the heat map of each channel.

From main menu->Info->Event->Heat Map, you can go to the following interface. See Figure 4-219. Select a channel, input start time and end time. Please note the report search period shall be within one month.

Click Search button, you can view the heat map report.

	INFO
SYSTEM	
ALARM STATUS PEOPLE COUN HEAT MAP	Channel D Start Time 2017 - 04 - 01 00 : 00 : 00 The report search pe Search Export Heat Map

Figure 4-219

### 4.10.3 Voice

The audio function is to manage audio files and set schedule play function. It is to realize audio broadcast activation function.

### Note Note

This function is for some series product only.

### 4.10.3.1 File Manage

Here you can add audio file, listen to the audio file, or rename/delete audio file. Here you can also set audio volume. See Figure 4-220.

	SETTING	G			
S CAMERA	🐞 NETWORK 🛛 📷 EVENT	STORAGE		SETTING	
CAMERA GENERAL DISPLAY RS232 PTZ VOICE ACCOUNT AUTO MAINTAIN IMP/EXP DEFAULT UPGRADE	File Manage       Schedule         6       File Name         1       brother.mp3         2       abc.mp3         3       sister.mp3         4       12345.mp3         5       %%%%mp3         6       d4\$=.mp3	STORAGE Size 2.80 MB 4.42 MB 3.91 MB 6.11 MB 4.94 MB 9.44 MB	Play Play Play Play	Rename	
	File size: 10K-10MB. Max file am	ount:255.	~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~	′olume	Add

Figure 4-220

Click Add button, you can add audio file and import the audio file via the USB device. The audio file format shall be MP3 or PCM. See Figure 4-221.

### Note

The file size shall be 2K-10MB.

Device Name (sdc1(USB DISK) 🔻	Refresh			
Total Space (15.14 GB	Free Space	(13.10 GB		
Address (/				
Name		Size	Туре	Del
🗆 🔚 NVR			Folder	×
🔄 📑 asfsadfsd.mp3		4.42 MB	File	×
🔄 📑 dgfdsgsdg.mp3		4.42 MB	File	×
🗖 📑 sfdsdfsd.mp3		3.91 MB	File	×
🔁 📑 fdsfsdgsdg.mp3		6.11 MB	File	×
🔁 📑 sdgsdgqwq41234.mp3		4.94 MB	File	×
2312132455.mp3		9.44 MB	File	×
🗌 📑 1234.mp3		2.80 MB	File	×
			N	
			×	;



It is to set schedule broadcast function. You can play the different audio files in the specified periods. See Figure 4-222.

		SETTIN	IG	_		
😽 CAMERA	📻 NETWORK	To EVENT	[ <mark>]</mark> ,sто	RAGE	SETTI	NG
CAMERA GENERAL DISPLAY RS232 PTZ VOICE ACCOUNT AUTO MAINTAIN IMP/EXP DEFAULT UPGRADE		Schedule	Name	RAGE Interval 60 min. 60 min. 60 min. 60 min. 60 min.	Repeat 0 0 0	NG Output (Mic *) (Mic *) (Mic *) (Mic *) (Mic *)
				ж) с	ancel )	Apply

Figure 4-222

#### 4.10.4 RS232

After setting RS232 parameters, the NVR can use the COM port to connect to other device to debug and operate.

From Main menu->Setting->System->RS232, RS232 interface is shown as below. There are five items. See Figure 4-223.

- Function: There are various devices for you to select.
  - ♦ Console is for you to use the COM or mini-end software to upgrade or debug the program.
  - ♦ Control keyboard is for you to control the device via the special keyboard.
  - ♦ Transparent COM (adapter) is to connect to the PC to transfer data directly.
  - ♦ Protocol COM is for card overlay function.
  - ♦ Network keyboard is for you to use the special keyboard to control the device.
  - ♦ PTZ matrix is to connect to the peripheral matrix control.

## Note

Different series products support different RS232 functions. Please refer to the actual product for detailed information.

- Baud rate: You can select proper baud rate.
- Data bit: You can select proper data bit. The value ranges from 5 to 8.
- Stop bit: There are three values: 1/1.5/2.
- Parity: there are five choices: none/odd/even/space mark.
- System default setup is:
- Function: Console

- Baud rate:115200
- Data bit:8
- Stop bit:1
- Parity: None

After completing all the setups please click save button, system goes back to the previous menu.

	SETTING	
😪 CAMERA	👼 NETWORK 🛛 📷 EVENT	STORAGE 🛃 SYSTEM
GENERAL DISPLAY RS232 PTZ POS BROADCAST VOICE PROMPT ACCOUNT AUTO MAINTAIN IMP/EXP DEFAULT UPGRADE	Function Console   Baud Rate 115200   Data Bit 8   Stop Bit 1   Parity None	
	Default	OK Cancel Apply

Figure 4-223

#### 4.10.5 Broadcast

It is to broadcast to the camera, or broadcast to a channel group.

Step 1 From Mani menu->Setting->System->Broadcast. Enter the following interface. See Figure 4-224.

	SETTING			
😋 CAMERA	👼 NETWORK 🛛 📷 EVENT	STORAGE	SYSTEM	
GENERAL DISPLAY RS232 PTZ POS BROADCAST VOICE PROMPT ACCOUNT AUTO MAINTAIN IMP/EXP DEFAULT UPGRADE	0 Group Name Memo	Modify	Del	

Figure 4-224

Step 2 Click Add group.

Enter add group interface. See Figure 4-225.

				Add G	iroup				
G	roup Name(								
	Channel		D3	🗖 D4	D5	D6	D7	D8	
	D9	D10	D11	D12	D13	D14	D15	D16	
	D17	D18	D19	D20	D21	D22	D23	D24	
	0	)	0	0	)	)	0	<u> </u>	
				Save	Cance				

Figure 4-225

Step 3 Input group name and select one or more channels.

Step 4 Click Save button to complete broadcast group setup.



After complete broadcast setup, on the preview interface and then click in the navigation

bar, device pops up broadcast diaologue box. Select a group name and then click [\_\_\_\_\_\_ to begin broadcast. See Figure 4-226.

	SETTING			
CAMERA	To EVENT	STORAGE	SYSTEM	
GENERAL DISPLAY RS232 PTZ POS BROADCAST VOICE PROMPT ACCOUNT AUTO MAINTAIN IMP/EXP DEFAULT UPGRADE	Vame Memo Channel D1 D2	Modify	Del X	

Figure 4-226

### 4.10.6 Security

#### 4.10.6.1 IP Filter

IP filter interface is shown as in Figure 4-227. You can add IP in the following list. The list supports max 64 IP addresses. System supports valid address of IPv4 and IPv6. Please note system needs to check the validity of all IPv6 addresses and implement optimization.

After you enabled trusted sites function, only the IP listed below can access current NVR.

If you enable blocked sites function, the following listed IP addresses cannot access current NVR.

- Enable: Highlight the box here, you can check the trusted site function and blocked sites function. You cannot see these two modes if the Enable button is grey.
- Type: You can select trusted site and blacklist from the dropdown list. You can view the IP address on the following column.
- Start address/end address: Select one type from the dropdown list, you can input IP address in the start address and end address. Now you can click Add IP address or Add IP section to add.
  - a) For the newly added IP address, it is in enable status by default. Remove the  $\sqrt{}$  before the item,

and then current item is not in the list.

- b) System max supports 64 items.
- c) Address column supports IPv4 or IPv6 format. If it is IPv6 address, system can optimize it. For example, system can optimize aa:0000: 00: 00aa: 00aa: 00aa: 00aa: 00aa as aa:: aa: aa: aa: aa: aa: aa: aa.
- d) System automatically removes space if there is any space before or after the newly added IP address.
- e) System only checks start address if you add IP address. System check start address and end address if you add IP section and the end address shall be larger than the start address.
- f) System may check newly added IP address exists or not. System does not add if input IP address does not exist.
- Delete: Click it to remove specified item.
- Edit: Click it to edit start address and end address. See Figure 4-228. System can check the IP address validity after the edit operation and implement IPv6 optimization.
- Default: Click it to restore default setup. In this case, the trusted sites and blocked sites are both null.

### D Note

- If you enabled trusted sites, only the IP in the trusted sites list can access the device.
- If you enabled blocked sites, the IP in the blocked sites cannot access the device.
- System supports add MAC address.

		SETTING		
STAMERA		To EVENT	STORAGE	SYSTEM
GENERAL DISPLAY RS232		sted Sites O Blocked S	Sites	
BROADCAST VOICE PROMPT ACCOUNT SECURITY AUTO MAINTE IMP/EXP DEFAULT UPGRADE	Start Address Add	End Address		Edit Delete
	Default		ОК	Cancel Apply

Figure 4-227

Edit
Start Address 10.15.6.140 123 End Address 10.15.6.145
OK Cancel

Figure 4-228

#### 4.10.6.2 System Service

The device supports to enable and disable various system internal services.

Step 1 From main menu->System->Security ->System Service. The System Service interface is displayed. See Figure 4-229.

	SETTING
N CAMERA	TNETWORK 📷 EVENT STORAGE SYSTEM
GENERAL DISPLAY RS232 BROADCAST VOICE PROMPT ACCOUNT SECURITY AUTO MAINTE IMP/EXP DEFAULT UPGRADE	IP FILTER       System Service
	Default OK Cancel Apply

Figure 4-229

Step 2 Configure the parameters. For details, see the below table.

Parameter	Description	
Password Reset	Enabled by default.	
	If it is disabled, the user can only use the security questions to reset	
	the password.	
Mobile Phone Push	Enabled by default.	
	The snapped pictures triggered at the device can be push to the	
	mobile app.	
CGI	Enabled by default.	
	The device can be connected via this protocol when enabled.	
ONVIF	Enabled by default.	

Parameter	Description
	The device can be connected via this protocol when enabled.
Audio/VideoEncryption	The stream transmission is encrypted when this function is enabled. The associated device or software shall support decryption.

Step 3 Click OK to complete the configuration.

#### 4.10.7 Auto Maintain

Here you can set auto-reboot time and auto-delete old files setup. You can set to delete the files for the specified days. See Figure 4-230.

You can select proper setup from dropdown list.

After all the setups please click save button, system goes back to the previous menu.

		SETTING		
🏹 CAMERA		📷 EVENT	STORAGE	SYSTEM
GENERAL DISPLAY VIDEO MATRIX RS232 PTZ ATM/POS ACCOUNT AUTO MAINTAIN IMP/EXP DEFAULT UPGRADE	Auto-Reboot Sys Tuesday Auto-Delete Old Customized	) at (02:00AM) Files	Day(s) Ago	
			OK	Cancel Apply

Figure 4-230

#### 4.10.8 Backup

4.10.8.1 File Backup

In this interface, you can backup record file to the USB device.

- a) Connect USB burner, USB device or portable HDD and etc to the device.
- b) From Main menu->Backup, you can go to the Backup interface. See Figure 4-231

BACKUP	
Device Nan (sdc1(USB DISK))	
0.00 KB(Space Needed) 13.78 GB/15.00 GB(Free/Total)	
Type	
Start Time 🔞 2013 - 10 - 18 00 : 00 : 00 Record CH 1	
End Time (0 2013 - 10 - 18 12 : 11 : 34 ) File Format (DAV ) Add (Remove)	
0 Channel Type Start Time End Time Size(KB)	
<b>`</b>	
Start	

Figure 4-231

- c) Select backup device and then set channel, file start time and end time.
- d) Click add button, system begins search. All matched files are listed below. System automatically calculates the capacity needed and remained. See Figure 4-232.
- e) System only backup files with a  $\sqrt{}$  before channel name. You can use Fn or cancel button to delete  $\sqrt{}$  after file serial number.
- f) Click backup button, you can backup selected files. There is a process bar for you reference.
- g) When the system completes backup, you can see a dialogue box prompting successful backup.

Type Start Tir	A) ne 💽		·	) Record CH (1			
End Tin	ne 💽	2013 - 10 - 1	18 12:11:34	File Format		Add Rev	nove
43	Cł	annel Type	Start Time	End Time	Size(KB		4
1	<b>∠</b> 1	R	13-10-14 22:00:00	13-10-14 23:00:00	48176		
2	<b>∠</b> 1	R	13-10-14 23:00:00	13-10-15 00:00:00	48037		
3	<b>∠</b> 1	R	13-10-15 00:00:00	13-10-15 00:28:50	22528		
4	<b>∠</b> 1	R	13-10-15 00:28:50	13-10-15 01:00:00	24668	~	
5	<b>∠</b> 1	R	13-10-15 01:00:00	13-10-15 02:00:00	46815		
6	<b>∠</b> 1	R	13-10-15 02:00:00	13-10-15 03:00:00	47802		
7	∠ 1	R	13-10-15 03:00:00	13-10-15 04:00:00	47566		
8	<b>∠</b> 1	R	13-10-15 04:00:00	13-10-15 05:00:00	47468		
9	<b>∠</b> 1	R	13-10-15 05:00:00	13-10-15 06:00:00	47358		
10	<b>∠</b> 1	R	13-10-15 06:00:00	13-10-15 07:00:00	47773		
11	<b>∠</b> 1	R	13-10-15 07:00:00	13-10-15 08:00:00	47229		
12	<b>∠</b> 1	R	13-10-15 08:00:00	13-10-15 09:00:00	47865		
13	<b>∠</b> 1	R	13-10-15 09:00:00	13-10-15 09:03:02	2780		
<u>11</u>	<b>1</b>	D	12 10 15 00.05.55	12 10 15 00-57-22	10060		
						( s	tart

Figure 4-232

h) Click backup button, system begins burning. At the same time, the backup button becomes stop button. You can view the remaining time and process bar at the left bottom.

### D Note

- During backup process, you can click ESC to exit current interface for other operation (For some series product only). The system will not terminate backup process.
- The file name format usually is: Channel number+Record type+Time. In the file name, the YDM format is Y+M+D+H+M+S. File extension name is .dav.

#### 4.10.8.2 Import/Export

This function allows you to copy current system configuration to other devices. It also supports import, create new folder, and delete folder and etc function.

From Main menu->Setting->System->Import/Export, you can see the configuration file backup interface is shown as below. See Figure 4-233.

		SETTING			
🗓 CAMERA		To EVENT		SYSTEM	
GENERAL DISPLAY RS232 PTZ ACCOUNT AUTO MAINTAIN IMP/EXP DEFAULT UPDATE	Device Name Total Space Address Name English English English E camera Camera	(sdc1(USB DISK))) (15.00 GB (/ 09 Format Import	Refresh Free Space 11	3.42 GB	Type Folder Folder Folder Folder Folder



- Export: Please connect the peripheral device first and then go to the following interface. Click Export button, you can see there is a corresponding "Config\_Time" folder. Double click the folder, you can view some backup files.
- Import: Here you can import the configuration files from the peripheral device to current device. You
  need to select a folder first. You can see a dialogue box asking you to select a folder if you are
  selecting a file. System pops up a dialogue box if there is no configuration file under current folder.
  After successfully import, system needs to reboot to activate new setup.
- Format: Click Format button, system pops up a dialogue box for you to confirm current operation. System begins format process after you click the OK button.

### Note

- System cannot open config backup interface again if there is backup operation in the process.
- System refreshes device when you go to the config backup every time and set current directory as the root directory of the peripheral device.
- If you go to the configuration backup interface first and then insert the peripheral device, please click Refresh button to see the newly added device.

### 4.10.8.3 Backup Log

a) From Main menu->Info->Log, the interface is shown as below. See Figure 4-234.

	INFO	
SYSTEM		
LOG		
	Start Time 2013 - 11 - 07 00 : 00 : 00	
	End Time 2013 - 11 - 08 00 : 00 : 00	
	Types (All )	
	19 Time Event Play Details	
	6 2013-11-07 18:01:01 Channel12 User logged in 📰	
	7 2013-11-07 18:01:01 Channel 4 User logged in 📰	
	8 2013-11-07 18:01:01 Channel 5 User logged in. 🗕 😑	
	9 2013-11-07 18:01:01 Channel 6 User logged in. 🗕 😑	
	10 2013-11-07 18:01:01 Channel 7 User logged in. 🗕 😑	
	11 2013-11-07 18:01:01 Channel 8 User logged in 😑	
	12 2013-11-07 18:01:20 Channel 9 User logged in 😑	
	13 2013-11-07 18:01:20 Channel13 User logged in 🗮	
	14 2013-11-07 18:01:20 Channel 2 User logged in 🗮	
	15 2013-11-07 18:01:20 Channel 3 User logged in 🗮	
	16 2013-11-07 20:13:01 User logged in. <10.15.6.122> 🧮	
	17 2013-11-07 20:13:01 User logged in. <10.15.6.122> 🧮	
	18 2013-11-07 20:14:01 User logged out. <admin> 🗮</admin>	
	19 2013-11-07 20:14:01 User logged out. <admin> 📰 🔻</admin>	
	PgUp         PgDn         1/1(Current Page/Total Page)         Go To         1         Page(s	
	Backup Clear	



b) Select log type and then set start time/end time, click Search button, you can see log time and event information. Click III to view detailed log information.

c) Select log items you want to save and then click backup button, you can select a folder to save them. Click Start to backup and you can see the corresponding dialogue box after the process is finish.

#### 4.10.8.4 USB Device Auto Pop-up

After you inserted the USB device, system can auto detect it and pop up the following dialogue box. It allows you to conveniently backup file, log, configuration or update system. See Figure 4-235. Please refer to chapter 4.10.8.1 file backup, chapter 4.10.8.3 backup log, chapter 4.10.8.2 import/export, and chapter 4.6.2 search for detailed information.

	Find USB device
Name: <sup>1</sup> Capacit	sdb1(USB DISK) y: 14.05 GB/15.00 GB(Free/Total)
File Backu Config Back	

Figure 4-235

### 4.10.9 Default



After you use default function, some your customized setup may lose forever! Please think twice before you begin the operation!

You can restore factory default setup to fix some problems when the device is running slowly. Configuration error occurred.

From Main menu->Setting->System->Default, you can go to the default interface. See Figure 4-236.

Check an item you want to restore default setup, or check the All to select all items.

Click OK or apply button, system pops up a dialogue box. Click OK to restore.

		SETTING		
📆 CAMERA		Tage EVENT	STORAGE	SYSTEM
GENERAL DISPLAY RS232 PTZ ACCOUNT AUTO MAINTAIN IMP/EXP DEFAULT UPDATE	Default All CAMERA NETWORK EVENT STORAGE SYSTEM		OK	) Cancel Apply

Figure 4-236

### 4.10.10 Upgrade

4.10.10.1 File Update

From Mani menu->Setting->Info->Update, you can go to the following interface. See Figure 4-237.

- Step 1 Insert USB device that contain the upgrade file.
- Step 2 Click Start button and then select the .bin file.
- Step 3 You can see the corresponding dialogue box after the update process is complete.



Figure 4-237

### 4.10.10.2 Online Upgrade

When the NVR is online, you can use the online upgrade to update the firmware.

Before the online upgrade, system needs to detect if any new version is available. It includes auto check and manual check.

- Auto check: System automatically detects if any new version is available once in a while.
- Manual check: Detect new version at real time.

# 

During the upgrade process, make sure that the network connection and power supply are normal. Step 1 Enter from main menu > Setup > System > Upgrade.

The Upgrade interface is displayed. See Figure 4-238.



Figure 4-238

Step 2 Version check.

• Auto check: Select the Auto check for updates check box and click Save.

### D Note

System enables this function by default.

- Manual check: Click Manual Check.
   System starts to search new version and displays the result after the check is completed.
- When system displays that it is the latest version, the current version is the latest one and you do not need to upgrade it.
- When system displays the new version information (including release date and upgrade notes), new version is available and go to Step 3.

Step 3 Click Upgrade to upgrade the system.

4.10.10.3 Uboot

When NVR boots up, during the uboot process, NVR automatically detects there is USB device and there is upgrade file on the USB device or not. If the detection result is OK, NVR automatically begins upgrade.



- The USB device shall contain two files: u-boot.bin.img and update.img.
- The USB device shall connected to the USB port at the front panel. Otherwise, NVR cannot properly
  detect the file or upgrade.

### 4.11 Logout /Shutdown/Restart

From Mani menu->Operation->Shutdown, you can see an interface shown as in Figure 4-239.

- Shutdown: System shuts down and turns off power.
- Logout: Log out menu. You need to input password when you login the next time.
- Restart: reboot device.

If you shut down the device, there is a process bar for your reference, system waits for 3 seconds and then shut down (You cannot cancel).

Please note, sometimes you need to input the proper password to shut down the device.



Figure 4-239

### 5 Web Operation

### 5.1 General Introduction

If it is your first time to login the device, please initialize your device first. Refer to chapter 5.2 Device Initialization for detailed information.

The device web provides channel monitor menu tree, search, alarm setup, system setup, PTZ control and monitor window and etc.

### Note

- Slight difference may be found on user interface. Please refer to the actual product for detailed information.
- Device supports various browsers such as Safari, Chrome and etc.
- Use ChromeApp to login the WEB if the Chrome version is 45 or higher. Go to the Chrome online store to download the ChromeApp installation package.

### 5.1.1 Preparation

- Step 1 PC and NVR connection is OK.
- Step 2 Set PC IP address, NVR IP address, subnet mask and gateway.
  - Set the IP address of the same section for the PC and NVR. Input corresponding gateway and subnet mask if there are routers.)
  - The device default IP address is 192.168.1.108.
- Step 3 Check the PC and device connection is OK or not. Refer to the following two ways to check the network connection is OK or not. When the PC and device network connection is OK, login the WEB via the PC.
  - On PC, use order ping \*\*\*.\*\*\*.\*\*\*(NVR IP address) to check connection is OK or not. Login Usually the TTL value is 255.
  - Login the device local menu, from setting->Network->Network test and then input PC IP address. Check the connection is OK or not.
- Step 4 Login the WEB. Refer to chapter 5.10 Login for detailed information.

### 5.2 Device Initialization

If it is your first time to use the device, please set a login password of **admin** (system default user).

### D Note

For your device safety, please keep your login password of **admin** well after the initialization steps, and change the password regularly.

Please follow the steps listed below.

- Step 1 Open the IE and then input the NVR IP address in the address column.
- Step 2 Click Enter button.

Device displays device initialization interface. See Figure 5-1.

Device Initialization          Image: Device Initialization       2       Password Protection 3       Successful         Username       admin         New Password       Image: Device Initialization         Low       Middle       High         It is 8 to 32-digit containing letter(s), number       (s), symbol(s). It contains at least two types.         Confirm Password       Image: Device Initialization	
1 Enter Password 2	Password Protection 3 Successful
New Password	Low Middle High It is 8 to 32-digit containing letter(s), number
	Next

Figure 5-1

- Step 3 Set login password of **admin**.
  - User name: The default user name is **admin**.
  - Password/confirm password: The password ranges from 8 to 32 digitals. It can contain letters, numbers and special characters (excluding "!", "!", ";", "&"). The password shall contain at least two categories. Usually we recommend the strong password.

# 

STRONG PASSWORD RECOMMENDED-For your device own safety, please create a strong password of your own choosing. We also recommend you change your password periodically especially in the high security system.

Step 4 Click Next, device goes to the following interface. See Figure 5-2.

Device Initialization     2 Password Protection 3 Successful						
Z Email	(To reset password)					
Z Security Question						
Question 1	What is your favorite children's book?					
Answer						
Question 2	What was the first name of your first boss?					
Answer						
Question 3	What is the name of your favorite fruit?					
Answer						
	Next					

Figure 5-2

Step 5 Set security questions.

### D Note

- After setting the security questions here, you can use the email you input here or answer the security questions to reset **admin** password Refer to chapter 5.4 Reset password for detailed information.
- Cancel the email or security questions box and then click Next button to skip this step.
- Email: Input an email address for reset password purpose. Scan the QR code to reset the password, you need to receive the security code by the email. Input the security code to reset the password of **admin**. In case you have not input email address here or you need to update the email information, please go to the main Setup->System->Account to set. Refer to chapter 5.11.5.7 for detailed information.
- Security question: Set security questions and corresponding answers. Properly answer the questions to reset admin password. In case you have not input security question here or you need to update the security question information, please go to the main menu->Setting->System->Account->Security question to set. Refer to chapter 4.10.1.3 Security question for detailed information.

### I Note

If you want to reset password by answering security questions, please go to the local menu interface.

Step 6 Click OK to complete the device initialization setup. See Figure 5-3.

Device Initialization	
1 Enter Password	2 Password Protection 3 Successful
	Successfully initialized the device!
	Ok

Figure 5-3

### 5.3 Log in

Open the IE and then input the NVR IP address in the address column.

For example, if your NVR IP address is 192.168.1.108, then please input http:// 192.168.1.108 in IE address column. See Figure 5-4.



Figure 5-4

System pops up warning information to ask you whether install Web plug-in or not. Please click yes button.

After installation, the interface is shown as below. See Figure 5-5.

(a)hua		
Username:	admin	]
Password:		
Type:	TCP 🔹	Forgot password?
	• LAN • WAN	
	Login Cancel	

Figure 5-5

Please input your user name and password.

Factory default user name is **admin** and password is what you set in chapter 5.2 Device initialization.

### 5.4 Reset Password

If you forgot **admin** password, you can reset the password by email or by answering the security questions (local menu only).

- When the password reset function is enabled, you can scan the QR code on the Web to reset the password.
- When the password reset function is disabled, you can reset password via the security questions configured before. If the secury questions are not configured, system displays that Password reset is closed! You need to contact the customer service for help.
- Step 1 Go to the device login interface. See Figure 5-5.
- Step 2 Click Forgot password.
  - If you have set the reserved email, system displays a notice before the password reset. See Figure 5-6.
  - If you have not set the reserved email, a dialogue box pops up that asks you to reset the password by clicking Forgot password on the local interface.



Figure 5-6

Step 3 Click OK.

System enters the following interface. See Figure 5-7.



After clicking OK, we will collect your personal information such as cell phone number, MAC address and device serial number. The collected information is used for verifying device legality and sending security code. Please read the notice carefully and confirm if you agree with the collection or not.

Reset(1/2)	Scan the QR code on the actual interface	Please scan the QR code on the actual interface and follow the prompts on the actual interface to continue.
Input security co	de:	
	Cancel	Next

Figure 5-7

Step 4 Follow the prompts on the interface and then scan the QR code to get the security code.



- ✤ For the same QR code, max scan twice to get two security codes. Refresh the QR code if you want to get security code again.
- ♦ The security code on you email is only valid for 24 hours.
- After five times security code failure, the **admin** account will be locked for 5 minutes.
- Step 5 Input the security code on the email and then click Next button.
- Step 6 Input new password and then confirm.



The password can be set from 8 characters through 32 characters and contain at least two types from number, letter and special character (excluding"", """, ";", ":" and "&"). It is recommended to set password of high security according to the prompts.

Step 7 Click OK button to complete the setup.

### 5.5 LAN Mode

For the LAN mode, after you logged in, you can see the main window. See Figure 5-13. This main window can be divided into the following sections.

- Section 1: there are six function buttons: Live (chapter 0), setup (chapter 5.11), info (Chapter 5.12), playback (chapter 5.13), alarm (chapter 5.14), and logout (chapter 5.16).
- Section 2: There are monitor channels successfully connected to the NVR.

Please refer to Figure 5-8 for main stream and extra stream switch information.



• Section 3: Open all. Open all button is to enable/disable all-channel real-time monitor. Here you can select main stream/sub stream too. See Figure 5-9.

C	)pen All	•
	Main Strean	n
	Sub Stream	
In	stant Record	



• Section 4: Start Talk button.

You can click this button to enable audio talk. Click 【▼】 to select bidirectional talk mode. There are four options: DEFAULT, G711a, G711u and PCM. See Figure 5-10.

After you enable the bidirectional talk, the Start talk button becomes End Talk button and it becomes yellow. Please note, if audio input port from the device to the client-end is using the first channel audio input port. During the bidirectional talk process, system will not encode the audio data from the 1-channel.

S	-	
	DEFAULT	
· ·	G711a	
	G711u	
	PCM	
	noner ronon	_



• Section 5: Instant record button. Click it, the button becomes yellow and system begins manual record. See Figure 5-11. Click it again, system restores previous record mode.



Figure 5-11

• Section 6: Local play button.

The Web can playback the saved (Extension name is dav) files in the PC-end.

Click local play button, system pops up the following interface for you to select local play file. See Figure 5-12.

- 🗐 🍋 📾 🗕
Norton AntiVirus ThinkVantage Technologies Vireless Manager 2008_04_08 L CCF09042008_00000
>
 Cancel

Figure 5-12

- Section 7: Zero-channel encoding. Please refer to chapter 5.9 for detailed information.
- Section 8: PTZ operation panel. Please refer to chapter 5.7 for detailed information.
- Section 9: Image setup and alarm setup. Please refer to chapter 5.8 for detailed information.
- Section 10: From the left to the right ,you can see video quality/fluency/ full screen/1-window/4-window/6-window/8-window/9-window/13-window/16-window/20-window/25-win dow/36-window.. You can set video fluency and real-time feature priority.



Figure 5-13

### 5.6 Real-time Monitor

In section 2, left click the channel name you want to view, you can see the corresponding video in current window.

On the top left corner, you can view device IP(172.11.10.11), channel number(1), network monitor bit stream(2202Kbps) and stream type(M=main stream, S=sub stream). See Figure 5-14.





Figure 5-14

On the top right corner, there are six unction buttons. See Figure 5-15.



Figure 5-15

- 1: Digital zoom: Click this button and then left drag the mouse in the zone to zoom in. right click mouse system restores original status.
- 2: Local record. When you click local record button, the system begins recording and this button becomes highlighted. You can go to system folder RecordDownload to view the recorded file.
- 3: Snapshot picture. You can snapshot important video. All images are memorized in system client folder PictureDownload (default).
- 4: Audio :Turn on or off audio.(It has no relationship with system audio setup)
- 5: Close video.

### 5.7 PTZ

Before PTZ operation, please make sure you have properly set PTZ protocol. (Please refer to chapter 5.11.5.4).

There are eight direction keys. In the middle of the eight direction keys, there is a 3D intelligent positioning key.

Click 3D intelligent positioning key, system goes back to the single screen mode. Drag the mouse in the screen to adjust section size. It can realize PTZ automatically.

Please refer to the following sheet for PTZ setup information.

Parameter       Function         Scan       • Select Scan from the dropdown list.         • Click Set button, you can set scan left and right limit.         • Use direction buttons to move the camera to you desired location and then click left limit button. Then move the camera again and then click right limit button to set a right limit.	
Scan	Select Scan from the dropdown list.
	<ul> <li>Click Set button, you can set scan left and right limit.</li> </ul>
	• Use direction buttons to move the camera to you desired location
	and then click left limit button. Then move the camera again and
	then click right limit button to set a right limit.
Preset	Select Preset from the dropdown list.
	<ul> <li>Turn the camera to the corresponding position and Input the</li> </ul>
	preset value. Click Add button to add a preset.

Parameter	Function
Tour	<ul> <li>Select Tour from the dropdown list.</li> <li>Input preset value in the column. Click Add preset button, you have added one preset in the tour.</li> <li>Repeat the above procedures you can add more presets in one tour.</li> <li>Or you can click delete preset button to remove one preset from</li> </ul>
	the tour.
Pattern	<ul> <li>Select Pattern from the dropdown list.</li> <li>You can input pattern value and then click Start button to begin PTZ movement such as zoom, focus, iris, direction and etc. Then you can click Add button to set one pattern.</li> </ul>
Aux	<ul> <li>Please input the corresponding aux value here.</li> <li>You can select one option and then click AUX on or AUX off button.</li> </ul>
Light and wiper	You can turn on or turn off the light/wiper.



Figure 5-16

Select one monitor channel video and then click Image button in section 9, the interface is shown as Figure 5-17.

### 5.8.1 Image

Here you can adjust its brightness, contrast, hue and saturation. (Current channel border becomes green).

Or you can click Reset button to restore system default setup.



Figure 5-17

#### 5.8.2 Alarm output

Here you can enable or disable the alarm signal of the corresponding port. See Figure 5-18.



Figure 5-18

### 5.9 Zero-channel Encode

Select a window and then click zero-channel encode button, the interface is shown as below. See Figure 5-19.



Figure 5-19

### 5.10 WAN Login

In WAN mode, after you logged in, the interface is shown as below. See Figure 5-20.



Figure 5-20

Please refer to the following contents for LAN and WAN login difference.

1) In the WAN mode, system opens the main stream of the first channel to monitor by default. The open/close button on the left pane is null.

2) You can select different channels and different monitor modes at the bottom of the interface. See

#### Figure 5-21.



Figure 5-21

#### Important

# The window display mode and the channel number are by default. For example, for the 16-channel, the max window split mode is 16.

3) Multiple-channel monitor, system adopts extra stream to monitor by default. Double click one channel, system switches to single channel and system uses main stream to monitor. You can view there are two icons at the left top corner of the channel number for you reference. M stands for main stream. S stands for sub stream (extra stream).

4) If you login via the WAN mode, system does not support alarm activation to open the video function in the Alarm setup interface.

#### Important

- For multiple-channel monitor mode, system adopts extra stream to monitor by default. You cannot modify manually. All channels are trying to synchronize. Please note the synchronization effect still depends on your network environments.
- For bandwidth consideration, system cannot support monitor and playback at the same time. System auto closes monitor or playback interface when you are searching setup in the configuration interface. It is to enhance search speed.

### 5.11 Setup

#### 5.11.1 Camera

5.11.1.1 Registration

#### 5.11.1.1.1 Registration

From Main menu->Setup->Camera->Registration->Registration, you can see the following interface. See Figure 5-22.

Regist	tration	Upgrade	÷										
Device	Search	IP Address	T			S	earch					Uninitialized Initialize	
		Status Previe	ew.	IP Addre	SS	Port D	)evice Name	e N	lanufacturei		Туре	MAC Address	
	Add	Manual Add		Modify	IP							Filter None	
•	СН	Camera Name	Modify	Delete	Status	IP Address	Port	Device Name			WEB Browse	Туре	
	D19	&conf_img	2	•		10.15.21.36	37777	2F0424BPAN00 074	) 1	Private	e		
	D20	CAM 20	2	•	<b>x</b>	10.15.6.168	37777	NVD	1	Private	e		
	D21	CAM 21	1	•	<b>x</b>	10.18.117.22	37777	ITC102-IR	1	Private	e		
	D22	CAM 22	2	•	×	10.15.5.88	40007	1K024B5YAZ00 004	1	Private	e		
	D23	CAM 23	1	•		10.15.9.108	37777	EVS	1	Private	e	EVS5000	
	D24	IPC	2	•		10.15.114.254	37777	2A018CFFAZ00 040	1	Private	e	P2s	
De	lete	Import		Export		Refresh							



Please refer to the following sheet for parameter information.

Parameter	Function
IP Address	Select IP address or the MAC address from the dropdown list
	and then input the corresponding information, click Search
	button to view the results.
Search	Click Search button, you can view the searched device
	information on the list. It includes device IP address, port, device
	name, manufacturer and type.
Uninitialized	Click to search the initialized devices. Select an uninitialized
	device and then click the Initialize button to set the account.
Preview	Click 🕨 to view the preview video of the remote device.
State	It is to display the device has been initialized or not. That is to
	say, the remote device has set the initial account information or
	not. 🗹 means the remote device has initialized, 💌 means
	the remote device has not been intialized.
Add	Select a device in the list and then click Add button, system can
	connect the device automatically and add it to the Added device
	list. Or you can double click one item in the list to add a device.
Modify	Click 혼 or any device in the Added device list, you can change
	the corresponding channel setup.
Delete	Click $^{oxed{00}}$ , you can delete the remote connection of the
	corresponding channel.
Parameter	Function
------------	---
Туре	There are two connection types. You can use the network to
	connect to the camera or use the Wi-Fi. The 💻 means
	current network camera connection mode is general; the $\widehat{\boldsymbol{\gamma}}$
	means current network camera mode is hotspot.
Delete	Select a device in the Added device list and then click Delete button, system can disconnect the device and remove it from the Added device list.
Manual Add	Click it, the interface is shown as in Figure 5-23. Here you can add network camera manually.
	You can select a channel from the dropdown list (Here only shows disconnection channel.)

Manual Add	×
Manufacturer	Onvif 💌
IP Address	192.168.0.0
RTSPMode	Self-adaption
HTTP Port	80
Username	admin
Password	Connect
Channel No.	1 Setup
Remote Channel No.	1
Channel	D1 💌
Decode Buffer	Default 💌
Encrypt	
Server Type	
	OK Cancel

Figure 5-23

Please refer to the following sheet for parameter information.

r

Parameter	Function
Manufacturer	Please select from the dropdown list.
	Note
	Different series products may support different manufacturers, please refer
	to the actual product.

Parameter	Function				
IP address	Input remote device IP address.				
	Input RTSP port of the remote device. The default setup is 554.				
RTSP port	Note				
	Skip this item if the manufacture is private or customize.				
	Input HTTP port of the remote device. The default setup is 80.				
HTTP port	Note				
	Skip this item if the manufacture is private or customize.				
TCP port	Input TCP port of the remote device. The default setup is 37777.				
User name/password	The user name and password to login the remote device.				
	Input channel amount or click the Connect button to get the channel amount of the remote device.				
Channel No.	Note				
	We recommend click Connect button to get remote device channel amount,				
	the manual add operation may result in failure if the input channel amount is				
	not right.				
	After getting the remote device channel amount, click Setup to select a				
Remote	channel.				
channel No.	Note				
	Click to select one or more remote channel numbers here.				
Channel	The local channel number you want to add. One channel name has				
	corresponding one channel number.				
Decode buffer	There are three item: realtime, local, fluent.				
	There are four items: auto/TCP/UDP/MULTICAST(ONVIF device only)				
	Note				
	• The default connection mode is TCP if the connection protocol is				
Service type	private.				
	<ul> <li>There are four items including Auto, TCP, UDP and MULTICAST if the</li> </ul>				
	<ul> <li>There are four items including Auto, TCP, UDP and MULTICAST if the connection protocol is ONVIF.</li> </ul>				
	<ul> <li>There are two items including TCP and UDP if the connection protocol is from the third-party.</li> </ul>				
	is from the third-party. When the connection protocol is ONVIF, enable the encryption function and				
	system transmits data in the encrypted mode.				
Encrypt	Note				
	System supports this function when HTTPS is enabled in IPC.				
Р					

# Change IP

On the searched devices list, check one or more device(s) at the same time. Click Modify IP button, you

can see the following interface. See Figure 5-24 Please refer to the following sheet for log parameter information.

Parameter	Function
DHCP	Check the box here, system can auto allocate the IP
	address. The IP address, subnet mask, default
	gateway are reference only.
Static	Check the box here, you can set IP address, subnet
	mask, default gateway manually.
IP address/subnet	You can input corresponding information here.
mask/default gateway	
User name/password	The account you login the remote device. Please
	input here to password verification to change the
	remote device password.
Incremental value	When you want to change several IP addresses,
	once you input the IP address of the first device, the
	IP address of the next device will increase
	accordingly. For example, when the incremental
	value is 1, if the IP address of the first device is
	172.10.3.128, the IP address of the second device
	will auto be set as 172.10.3.129.

# Note

For the static IP address, system will alert you if there is any IP conflict. If you are changing several IP addresses at the same time, system auto skip the conflicted IP and auto allocate again according to the incremental value you set.

Modify IP			×
Checked	Device No.: 1		
	User	admin	
STATIC	Password	i	
IP Addres	s 172 11	. 2 . 50 Incremental Value	1
Subnet M	ask 255 255	i. 0. 0	
Default G	ateway 172 11	. 0 . 1	
	ОК	Cancel	
SN	IP Address		
1	172.11.2.50		*
			Ŧ

Figure 5-24

# Export IP

System supports to export the registered device list and save it in the USB device.

Step 1 Inset the USB device and click Export.

The File Backup Encryption interface is displayed. See Figure 5-25.

File Backup Encryption	×
File Backup Encryption	<b>V</b> Enable
ОК	Cancel

Figure 5-25

Step 2 File backup encryption is enabled by default. Click OK to select the save path.

Step 3 Click Save. After the export is completed, system pops up a dialogue box to show that backup is completed.

# Note

Backup encryption is enabled by default when exporting IP. The file contains information such as IP

address, port, remote channel number, manufacturer, username and password.

- If file backup encryption is enabled, the extension name of the exported file is .backup. Except the NVR device, any other software cannot open and edit the file.
- If the backup encryption is disabled, the extension name of the exported file is .csv. It might lead to data leakage.

## Import IP

You can import the added device list to add the device conveniently. Click Import button, and then select the import file.

# Note

If the imported IP is already in the added device list, system pops up dialogue box for you to confirm overwrite or not.

- Click OK button, the new IP setup can overwrite the old one.
- Click Cancel button, system adds the new IP setup.



### Important

- You can edit the exported file. Please make sure the file format is the same. Otherwise you cannot import the file again!
- System does not support customized protocol import/export.
- The import/export function is for the devices of the same language.

# 5.11.1.1.2 IPC Upgrade

This interface is to upgrade network camera.

From Main menu->Setting->Camera->Registration->IPC upgrade, enter the following interface. See Figure 5-26.

Click Browse button to select upgrade file. Or you can use filter to select several network cameras at the same time.

Registration		Upgrade							
Select Firmware File				Browse					
Device Upgrade							Device Type No	ne 💌	
	СН	Status	IP Address	Version	Upgrade Status	Port	Туре	Manufacturer	
	D8		10.15.114.161	2.400.DS00.1.T,2016- 05-26		8005	IPC-HDBW722 1F-MPC	Private	
	D11		10.15.23.69	2.420.0000.10.R,2017 -01-11		37777	IP Camera	Private	:
	D13		10.15.114.20			37777	EVS5000	Private	1
	D14		10.15.6.84	1.000.0000.0.R,2017- 01-22		37777		Private	
	D15		10.15.114.29			37777		Private	
	D17	<b>—</b>	10 15 6 250			5050		Private	
								Start Upgrade	3

Figure 5-26

# I Note

Slight difference may be found since the connected network camera may not be same model.

Here you can view device property information. The setups become valid immediately after you set. See Figure 5-27.

Conditions							
	2013-10-24 16:58 42 U/u	Channel 1		×			
		Mirror (	○ Enable ⊙ Dis	sable	Saturation Brightness Contrast Sharpness	—50 —50 —50 —50	
	W.	Flip Light	No Flip Close	× ×			
1		Scene Mode DayLight	Auto Auto	~			
IPDome							
Default	t Save Refr	esh					

Figure 5-27

Please refer to the following sheet for detailed information.

Parameter	Function
Channel	Please select a channel from the dropdown list.
Period	It divides one day (24 hours) to two periods. You can set different hue, brightness, and contrast for different periods.
Hue	It is to adjust monitor video brightness and darkness level. The default value is 50.
	The bigger the value is, the large the contrast between the bright and dark section is and vice versa.
Brightness	It is to adjust monitor window brightness. The default value is 50.
	The larger the number is , the bright the video is. When you input the value here, the bright section and the dark section of the video will be adjusted accordingly. You can use this function when the whole video is too dark or too bright. Please note the video may become hazy if the value is too high. The value ranges from 0 to 100. The recommended value ranges from 40 to 60.
Contrast	It is to adjust monitor window contrast. The value ranges from 0 to 100. The default value is 50.
	The larger the number is, the higher the contrast is. You can use this function when the whole video bright is OK but the contrast is not proper. Please note the video may become hazy if the value is too low. If this value is too high, the dark section may lack brightness while the bright section may over exposure .The recommended value ranges from 40 to 60.

Saturatio	on	It is to adjust monitor window saturation. The value ranges from 0 to 100. The default value is 50.				
		The larger the number is, the strong the color is. This value has no effect on the general brightness of the whole video. The video color may become too strong if the value is too high. For the grey part of the video, the distortion may occur if the white balance is not accurate. Please note the video may not be attractive if the value is too low. The recommended value ranges from 40 to 60.				
Gain		The gain adjust is to set the gain value. The smaller the value is, the low the noise is. But the brightness is also too low in the dark environments. It can enhance the video brightness if the value is high. But the video noise may become too clear.				
White le	vel	It is to enhance video effect.				
Color m	ode	It includes several modes such as standard, color. You can select corresponding color mode here, you can see hue, brightness, and contrast and etc will adjust accordingly.				
Auto Iris	;	It is to enable/disable auto iris function.				
Flip		It is to switch video up and bottom limit.				
		This function is disabled by default.				
Mirror		It is to switch video left and right limit. This function is disabled by default.				
BLC Mode	BLC	The device auto exposures according to the environments situation so that the darkest area of the video is cleared				
	WDR	For the WDR scene, this function can lower the high bright section and enhance the brightness of the low bright section. So that you can view these two sections clearly at the same time.				
		The value ranges from 1 to 100. When you switch the camera from no-WDR mode to the WDR mode, system may lose several seconds record video.				
	HLC	After you enabled HLC function, the device can lower the brightness of the brightest section according to the HLC control level. It can reduce the area of the halo and lower the brightness of the whole video.				
	Off	It is to disable the BLC function. Please note this function is disabled by default.				
Profile		It is to set the white balance mode. It has effect on the general hue of the video. This function is on by default.				
		You can select the different scene mode such as auto, sunny, cloudy, home, office, night, disable and etc to adjust the video to the best quality.				
		• Auto: The auto white balance is on. System can auto compensate the color temperature to make sure the vide color is proper.				
		<ul> <li>Sunny: The threshold of the white balance is in the sunny mode.</li> </ul>				
		<ul> <li>Night: The threshold of the white balance is in the night</li> </ul>				

	<ul> <li>mode.</li> <li>Customized: You can set the gain of the red/blue channel. The value reneges from 0 to 100.</li> </ul>
Day/Night	It is to set device color and the B/W mode switch. The default setup is auto.
	<ul> <li>Color: Device outputs the color video.</li> </ul>
	<ul> <li>Auto: Device auto select to output the color or the B/W video according to the device feature (The general bright of the video or there is IR light or not.)</li> </ul>
	• B/W: The device outputs the black and white video.
	<ul> <li>Sensor: It is to set when there is peripheral connected IR light.</li> </ul>

# 5.11.1.3 Encode

# 5.11.1.3.1 Encode

The encode interface is shown as below. See Figure 5-28.

Encode Mode	Snapshot	Overlay	Path		
Channel	D8	•			
Main Stream			Sub Stream		
Code-Stream Type	Regular	-	Video Enable		
Compression	H.264	-	Code-Stream Type	Sub Stream1 🔹	
Resolution	1920*1080(1080P)	•	Compression	H.264 💌	
Frame Rate(FPS)	7	•	Resolution	352*288(CIF)	
Bit Rate Type	CBR	•	Frame Rate(FPS)	25 💌	
Bit Rate	4096	▼ Kb/S	Bit Rate Type	CBR	1
Reference Bit Rate	4096-4096Kb/S		Bit Rate	896 💌	Kb/S
			Reference Bit Rate	896-896Kb/S	
🔽 Audio Enable			Audio Enable		
Audio Encode		•	Audio Encode	•	
Sampling Rate		•	Sampling Rate		
Vatermark Enable			Watermark String	DigitalCCTV	
	Сору	ОК	Refresh De	fault	

# Figure 5-28

#### Please refer to the following sheet for detailed information.

Parameter	Function
Channel	Please select a channel from the dropdown list.
Video enable	Check the box here to enable extra stream video. This item is enabled by default.
Code stream type	It includes main stream, motion stream and alarm stream. You can select different encode frame rates form different recorded events. System supports active control frame function (ACF). It allows you to record in different frame rates. For example, you can use high frame rate to record important events, record scheduled event in lower frame rate and it allows

	you to not different frame rates for motion detection record and
	you to set different frame rates for motion detection record and alarm record.
0	Video encode mode.
Compression	
	H.264: Main Profile encode mode.
	• H.264H: High Profile encode mode.
	• H.264B: Baseline Profile encode mode.
	• H.265: Main Profile encode mode.
	<ul> <li>MJPEG: System needs high bit streams to guarantee video definition. Use the recommended max bit stream value to get the better video effect.</li> </ul>
Smart Codec	This function is to reduce bit streams.
	Note
	• Some series products support smart codec function.
	<ul> <li>After changing smart code, please reboot network camera and some network camera functions (such as IVS, ROI, SVC, lobby mode and etc.) becomes null. Please think twice before the operation.</li> </ul>
Resolution	The resolution here refers to the capability of the network
	camera.
Frame Rate	The video frame amount displayed in each second. The higher the frame rate is, the clearer and more fluent the video is. The frame rate may vary depending on the resolution.
Bit Rate	<ul> <li>Main stream: You can set bit rate here to change video quality. The large the bit rate is, the better the quality is. Please refer to recommend bit rate for the detailed information.</li> </ul>
	• Extra stream: In CBR, the bit rate here is the max value. In dynamic video, system needs to low frame rate or video quality to guarantee the value. The value is null in VBR mode.
Bit rate type	System supports two types: CBR and VBR.
	• Main stream: It is to set frame rate to change video quality. The higher the frame rate is, the better the video quality is. The referenced bit rate is the recommended value.
	• Sub stream: In CBR mode, the bit stream is near the specified value. In VBR mode, the video quality changes according to the bit stream value. But its max value is near the specified value. Reference bit rate: The reference bit rate depends on the resolution and frame rate you set.
Reference bit rate	Recommended bit rate value according to the resolution and frame rate you have set.
I Frame	Here you can set the P frame amount between two I frames. The value ranges from 1 to 150. Default value is 50.
	Recommended value is frame rate *2.

Video/audio	You can enable or disable the video/audio. The main stream is
	enabled by default. After enable the audio function, the record f
	is composite file consisting of the video and audio. For the sub
	stream 1, please enable video first and then enable audio
	function.
Audio format	Set audio encode format.
	Note
	Different series products support different audio encode mode.
	Please refer to the actual interface for detailed information.
Sampling rate	Audio sampling rate refers to the sampling amount within 1
	second. The higher the value is, the better the audio is. The
	default setup is 8K.
Watermark	This function allows you to verify the video is tampered or not.
enable	Here you can select watermark bit stream, watermark mode and watermark character. Default character is DigitalCCTV. The max length is 85-digit. The character can only include number, character and underline.

# 5.11.1.3.2 Snapshot

The snapshot interface is shown as in Figure 5-29.

Encode Mode	Snapshot	Overlay	Path	
Channel	D8	•		
Mode	Timing	•		
Image Size	1920*1080(1080P)	-		
Image Quality	5	•		
Interval	1 SPL	•		
	ОК	Refresh		

Figure 5-29

Please refer to the following sheet for detailed information.

Parameter	Function
Snapshot type	<ul> <li>There are two modes: Regular (schedule) and Trigger.</li> <li>Regular snapshot is valid during the specified period you set.</li> <li>Trigger snapshot only is valid when motion detect alarm, tampering alarm or local activation alarm occurs.</li> </ul>
Image size	It is the same with the resolution of the main stream.
Quality	It is to set the image quality. There are six levels.
Interval	It is to set snapshot frequency. The value ranges from 1s to 7s. Or you can set customized value. The max setup is 3600s/picture.
Сору	Click it; you can copy current channel setup to other channel(s).

5.11.1.3.3 Video Overlay

The video overlay interface is shown as in Figure 5-30.

Encode	Snapshot	Overlay	Path
IPC		2013-11-12 1	0:50:54       Channel       1         Cover-Area       Image: Cover-Area         Image: Monitor       Image: Channel Display       Setup         Image: Channel Display       Setup         Image: Time Display       Setup
[	Сору 5	ave Refresh	Default

Figure 5-30

Please refer to the following sheet for detailed information.

Parameter	Function
Cover-area	Check Preview or Monitor first.
	Click Set button, you can privacy mask the specified video in the preview or monitor video.
	System max supports 4 privacy mask zones.
Time Title	You can enable this function so that system overlays time
	information in video window.
	You can use the mouse to drag the time title position.
	You can view time title on the live video of the WEB or the
	playback video.
Channel Title	You can enable this function so that system overlays channel
	information in video window.
	You can use the mouse to drag the channel title position.
	You can view channel title on the live video of the WEB or the
	playback video.

## 5.11.1.3.4 Path

The storage path interface is shown as in Figure 5-31.

Here you can set snap image saved path ( in the preview interface) and the record storage path



(Implies the preview interface). The default setup is C:\PictureDownload and C:\RecordDownload.

Please click the Save button to save current setup.

Encode	Snapshot	Overlay	Path	
Snapshot Path Record Path	C:\PictureDownload C:\RecordDownload		Browse	
	Save	Default		

Figure 5-31

# 5.11.1.4 Channel Name



D1 (				
D1 (				
	CAM 1	D2	CAM 2	
D3 (	CAM 3	D4	CAM 4	
D5 (	CAM 5	D6	CAM 6	
D7 (	CAM 7	D8	IP PTZ Dome	
D9 I	IP PTZ Dome	D10	热成像	
D11 I	IPC	D12	CAM 12	
D13	CAM 13	D14	&conf_img.channel1	
D15	CAM 15	D16	CAM 16	
D17 (	CAM 17	D18	CAM 18	
D19 8	&conf_img.channel1	D20	CAM 20	
D21	CAM 21	D22	CAM 22	
D23	CAM 23	D24	IPC	
	ОК	Refresh	Default	

Figure 5-32

# 5.11.2 Network

5.11.2.1 TCP/IP The TCP/IP interface is shown as in Figure 5-33.

TCP/IP	P2P
Network Mode	Multi-address
Default Card	Ethernet Card1
Ethernet Card	Ethernet Card1 Default Card
Mode	⊙ STATIC O DHCP
MAC Address	88 , 38 , 44 , 62 , 11 , fe
MTU	1500
IP Version	IPv4
IP Address	10 . 15 . 6 . 144
Subnet Mask	255 . 255 . 0 . 0
Default Gateway	10 . 15 . 0 . 1
Preferred DNS	10 . 1 . 2 . 80
Alternate DNS	10 . 1 . 2 . 81
LAN Download	

Figure 5-33

Please refer to the following sheet for detailed information.
---

Parameter	Function			
Mode	There are two modes: static mode and the DHCP mode.			
	<ul> <li>The IP/submask/gateway are null when you select the DHCP mode to auto search the IP.</li> </ul>			
	<ul> <li>If you select the static mode, you need to set the IP/submask/gateway manually.</li> </ul>			
	<ul> <li>If you select the DHCP mode, you can view the IP/submask/gateway from the DHCP.</li> </ul>			
	<ul> <li>If you switch from the DHCP mode to the static mode, you need to reset the IP parameters.</li> </ul>			
	<ul> <li>Besides, IP/submask/gateway and DHCP are read-only when the PPPoE dial is OK.</li> </ul>			
Mac Address	It is to display host Mac address.			
IP Version	It is to select IP version. IPV4 or IPV6.			
	You can access the IP address of these two versions.			
IP Address	Please use the keyboard to input the corresponding number to modify the IP address and then set the corresponding subnet mask and the default gateway.			
Preferred DNS	DNS IP address.			
Alternate DNS	Alternate DNS IP address.			
	s of IPv6 version, default gateway, preferred DNS and e input value shall be 128-digit. It shall not be left in blank.			
LAN load	System can process the downloaded data first if you enable this function. The download speed is 1.5X or 2.0X of the normal speed.			

#### 5.11.2.2 Port

The connection interface is shown as in Figure 5-34.

CONNECTION		
Max Connection	128	(0~128)
TCP Port	37777	(1025~65535)
UDP Port	37778	(1025~65535)
HTTP Port	80	(1~65535)
HTTPS Port	443	(128~65535) 🔲 Enable
RTSP Port	554	(128~65535)
RTSP Format		<password>@<ip address="">:<port>/cam/realmonitor?channel=1&amp;subtype=0 32; subtype: Code-Stream Type, Main Stream 0, Sub Stream 1. Refresh Default</port></ip></password>

Figure 5-34

Please refer to the following sheet for detailed information.

Parameter	Function
Max connection	The max client login amount (such as WEB, platform, cellphone and etc). The value ranges from 1 to 128(default).
TCP port	The default value is 37777. You can input the actual port number if necessary.
UDP port	The default value is 37778. You can input the actual port number if necessary.
HTTP port	The default value is 80. You can input the actual port number if necessary.
HTTPS	Select the Enable check box and configure the port according your actual needs. The default value is 443. After HTTPS is enabled, HTTP will be switched to HTTPS by force to transmit data in a safer way.
RTSP port	The default value is 554.

# 5.11.2.3 Wi-Fi AP

This function is available only for NVR devices with built-in Wi-Fi module. See the actual situation. 5.11.2.3.1 General Setup

The Wi-Fi AP interface is shown as in Figure 5-35. Select the Enable check box and you can set Wi-Fi hotspot including SSID, encryption type, password, channel and gain, so that the Wi-Fi IPC can use the hotspot to connect to the network.

General A	dvanced
2.4GHz 🔽	Enable
SSID	NVR-2hhhh
Encryption Type	WPA2 PSK
Password	12345678
Channel	Auto
Gain	Middle
	OK Refresh Default

Figure 5-35

Please refer to the following sheet for detailed information.

Parameter	Function		
2.4GHz	Select the check box to enable Wi-Fi.		
SSID	It is to set SSID name. You can use this name to search the device.		
Encryption Type	Select the encryption type from the dropdown list, including WPA2 PSK, WPA PSK and OPEN.		
Password	It is to set SSID password. You can use this password to connect to the network.		
Channel	Select the channel to connect the Wi-Fi IPC.		
Gain	Adjust the Wi-Fi signal intensity.		

### 5.11.2.3.2 Advanced

Click Advanced button, the interface is shown as below. See Figure 5-36.

General	Advanced
IP Config	
IP Address	22 . 1 . 1 . 1
Subnet Mask	255 . 255 . 255 . 0
Default Gatewa	22 . 1 . 1 . 1
DHCP Server	
Start IP	22 . 1 . 1 . 100
EndIP	22 . 1 . 1 . 200
	OK Refresh Default

# Figure 5-36

Please refer to the following sheet for detailed information.

Parameter	Function
IP Address	Input the IP address, subnet mask and default gateway of the

Subnet Mask	NVR Wi-Fi AP.			
Default Gateway	NOTE The IP address and default gateway shall be in the same network segment.			
Start IP/End IP	Input start IP and end IP of DHCP server. The NVR device can allocate the IP address in the range you specified here.			
Upgrade	Click it to upgrade Wi-Fi AP module.			

5.11.2.4 Wi-Fi

Please note this function is for the device of Wi-Fi module.

The Wi-Fi interface is shown as in Figure 5-37.

WIFI				
Enable	_			Search SSID
	S SID	Security Type	Encryption Type	Signal Intensity
WIFI Working Info Current Hotspot IP Address				<u></u>
Subnet Mask Default Gateway				Ŷ
Save	Refresh			



Please check the box to enable Wi-Fi function and then click the Search SSID button. Now you can view all the wireless network information in the following list. Double click a name to connect to it. Click Refresh button, you can view latest connection status.

5.11.2.5 3G 5.11.2.5.1 CDMA/GPRS The CDMA/GPRS interface is shown as in Figure 5-38.

CDMA/GPRS	Mobile	
WLAN Type	No Service	Enable
APN		Dial/SMS Activate
AUTH	PAP	Y
Dial No.		
User Name		
Password		
Pulse Interval		Second
WLAN Status		
IP Address		
Wireless Signal	Search	
	Save	Refresh Default

Figure 5-38

Please refer to the following sheet for detailed information.

Parameter	Function			
WLAN type	Here you can select 3G network type to distinguish the 3G module from different ISP. The types include WCDMA, CDMA1x and etc.			
APN/Dial No.	Here is the important parameter of PPP.			
Authorization	It includes PAP,CHAP,NO_AUTH.			
Pulse interval	It is to set time to end 3G connection after you close extra stream monitor. For example, if you input 60 here, system ends 3G connection after you close extra stream monitor 60 seconds.			
Important				
<ul> <li>If the pulse interval is 0, then system does not end 3G connection after you close the extra stream monitor.</li> </ul>				
<ul> <li>Pulse interval here is for extra stream only. This item is null if you are using main stream to monitor.</li> </ul>				

### 5.11.2.5.2 Mobile

The mobile setup interface is shown as in Figure 5-39.

Here you can activate (send out "on") or turn off (Send out "off") the 3G connected phone or mobile phone, or the phone you set to get alarm message.

Check send SMS box and then input the phone number in the receiver column. Click I to add one

receiver. Repeat the above steps you can add more phones. Select a phone number and then click you can delete it. Click OK button to complete the setup.

CDMA/GPRS	Mobile			
Send SMS		SMS Activate	Tel Activate	
Receiver	+	Sender	Caller	+
18969021865		18969021865		
Title NVR Message				
	Save	Refresh Defau	uit	

Figure 5-39

# 5.11.2.6 PPPoE

The PPPoE interface is shown as in Figure 5-40.

Input the PPPoE user name and password you get from the IPS (internet service provider) and enable PPPoE function. Please save current setup and then reboot the device to get the setup activated.

Device connects to the internet via PPPoE after reboot. You can get the IP address in the WAN from the IP address column.

Please note, you need to use previous IP address in the LAN to login the device. Please go to the IP address item to via the device current device information. You can access the client-end via this new address.

PPPoE	
Enable	
User Name	
Password	
IP Address	0.0.0
	0.0.0
	Save Refresh Default



# 5.11.2.7 DDNS

DDNS (Dynamic Domain Name Server) is to dynamically refresh the DNS domain name and IP address if the device IP address has changed frequently. The user can use the domain to access the device.

# Preparation

Before the operation, check the DDNS type that the device supports.

- If the DDNS type is Quick DDNS. You do not need to register the domain name.
- If the DDNS is some other type, log in the website of the DDNS provider and register information like domain name.

## 

After you register the device and log in the DDNS website, you can view all connected device information of the current user.

Step 1 Enter from main memu > Setup > Network > DDNS.

DDNS setup interface is shown as in Figure 5-41.

DDNS	
Enable	After enabling DDNS function, third-party server may collect your device info.
DDNS Type	NO-IP DDNS
Host IP	dynupdate.no-ip.com
Domain Nan	ne Test
Username	
Password	
Interval	1440 Min. (1440~2880)
	OK Refresh Default

Figure 5-41

Step 2 Select the Enable check box.

# 

After enabling DDNS, the third-party server might collect your device information.

Step 3 Select the DDNS type and configure the parameters. For details, see the below table.

Parameter	Description	
Server Type	You can select DDNS protocol from the dropdown list and then enable DDNS function.	
Address	<ul> <li>DDNS server IP address list:</li> <li>Dyndns DDNS: members.dyndns.org.</li> <li>NO-IP DDNS: dynupdate.no-ip.com.</li> <li>CN99 DDNS: members.3322.org.</li> <li>NOTE</li> <li>When the DDNS type is NO-IP DDNS, some series will display the Test button. Click Test and you can detect if the device has registered successfully.</li> </ul>	
Domain Name	Your self-defined domain name.	
User	The user name you input to log in the server.	

Parameter	Description	
Password	The password you input to log in the server.	
Test	After the configuration, click Test and system saves the configuration and check if the domain name can be registered successfully.	
	<ul> <li>If succeeded, go to step4.</li> </ul>	
	<ul> <li>If failed, check if the domain information is correct and clear the browser buffer.</li> </ul>	
	NOTE NOTE	
	System supports this function when DDNS type is NO-IP DDNS.	
Update period	The time interval to send update request. Unit: Minute.	

Step 4 Click Save to complete the setting.

Step 5 Input the domain name in the Web browser and click Enter key. The setting is right if you can view the Web interface of the device. Otherwise, check the parameters.

## 5.11.2.8 Email

The email interface is shown as in Figure 5-42.

Email	
Enable	
SMTP Server	10.1.0.97
Port	25
Anonymous	
User Name	ge_xiaoxia
Password	••••••
Sender	ge_xiaoxia@it.com
Encrypt Type	NONE
Subject	NVR ALERT 🗹 Attachment
Receiver	
	ge_xiaoxia@it.com
Interval	120 Second(0~3600)
Health Enable	60 Minute (30~1440)
	Test
	Save Refresh Default

Figure 5-42

Please refer to the following sheet for detailed information.

Parameter	Function
Enable	Please check the box here to enable email function.
SMTP Server	Input server address and then enable this function.
Port	Default value is 25. You can modify it if necessary.
Anonymity	For the server supports the anonymity function. You can auto login anonymously. You do not need to input the user name.

Parameter	Function
	password and the sender information.
User Name	The user name of the sender email account.
Password	The password of sender email account.
Sender	Sender email address.
Authentication (Encryption mode)	You can select SSL or none.
Subject	Input email subject here.
Attachment	System can send out the email of the snapshot picture once you check the box here.
Receiver	Input receiver email address here. Max three addresses. It supports SSL, TLS email box.
Interval	The send interval ranges from 0 to 3600 seconds. 0 means there is no interval. Please note system will not send out the email immediately when the alarm occurs. When the alarm, motion detection or the abnormity event activates the email, system sends out the email according to the interval you specified here. This function is very useful when there are too many emails activated by the abnormity events, which may result in heavy load for the email server.
Health mail enable	Please check the box here to enable this function.
Update period (interval)	This function allows the system to send out the test email to check the connection is OK or not. Please check the box to enable this function and then set the corresponding interval. The value ranges from 30 minutes to 1440 minutes. System can send out the email regularly as you set here.
Email test	The system will automatically sent out a email once to test the connection is OK or not .Before the email test, please save the email setup information.

# 5.11.2.9 UPnP

It allows you to establish the mapping relationship between the LAN and the public network.

Here you can also add, modify or remove UPnP item. See Figure 5-43.

- In the Windows OS, From Start->Control Panel->Add or remove programs. Click the "Add/Remove Windows Components" and then select the "Network Services" from the Windows Components Wizard.
- Click the Details button and then check the "Internet Gateway Device Discovery and Control client" and "UPnP User Interface". Please click OK to begin installation.
- Enable UPnP from the Web. If your UPnP is enabled in the Windows OS, the NVR can auto detect it via the "My Network Places"

UPNP								
PAT	🖸 Enable 🔿 (	Disable						
Status	Disable							
LAN IP	0.0.0	).0						
WAN IP	0.0.0	0.0						
Port Mappin	ng List							
No.		Service Name	Protocol	Internal Port	External Port	Modify	Delete	
1	<ul><li>✓</li></ul>	HTTP	TCP	80	80	2	8	^
2		TCP	TCP	37777	37777	1	8	
3	✓	UDP	UDP	37778	37778	2	8	
4		RTSP	UDP	554	554	🧷	8	
5	✓	RTSP	TCP	554	554	2	8	
6		SNMP	UDP	161	161	2	8	
7		HTTPS	TCP	443	443	2	8	
								~
Add								
Save	Refresh	Default						

# Figure 5-43

Please refer to the following sheet for detailed information.

Parameter	Function		
PAT	Check the corresponding box to enable PAT function.		
Status	Display UPnP function status.		
	It is corresponding to the UPnP mapping information on the router.		
	Check the box before the service name to enable current PAT service.		
	Otherwise, the service is null.		
	Service name: Customized name.		
	Protocol: Protocol type.		
Port manning list	Internal port: The port mapped to the port.		
Port mapping list	External port: The port current device needs to map.		
	Device has three mapping items: HTTP/TCP/UDP.		
	Note		
	When you set the external port (outport) of the router, the value ranges		
	from 1024 to 5000. Do not use port 1 $\sim$ 255 or system port 256 $\sim$ 1023,		
	in case there is conflict.		
	Click Add button to add map relationship.		
Add	Note		
Adu	For the data transmission protocol TCP/UDP, the external port and the		
	internal port shall be the same to guarantee proper data transmission.		
Delete	Select one service and then click 🤤 to delete map relationship.		

# 5.11.2.10 SNMP

The SNMP interface is shown as in Figure 5-44.

The SNMP allows the communication between the network management work station software and the proxy of the managed device. It is reserved for the 3<sup>rd</sup> party to develop.

0.000			
SNMP			
Enable			
Version	V1 V2	V3 (Recomme	nded)
SNMP Port	161	(1~65535)	
Read Community			
Write Community			
Trap Address			
Trap Port	162	(1~65535)	
Read Only User	Public		
Authentication Type	MD5	•	
Authentication			
Password			
Encryption Type	CBC-DES	-	
Encryption Password			
Decidaria Hara	<b>D</b> :		
Read/Write User	Private		
Authentication Type	MD5	•	
Authentication			
Password			
Encryption Type	CBC-DES	•	
Encryption Password			
		Defeat	Defeut
	OK	Refresh	Default

Figure 5-44

Please refer to the following sheet for detailed information.

Parameter	Function
Version	Select by clicking the check box in front of the corresponding version. NOTE System selects V3 by default. There might be some risks for V1 and V2.
SNMP Port	The listening port of the proxy program of the device. It is a UDP port not a TCP port. The value ranges from 1 to 65535. The default value is 161
Read Community	It is a string. It is a command between the manage process and the proxy process. It defined the authentication, access control and the management relationship between one proxy and one group of the managers. Please make sure the device and the proxy are the same. The read community will read all the objects the SNMP supported in the specified name. The default setup is public.
Write Community	It is a string. It is a command between the manage process and the proxy process. It defined the authentication, access control and the management relationship between one proxy and one group of the managers. Please make sure the device and the proxy are the same. The read community will read/write/access all the objects the SNMP supported in the specified name. The default setup is

Parameter	Function
	write.
Trap address	The destination address of the Trap information from the proxy program of the device.
Trap port	The destination port of the Trap information from the proxy program of the device. It is for the gateway device and the client-end PC in the LAN to exchange the information. It is a non-protocol connection port. It has no effect on the network applications. It is a UDP port not TCP port. The value ranges from 1 to 165535. The default value is 162.
Read-only user	It only supports reading function when logging in the device with this user account.
Authentication mode	Including two modes: MD5 and SHA. The system can automatically recognize it after enabled.
Read-write user	It supports reading and writing when logging in the device with this user account.
Password	The password for authentication and encryption. It shall be no less than 8 characters.
Encryption Type	Select the encryption mode. The default mode is CBC-DES.

# 5.11.2.11 Multicast

The multicast interface is shown as in Figure 5-45.

Multicast is a transmission mode of data packet. When there is multiple-host to receive the same data packet, multiple-cast is the best option to reduce the broad width and the CPU load. The source host can just send out one data to transit. This function also depends on the relationship of the group member and group of the outer.

Multicast	
Enable	
IP Address	239 . 255 . 42 . 42 (224.0.0.0~239.255.255.255)
Port	36666 (1025~65500)
	Save Refresh Default

Figure 5-45

# 5.11.2.12 Auto Register

The auto register interface is shown as below. See Figure 5-46.

This function allows the device to auto register to the proxy you specified. In this way, you can use the client-end to access the NVR and etc via the proxy. Here the proxy has a switch function. In the network service, device supports the server address of IPv4 or domain.

Please follow the steps listed below to use this function.

Please set proxy server address, port, and sub-device name at the device-end. Please enable the auto register function, the device can auto register to the proxy server.

AUTO REGISTER	
Enable	
Host IP	0.0.0.0
Port	8000
Sub-device ID	0
	Save Refresh Default



## 5.11.2.13 Alarm Centre

The alarm center interface is shown as below. See Figure 5-47.

This interface is reserved for you to develop. System can upload alarm signal to the alarm center when local alarm occurs.

Before you use alarm center, please set server IP, port and etc. When an alarm occurs, system can send out data as the protocol defined, so the client-end can get the data.

Alarm Centre	
Enable	
Protocol Type	ALARM CENTER
Host IP	20 . 2 . 12 . 27
Port	1
Self-report Time	Everyday 💽 at 08:00 💌 Save Refresh Default

Figure 5-47

### 5.11.2.14 HTTPS

In this interface, you can set to make sure the PC can successfully login via the HTTPS. It is to guarantee data communication security. The reliable and stable technology can secure the user information security and device safety. See Figure 5-48.

#### Note

- You need to implement server certificate again if you have changed device IP.
- You need to download root certificate if it is your first time to use HTTPS on current PC.

HTTPS	
Create Server Certificate	Download Root Certificate

Figure 5-48

### 5.11.2.14.1 Create Server Certificate

If it is your first time to use this function, please follow the steps listed below.

In Figure 5-48, click Create Server Certificate button, input country name, state name and etc. Click Create button. See Figure 5-49.

## Note

Please make sure the IP or domain information is the same as your device IP or domain name.

Create Server Certifi	ate	X
Country	AU	
State		
Locatity		
Oragnization		
Oragnization Unit		
IP or Domain Name	10.10.6.238	
	Create Cancel	

Figure 5-49

You can see the corresponding prompt. See Figure 5-50. Now the server certificate is successfully created.

HTTPS			
Create Server Certific	ate Download Root Certificate		
Create Succeed	I		



### 5.11.2.14.2 Download root certificate

In Figure 5-48, click Download Root Certificate button, system pops up a dialogue box. See Figure 5-51.



Figure 5-51

Click Open button, you can go to the following interface. See Figure 5-52.

Certificate ? 🗙
General Details Certification Path
Certificate Information This CA Root certificate is not trusted. To enable trust, install this certificate in the Trusted Root Certification Authorities store.
Issued to: Product Root CA
Issued by: Product Root CA
<b>Valid from</b> 2013-6-18 <b>to</b> 2023-6-16
Install Certificate Issuer Statement

Figure 5-52

Click Install certificate button, you can go to certificate wizard. See Figure 5-53.



Figure 5-53

Click Next button to continue. Now you can select a location for the certificate. See Figure 5-54.

rtificate Import Wizard	
Certificate Store	
Certificate stores are system areas where certificates are kept.	
Windows can automatically select a certificate store, or you can specify a location for	
<ul> <li>Automatically select the certificate store based on the type of certificate</li> </ul>	
O Place all certificates in the following store	
Certificate store:	
Browse	
<u>Back</u> <u>N</u> ext > Cance	el

Figure 5-54

Click Next button, you can see the certificate import process is complete. See Figure 5-55.

Certificate Import Wizard		×
	Completing the C Wizard You have successfully compl wizard.	Certificate Import
	You have specified the follow	wing settings:
	Certificate Store Selected Content	Automatically determined by t Certificate
	< <u>B</u> ack	Finish Cancel

Figure 5-55

Click Finish button, you can see system pops up a security warning dialogue box. See Figure 5-56.

Security	Warning			
	You are about to install a certificate from a certification authority (CA) claiming to represent:			
	Product Root CA			
	Windows cannot validate that the certificate is actually from "Product Root CA". You should confirm its origin by contacting "Product Root CA". The following number will assist you in this process:			
	Thumbprint (sha1): CD20E4B2 A52D50B8 8447BD20 5C67B033 397E3F81			
	Warning: If you install this root certificate, Windows will automatically trust any certificate issued by this CA. Installing a certificate with an unconfirmed thumbprint is a security risk. If you click "Yes" you acknowledge this risk.			
	Do you want to install this certificate?			
	<u>Y</u> es			

Figure 5-56

Click Yes button, system pops up the following dialogue box, you can see the certificate download is complete. See Figure 5-57.



Figure 5-57

5.11.2.14.3 View and set HTTPS port

From Setup->Network->Port, you can see the following interface. See Figure 5-58. You can see HTTPS default value is 443.

Max Connection	128	(0~128)
TCP Port	37777	(1025~65535)
UDP Port	37778	(1025~65535)
HTTP Port	80	(1~65535)
HTTPS Port	443	(128~65535) 🔲 Enable
RTSP Port	554	(128~65535)
RTSP Format		<password>@<ip address="">:<port>/cam/realmonitor?channel=1&amp;subtype=0 -32; subtype: Code-Stream Type, Main Stream 0, Sub Stream 1. Refresh Default</port></ip></password>

Figure 5-58

# 5.11.2.14.4 Login

Open the browser and then input <a href="https://xx.xx.xx.xx:port">https://xx.xx.xx.xx:port</a>.

xx.xx.xx: is your device IP or domain mane.

Port is your HTTPS port. If you are using default HTTPS value 443, you do not need to add port information here. You can input <u>https://xx.xx.xx</u> to access.

Now you can see the login interface if your setup is right.

### 5.11.2.15 P2P

You can use your cell phone to scan the QR code and add it to the cell phone client.

Via the SN from scanning the QR code, you can access the device in the WAN. Please refer to the P2P operation manual included in the resources CD.

The P2P interface is shown as in Figure 5-59.

P2P		
Enable		
After enabling P2P and connec	ging your device, the P2P will be enabled. ting to Internet, we need to collect IP address,	
	vice SN, etc. All collected info is used only for If you don't agree to enable P2P function,	
please deselect the check box		
Status Offline		
Cellphone client	SN	
Scan the QR code o	■ 記述版目 (応力を発生す) n the actual interface.	
Scan QR to download	1J00811YAZL9793	
Save Refr	esh	

Check the Enable box to enable P2P function and then click the Save button. When the Status shows Online, the P2P registration is successful.

**NOTE** 

- P2P is enabled by default.
- To enable you to manage the device on the mobile APP, we will collect device information like IP address, MAC address, device name and device SN. The collected information is only used for remote device access.

## 5.11.3 Event

5.11.3.1 Video detect

5.11.3.1.1 Motion Detect

After analysis video, system can generate a video loss alarm when the detected moving signal reached the sensitivity you set here.

The motion detect interface is shown as in Figure 5-60.

Motion Detect	Video Loss	Tampering	Scene Change	
Enable	D8	•		
Period	Setup			
Anti-Dither Region	5 Setup	Sec.(0-600)		
Record Chann	el Setup			
Delay	10	Sec.(10~300)		
🔲 Alarm Out	1 2 3	4 5 6		
Latch	10	Sec.(0~300)		
PTZ Activation	Setup			
Tour	Setup			
Snapshot	Setup			
Voice Prompts	File Name	None	•	
Show Message	e 📃 Send Ema	il 🔲 Alarm Upload	Buzzer 🗌 Message 📄 Log	
	Сору	ОК	Refresh Default	

Figure 5-60

Setup		$\sim$
	Thursday 🔽 Copy	
	☑ 00 : 00 - 24 : 00	
	00 : 00 - 24 : 00	
	00 : 00 - 24 : 00	
	00 : 00 - 24 : 00	
	00 : 00 - 24 : 00	
	00 : 00 - 24 : 00	
	Save Cancel	

Figure 5-61



Figure 5-62

PTZ	Activation	I.			×
	D1	None	Ŧ	1	Â
	D2	None	T	1	
	D3	None	-	1	
	D4	None	Ŧ	1	
	D5	None	Ŧ	1	
	D6	None	Ŧ	1	=
	D7	None	-	1	
	D8	None	•	1	
	D9	None	Ŧ	1	
	D10	None	Ŧ	1	
	D11	None	•	1	
	D12	None	Ŧ	1	
	D13	None	•	1	
	D14	None	•	1	
	D15	None	•	1	
	D 40				<b>T</b>
		ОК	Ca	ancel	

Figure 5-63

Tour	×
All	
D8 D11 D13 D14 D15 D17 D18 D19 D20 D21 D22	
D23 D24	
OK Cancel	

Figure 5-64

Snapshot	X
All D8 D11 D13 D14 D15 D17 D18 D19 D20 D21 D22 D23 D24	
OK Cancel	

Figure 5-65

Please refer to the following sheet for detailed information.

Parameter	Function
Enable	You need to check the box to enable motion detection function.
	Please select a channel from the dropdown list.
Period	Motion detection function becomes activated in the specified periods. See Figure 5-61.
	There are six periods in one day. Please draw a circle to enable corresponding period.
	Click OK button, system goes back to motion detection interface, please click save button to exit.
Anti-dither	System only memorizes one event during the anti-dither period. The value ranges from 5s to 600s.
Sensitivity	There are six levels. The sixth level has the highest sensitivity.
Region	If you select motion detection type, you can click this button to set motion detection zone. The interface is shown as in Figure 5-62. Here you can set motion detection zone. There are four zones for you to set. Please select a zone first and then left drag the mouse to select a zone. The corresponding color zone displays different detection zone. You can click Fn button to switch between the arm mode and disarm mode. In arm mode, you can click the direction buttons to move the green rectangle to set the motion detection zone. After you completed the setup, please click ENTER button to exit current setup. Do remember click save button to save current

Parameter	Function
	setup. If you click ESC button to exit the region setup interface system will not save your zone setup.
Record channel	System auto activates motion detection channel(s) to record once an alarm occurs. Please note you need to set motion detect record period and go to Storage-> Schedule to set current channel as schedule record.
Record Delay	System can delay the record for specified time after alarm ended. The value ranges from 10s to 300s.
Alarm out	Enable alarm activation function. You need to select alarm output port so that system can activate corresponding alarm device when an alarm occurs.
Latch	System can delay the alarm output for specified time after an alarm ended. The value ranges from 1s to 300s.
Show message	System can pop up a message to alarm you in the local host screen if you enabled this function.
Buzzer	Check the box here to enable this function. The buzzer beeps when an alarm occurs.
Alarm upload	System can upload the alarm signal to the center (Including alarm center.
Message	When 3G network connection is OK, system can send out a message when motion detect occurs.
Send Email	If you enabled this function, System can send out an email to alert you when an alarm occurs.
Tour	You need to click setup button to select tour channel. System begins 1-wiindow or multiple-window tour display among the channel(s) you set to record when an alarm occurs. See Figure 5-64.
PTZ Activation	Here you can set PTZ movement when alarm occurs. Such as go to preset X. See Figure 5-63.
Snapshot	Click setup button to select snapshot channel. See Figure 5-65.
Video Matrix	This function is for motion detect only. Check the box here to enable video matrix function. Right now system supports one-channel tour function. System takes "first come and first serve" principle to deal with the activated tour. System will process the new tour when a new alarm occurs after previous alarm ended. Otherwise it restores the previous output status before the alarm activation.

# 5.11.3.1.2 Video Loss

The video loss interface is shown as in Figure 5-66.

Please note video loss does not support anti-dither, sensitivity, region setup. For rest setups, please refer to chapter 5.11.3.1.1 motion detect for detailed information.

Motion Detect	Video Loss	Tampering	Scene Change
Enable	D8	•	
Period	Setup		
Record Channe	I Setup		
Delay	10	Sec.(10~300)	
Alarm Out	1 2 3	4 5 6	
Latch	10	Sec.(0~300)	
PTZ Activation	Setup		
V Tour	Setup		
Snapshot	Setup		
Voice Prompts	File Name	None	•
Show Message	🔲 Send Ema	I 🔲 Alarm Upload	🗌 Buzzer 🗌 Message 🗸 Log
	Сору	ОК	Refresh Default

Figure 5-66

# 5.11.3.1.3 Tampering

The tampering interface is shown as in Figure 5-67.

After analysis video, system can generate a tampering alarm when the detected moving signal reached the sensitivity you set here.

For detailed setups, please refer to chapter 5.11.3.1.1 motion detect for detailed information.

Motion Detect	Video Loss	Tampering	Scene Change
✓ Enable	D8	•	
Period	Setup		
Record Channe	I Setup		
Delay	10	Sec.(10~300)	
Alarm Out	1 2 3	4 5 6	
Latch	10	Sec.(0~300)	
PTZ Activation	Setup		
Tour	Setup		
Snapshot	Setup		
Voice Prompts	File Name	None	<b>v</b>
Show Message	📃 Send Ema	il 🔲 Alarm Upload	🗌 Buzzer 🔲 Message 🔽 Log
	Сору	ОК	Refresh Default

Figure 5-67

### 5.11.3.1.4 Scene Change

From main window->Setup->Event->Video detect->Scene change, the video diagnosis interface is shown as in Figure 5-68.

Motion Detect	Video Loss	Tampering	Scene Change				
Enable	D8	•					
Period	Setup						
Record Channe	el Setup						
Delay	10	Sec.(10~300)					
Alarm Out	1 2 3	4 5 6					
Latch	10	Sec.(0~300)					
PTZ Activation	Setup						
Tour	Setup						
Snapshot	Setup						
Voice Prompts	File Name	None	•				
🔲 Send Email 🛛	Alarm Upload	Buzzer 🔲 Message	e 🔽 Log				
	Сору	ОК	Refresh	Default	]		

Figure 5-68

For detailed setups, please refer to chapter 5.11.3.1.1 motion detect for detailed information.

5.11.3.2 IVS Plan

The smart plan is for the smart network camera. If you do not set a rule here, you cannot use the intelligent functions in IVS (Chapter 5.11.3.3), Face detection (Chapter 5.11.3.4) and People counting (Chapter 5.11.3.5) when you are connecting to a smart network camera.

There are two types to realize intelligent analytics function.



- Smart network camera supports intelligent functions: Some smart camera supports the intelligent functions. For NVR, it just displays the intelligent alarm information from the smart network camera and set or playback the record file.
- NVR supports intelligent functions: The connected network camera does not support intelligent video analytics function. The NVR supports the analytics function.

From main menu->Setup->Event->IVS plan, you can go to the IVS plan interface. See Figure 5-69.

IVS PLAN		
Channel	-	
Ad	<b>*</b>	
ОК	Refresh	

Figure 5-69
Select a channel from the dropdown list. Click Add button, you can see an interface shown as below. See Figure 5-70.

Select a channel from the dropdown list and then set preset. Click Add button and then set the corresponding rule.

# D Note

Some smart camera does not need to add the preset. Please refer to the actual product for detailed information.





Click OK button to complete the setup.

# III Note

- The NVR supports general behavior analytics (IVS), human face detection, heat map, and people counting. Different network camera supports different smart plans. Please refer to the actual product for detailed information.
- The general behavior analytics (IVS) and human face detection function cannot be valid at the same time. For example, when add the IVS plan to the preset 1, the human face detection icon becomes grey.

5.11.3.3 IVS (Behavior Analytics) (Optional)

Once the object state has reached the threshold, NVR can trigger an intelligent alarm.

D Note

- This function is for some series product only. Please refer to the actual product for detailed information.
- The IVS function and the human face detection function cannot be valid at the same time.

The IVS function environment shall meet the following requirements:

- The object total size shall not be more than 10% of the whole video.
- The object size on the video shall not be more than 10pixels\*10 pixels. The abandoned object size shall be more than 15pixels\*15 pixels (CIF resolution). The object width shall not be more than 1/3 of

the video height and width. The recommended height is 10% of the video.

- The object and the background brightness different shall be more than 10 grey levels.
- The object shall remain on the video for more than 2 seconds. The moving distance is larger than its own width and shall not be smaller than 15pixels (CIF resolution).
- The surveillance environment shall not be too complicated. The IVS function is not suitable for the environment of too many objects or the changing light.
- The surveillance environment shall not contain glasses, reflection light from the ground, and water. Free of tree branches, shadow, mosquito and bugs. Do not use the IVS function in the backlight environment, avoid direct sunlight.

#### 5.11.3.3.1 Behavior Analytics

From main menu->Setup->Event->Behavior analytics->Behavior analytics, you can go to the Behavior analytics interface. See Figure 5-71.

Otherward     Chanel     No.           No. </th <th>BEHAVIOR ANALYTICS GLOBAL</th> <th></th> <th></th> <th></th> <th></th>	BEHAVIOR ANALYTICS GLOBAL				
I Rule I     I	2014-07-21 20:01:44	Channel	1	*	
I Rule1     I		No.	Name F	Preset Rule Type	÷
Image: Series of the series of th		1	Rule1	- Tripwire	
Direction A To B   Period Setup   Period Setup   Period Setup   Diraw Rule Clear   Target Filter Max Size   Min Size Draw Target   Clear 12345678   Latch 10 s(0-300)   PTZ Activation Setup   Torur Setup   Snapshot Setup   Send Email Alarm Upload   Buzzer Log		- Parameters Config	J <u></u>		
Draw Rule   Target Filter   Min Size   Draw Target   Clear     Y Record Channel   Setup   Delay   1   2   4   5   6   7   8   Draw Target   Clear     Y Record Channel   Setup   Delay   10   s(0-300)     PTZ Activation   Setup   Tour   Setup   Snapshot   Setup   Send Email   Alarm Upload   Buzzer   Log				•	
Draw Rule   Target Filter   Min Size   Draw Target   Clear     Y Record Channel   Setup   Delay   1   2   4   5   6   7   8   Draw Target   Clear     Y Record Channel   Setup   Delay   10   s(0-300)     PTZ Activation   Setup   Tour   Setup   Snapshot   Setup   Send Email   Alarm Upload   Buzzer   Log		Period	Setup	]	
Draw Rule       Clear         Target Filter       Max Size         Oraw Target       Clear         Min Size       Draw Target         Clear       Tour         Snapshot       Setup         Send Email       Alarm Upload         Buzzer       Log		Record Channe	el Setup	1	
Draw Rule       Clear         Target Filter          Max Size        Draw Target         Other Min Size       Draw Target         Clear       Tour         Setup		Delay	10	s(10~300)	
Target Filter     Max Size       Oraw Target     Clear       Min Size     Tour       Setup       Snapshot       Setup       Send Email		Alarm Out	1 2 3	8 4 5 6 7 8	
Target Filter  Max Size Min Size Tour Setup Snapshot Setup Send Email Alarm Upload Buzzer Log	Draw Rule Clear	Latch	10	s(0~300)	
Min Size     Draw Target     Clear     Tour     Setup       Snapshot     Setup       Send Email     Alarm Upload     Buzzer     Log		PTZ Activation	Setup		
Sanapshot Setup Send Email Alarm Upload Buzzer V Log	Draw Target Clear	Tour	Setup	2	
	O Min Size	🗍 Snapshot	Setup	1	
OK Refresh		Send Email	Alarm Upload	□ Buzzer 🔽 Log	
OK Refresh					
		ОК	Refresh	]	

Figure 5-71

Please select a channel from the dropdown list

Click 🔁 to add a rule. The default setup is tripwire, you can double click the rule type name to modify. See Figure 5-72.

Cha	nnel	1		-	
	No.	Name	Preset	Rule Type	÷
	1	Rule1		Tripwire 💌	0
				Tripwire Intrusion Abandoned Objec Missing Object	

Then you can set corresponding parameters. Click OK button to complete the setup.

## 5.11.3.3.2 Tripwire

From main menu->Setup->Event-> Behavior analytics->Behavior analytics, click 🔂 you can see the following interface. See Figure 5-73.

System generates an alarm once there is any object crossing the tripwire in the specified direction.

BEHAVIOR ANALYTICS	GLOBAL									
BEHAVIOR ANALYTICS		2015-03-	04 14:13:03	Chan	nel	4		•		
					No.	Name	Preset	Rule Type	÷	
	se diaw a line.	C. WITTE	T	<b>V</b>	1	Rule1	-	Tripwire	0	
		PERSONAL PROPERTY		Dire	eters Config ection	A To B		•		
		1 N P		Peri	iod ord Channel	Setur				
California no3				Del:		10 1 2	s(10~3			
Draw Rule			Clear	Lato	:h	10	s(0~30	0)		
				PTZ	Activation	Setur	2			
Target Filter 💿 Max Si:	ze	Draw Target	Clear	🗌 Tou	r	Setur	<b></b>			
Min Siz	ze			Sna		Setur	2			
				📄 Sen	d Email 🗌	] Alarm Uploa	d 🔲 Buzzer	✓ Log		
				0	ж	Refresh				

Figure 5-73

Check the Tripwire box to enable tripwire function.

Select SN (Line1/2/3/4) and direction, and then input customized rule name.

• Direction: There are three options: A->B, B->A, both. System can generate an alarm once there is any object crossing in the specified direction.

Now you can draw a rule. Click Draw rule button and then left click mouse to draw a tripwire. The tripwire can be a direct line, curve or polygon. Right click mouse to complete. See Figure 5-74.

BEHAVIOR ANALYTICS	GLOBAL						
	· A	2015-03-04 14:12:44	Channel No.	4 Name	Preset	▼ Rule Type	÷
Draw	ng is completed	Caumh Sabara	Parameters Config	Rule1	-	Tripwire	0
	P		Parameters Config - Direction Period	A To B		•	
Rule1 California no3			<ul> <li>Record Channel</li> <li>Delay</li> <li>Alarm Out</li> </ul>	Setup 10 1 2	s(10~30	0)	
Draw Rule Target Filter    Max Size		Clear	Latch	10 Setup	s(0~300	))	
⊖ Min Size	Dra	aw Target Clear	Tour Snapshot Send Email	Setup Setup Alarm Upload		✓ Log	
			ОК	Refresh			

Figure 5-74



Figure 5-75

Select the blue line and then use mouse to adjust zone size.

#### Note

Each rule can set two sizes (min size/max size). Once the object is smaller than the min size or larger than the max size, there is no alarm. Please make sure the max size is larger than the min size. Click Ok to complete the rule setup.

For detailed setups, please refer to chapter 5.11.3.1.1 motion detect for detailed information.

5.11.3.3.3 Intrusion (Cross warning zone)

From main menu->Setup->Event-> Behavior analytics->Behavior analytics, click ch, and then select rule

type as intrusion, you can see the following interface. See Figure 4-126. **Note:** 

- System supports customized area shape and amount.
- Support enter/leave/both detection.
- Can detect the moving object operation in the specified zone, customized trigger amount and staying time.
- Support objects filter function.

HAVIOR ANALYTICS GLOBAL						
7	2015-03-04 14:13:19	Channel	4			
		No.	Name	Preset	Rule Type	÷
		✓ 1	Rule1	-	Intrusion	0
	2 3 38					
	ERI JAN					
	Sautok N					
		Parameters Config				
		Action	Cross		•	
		Direction	Both		•	
	6 1 2 K 8 1					
	€-02/	Period	Setu	p		
		Record Channel	Setu	p		
California no3		Delay	10	s(10~	300)	
Draw Rule	Clear	Alarm Out	1 2	3 4 5	6 7 8	
Diawridic	oldar	Latch	10	s(0~3		
Target Filter 🔘 Max Size	Draw Target Clear	PTZ Activation	Setu			
Min Size		Tour	Setu			
		Snapshot				
			Setu			
		Send Email	Alarm Uploa	ad 🗌 Buzzer	Log	
		ок	Refresh			

Figure 5-76

Check the Intrusion box to enable intrusion function.

Select SN (Area1/2/3/4) and direction, and then input customized rule name.

- Action: System supports two types: appear/cross.
- Direction: There are three options: A->B, B->A, both. System can generate an alarm once there is any object enter/exit (Or both) the zone.

Now you can draw a rule. Left click mouse to draw a line first and then right click mouse to draw another line until you draw a rectangle, you can right click mouse to exit.

Click Ok to complete the rule setup.



BEHAVIOR ANALYTICS GLOBAL						
	2015-03-04 14:13:03	Channel	4		Ŧ	
		No.	Name	Preset	Rule Type	÷
Drawing is compl	CANUNK	2 1	Rule1		Intrusion	0
Rule1		Parameters Config Action Direction	Cross		•	
		Period	Setup	_		
California no3		Delay	10	s(10~3	00)	
				1000		
Draw Rule	Clear	Alarm Out	1 2	3 4 5	6 7 8	
Target Filter 💿 Max Size		Latch	10	s(0~30	0)	
Min Size	Draw Target Clear	PTZ Activation	Setup			
		Tour	Setup			
		Snapshot	Setup			
		Send Email	Alarm Upload	Buzzer	✓ Log	
		ОК	Refresh			

Figure 5-77

For detailed setups, please refer to chapter 5.11.3.1.1 motion detect for detailed information.

## 5.11.3.3.4 Abandoned Object Detect

From main menu->Setup->Event-> Behavior analytics->Behavior analytics, click , and then select rule

type as abandoned object detection, you can see the following interface. See Figure 5-78.

- System supports customized area shape and amount.
- Support duration setup.
- Support objects filter function.

A starting the starting of the	2015-03-04 14:13:16	Channel	4	-	
		No.	Name Pre	set Rule Type	÷
	and a second sec	1	Rule1	Abandoned Objec	t 😑
	Cault K Strater	Parameters Config – Period Period	30 Setup	S	
		Record Channel	Setup	s(10~300)	
California_no3		Delay	10		
		Alarm Out	1 2 3	4 5 6 7 8	
Draw Rule	Clear	Latch	10	s(0~300)	
		PTZ Activation	Setup		
Target Filter O Max Size	Draw Target Clear	Tour	Setup		
Min Size		🗌 Snapshot	Setup		
		Send Email	Alarm Upload 🛛	Buzzer 🔽 Log	

Figure 5-78

Check the Object box to enable object detect function.

• Period: System can generate an alarm once the object is in the zone for the specified period.

Click	Draw Rule	to draw the	rule. See Figure 5	-79.			
	BEHAVIOR ANALYTICS	GLOBAL					
			2015-03-04 14:14:00	Channel	4		
				No.	Name Rule1	Preset Rule Typ – Abandone	
	California po3 Rule			Parameters Config Period Period V Record Channel Delay	30 Setup Setup 10	s (10~300)	
	California no3 Rule			Alarm Out			8
	Draw Rule		Clear	Latch	10	s(0~300)	
	Target Filter 🔿 Ma		Draw Target Clear	PTZ Activation     Tour	Setup Setup		
				Snapshot	Setup Alarm Upload	Buzzer V Log	
				ОК	Refresh		

Figure 5-79

Now you can draw a rule. Left click mouse to draw a line, until you draw a rectangle, you can right click mouse.

Click Ok to complete the rule setup.

For detailed setups, please refer to chapter 5.11.3.1.1 motion detect for detailed information. 5.11.3.3.5 Missing Object Detect

From main menu->Setup->Event-> Behavior analytics->Behavior analytics, click , and then select rule

type as missing object detection, you can see the following interface. See Figure 2-6.

- System supports customized area shape and amount.
- Support period setup.
- Support objects filter function.

		No.	Name	Preset	Rule Type	÷
		1	Rule1	-	Missing Object	0
	SAWINK					
	A RESTREAM					
	LIS.	Parameters Config Period	30		s	
		Fellou	50	12	5	
	1 11 P	Period	Setu	q		
		Record Channel	Setu	a		
		Delay	10	s(10~3	00)	
alifornia no3		Alarm Out	1 2			
)raw Rule	Clear	Latch	10	s(0~30		
		PTZ Activation	Setu	ıp		
Target Filter 🔘 Max Size	Draw Target Clear	Tour	Setu	ıp		
Min Size		Snapshot	Setu	ıp		
		Send Email	Alarm Linio:	ad 🔲 Buzzer	<b>1</b> 00	

Figure 5-80



Figure 5-81

Click Ok to complete the rule setup.

For detailed setups, please refer to chapter 5.11.3.1.1 motion detect for detailed information.

#### 5.11.3.3.6 Loitering

From main menu->Setup->Event-> Behavior analytics->Behavior analytics, click, and then select rule

type as loitering detection, you can see the following interface. See Figure 2-21.

#### Note

- System supports customized area shape and amount.
- Support duration setup.
- Support objects filter function.

BEHAVIOR ANALYTICS	GLOBAL		-				
	20	14-07-21 20:01:42	Channel	2		*	
1	-		No.	Name	Preset	Rule Type	÷
			☑ 1	Rule1	1	Loitering Detection	0
			Parameters Config				
		alter and	Duration	5		S	
		250	Period	Setup			
			Record Channel	Setup			
I Pa			Delay	10		300)	
		and the second se	Alarm Out	1 2	3 4 5	6 7 8	
Draw Rule		Clear	Latch	10	s(0~3	00)	
			PTZ Activation	Setup			
Target Filter 💿 Max Siz	Draw I	arget Clear	Tour	Setup	-		
O Min Size	e		Snapshot	Setup			
			Send Email	Alarm Upload	Buzzer	✓ Log	
			Track Time	30	s (5~3		
			ОК	Refresh			

Figure 5-82

• Duration: System can generate an alarm once the object is in the zone for the specified period.

Draw Rule to draw the rule.

Click OK to complete the rule setup.

For detailed setups, please refer to chapter 5.11.3.1.1 motion detect for detailed information.

#### 5.11.3.3.7 Crowd gathering detection

From main menu->Setup->Event-> Behavior analytics->Behavior analytics, click, and then select rule

type as crowd gathering estimation, you can see the following interface. See Figure 2-20.

- Customized zone and amount setup.
- Duration setup.

Click

- Sensitivity setup.
- Min gathering zone setup.

BEHAVIOR ANALYTICS	GLOBAL		
	2013-09-12 12:15:44	4 Channel 2	
		No. Name Preset Rule Type 4분	
- A A		1 Rule1 1 Crowd Gathering Estima     tiion	
ALL STA		Parameters Config	
		Duration 10 s	
12 12 -		Sensitivity - 0 + 5	
		Period Setup	
12A		Record Channel Setup	
		Delay 10 s(10~300)	
Draw Rule	Clear	Alarm Out 1 2 3 4 5 6 7 8	
		Latch 10 s(0~300)	
Crowd Gathering	Draw Target Clear	PTZ Activation Setup	
Estimatiion		Tour Setup	
		Snapshot Setup	
		Send Email 🗌 Alarm Upload 🗌 Buzzer 🔽 Log	
		✓ Track Time 30 \$ (5~300)	
		OK Refresh	

## Figure 5-83

- Duration: System can generate an alarm once the object is in the zone for the specified period.
- Sensitivity: It is to set alarm sensitivity. The value ranges from 1 to 10. The default setup is 5.

Click Draw Rule to draw the rule.

Click OK to complete the rule setup.

For detailed setups, please refer to chapter 5.11.3.1.1 motion detect for detailed information.

## 5.11.3.3.8 Fast moving

From main menu->Setup->Event-> Behavior analytics->Behavior analytics, click, and then select rule

type as fast moving, you can see the following interface. See Figure 2-19.

• Sensitivity: It is to set alarm sensitivity. The value ranges from 1 to 10. The default setup is 5.

BEHAVIOR ANALYTICS	GLOBAL						
	1	X \$ 31 *** 1224	Channel	2		¥	
			No.	Name	Preset	Rule Type	÷
		•	✓ 1	Rule1	1	Fast-Moving	0
	l	1	- Parameters Config				
		AL	Sensitivity	Ξ	-0	+ 5	
		SANT.	Period	Setu	p		
			Record Channe Delay	I Setu	ps(10~3	00)	
<del>11-</del>			Alarm Out	1 2			
Draw Rule		Clear	Latch	10	s(0~30	10)	
			PTZ Activation	Setu	p		
Target Filter 💿 Max Si. 🔿 Min Siz	DI	raw Target Clear	Tour	Setu	p		
U 1012	Te.		Snapshot	Setu	p		
			Send Email	] Alarm Uploa	id 🗌 Buzzer	☑ Log	
			Track Time	30	s (5~30	00)	
			ок	Refresh			

Figure 5-84

Click Draw Rule to draw the rule.

Click OK to complete the rule setup.

For detailed setups, please refer to chapter 5.11.3.1.1 motion detect for detailed information.

## 5.11.3.3.9 Global Config

From main menu->Setup->Event->Behavior analytics->Global, you can go to the global configuration interface. See the below figure.

- Channel: Please select a channel from the dropdown list.
- Preset: Select a preset you want to set the rule. Please note, you need to add a preset first, otherwise, you cannot see the preset dropdown list. If there is no preset, you can draw a rule in current channel.
- Calibration zone:
- ♦ Click Add area , you can draw a calibration zone at the left pane of the interface. Select a zone and then click Delete zone button; you can remove the selected zone.
- Select gauge type (vertical/level), you can set the corresponding length. You can draw three tilt gauges and one horizontal gauge at the left pane of the interface.
- Select Width/Height and then click Verify, you can draw a line in the calibration zone, and then you can see its actual length.
- Update preset: Click it to get the latest preset setup.

BEHAVIOR ANALYTICS	GLOBAL		
	2016-03-50 11 20 11 11 11 11	Channel	8 🔹
		Preset Calibration Config Calibration Area	The PTZ camera does n
E		<sup>□</sup> • <u></u> Region	
		Add Area	Delete Area
	188	Gauge Vertical Gauge	O Level Gauge
IP PTZ Dome		Actual Length	1 M
		Add Gauge	Delete Gauge
	- Zoom + Speed 5	Width Verification	▼ Verify
	Focus + Update Preset     Inis +	ОК	Refresh Default

Figure 5-85

## 5.11.3.4 Face Detect (Optional)

When camera detects human face, system can generate an alarm.

From main menu->Setup->Event->Face detect, the interface is shown as in Figure 5-86.

• Enable face boost: Check the box here, system can enhance the human face display pane.

• Sensitivity: System supports 6 levels. The sixth level has the highest sensitivity.

FACE DETECT	
Enable	2
Period	Setup
Enable Face Boost	
Record Channel	Setup
Delay	10 sec. (10~300)
Alarm Out	1 2 3 4 5 6 7 8
Latch	10 sec. (1~300)
PTZ Activation	Setup
✓ Tour	Setup
Snapshot	Setup
Alarm Upload	Send Email 🔲 Buzzer 🗹 Log
	OK Refresh Default

Figure 5-86

For detailed setups, please refer to chapter 5.11.3.1.1.

#### 5.11.3.5 People Counting

System can calculate the entry/exit people amount in the specified zone. It can generate an alarm when the amount has exceeded the threshold.

From main menu->Setup->Event->People counting, you can see an interface shown as the below figure.

- Channel: Please select a channel from the dropdown list. Check the box to enable people counting function.
- OSD overlay: Check the box here; you can view the people amount on the surveillance video.
- Direction: It is to set people flow direction. It includes entry/exit.
- Entry No.: It is to set people entry amount. System can generate an alarm once the amount has exceeded the threshold.
- Exit No.: It is to set people entry amount. System can generate an alarm once the amount has exceeded the threshold.
- Stranded No.: It is to set people staying amount in the zone. System can generate an alarm once the amount has exceeded the threshold.

For detailed setups, please refer to chapter 5.11.3.1.1 motion detect for detailed information.

2013-09-12 12:16:48	Channel 2
	OSD Overlay Clear
	Name Direction Enter 💌
	People Counting
	Enter No. 0
	Exit No. 0
ava the state	Stranded No. 0
	Parameters Config
	Period Setup
	Record Channel Setup
Draw Rule Clear	Delay 10 s(10~300)
	Alarm Out 1 2 3 4 5 6 7 8
	Latch 0 s(0~300)
	PTZ Activation Setup
	Tour Setup
	Snapshot Setup
	Send Email Alarm Upload Buzzer Log
	OK Refresh Default

Figure 5-87

#### 5.11.3.6 Heat Map

It is to detect the object activity level in the scene during the specified period.

From main menu->Setup->Event->Heat Map, you can see an interface shown as in Figure 5-88. For detailed setups, please refer to chapter 5.11.3.1.1 motion detect for detailed information.

HEAT MAP 2014-07-21 20:01:41	Channel Parameters Config Period	14 💌	
	ок	Refresh Default	]

Figure 5-88

## 5.11.3.7 Plate Recognition

License plate recognition adopts video image recognition technology to extract the license plate number in video image and match it with the pre-set license plate number. After successful matching, the system performs alarm linkage action

5.11.3.7.1 Configuring Plate Recognition

You can set the different plate recognition detection rules and alarm linkage actions under different confitions (B/W list and regular)

## Step 1 Select Setup > Event > ANPR.

The ANPR interface is displayed. See Figure 5-89.

ANPR B/W List					
		Channel			
		Regular	Blacklist	Whitelist	
		Period	Setup		
		Record Channel	Setup		
		Post-Record	10	Sec.(10~300)	
		🔲 Alarm Out	1 2		
		Latch	0	Sec.(0~300)	
		PTZ Activation	Setup		
		🔲 Tour	Setup		
		🔲 Snapshot	Setup		
		Voice Prompts	File Name	lone	•
Draw Rule	Clear	🔲 Send Email 📃	Alarm Upload 📃 I	Buzzer 📃 Log	
			ОК	Refresh	Default

Figure 5-89

- Step 2 Select the Enable check box and choose the channel.
- Step 3 Enter the Name and click Draw Rule to draw the rule region on the monitor screen. Click Clear to cancel the drawing.
- Step 4 Click the Regular, Whitelist or Blacklist tab according to actual needs. System displays the Regular tab by default.

D NOTE

You need to configure the B/W list before using the B/W alarm linkage. For details, see 4.7.7.2 B/W List.

- Regular: System activates alarm when any car plate is detected.
- Blacklist: System activates alarm only when plates in the black list is detected.
- Whitelist: System activates alarm only when plates in the white list is detected.

Step 5 Configure the parameters.

Step 6 Click OK to save the configuration.

#### 5.11.3.7.2 B/W List

It is to set the blacklist and the whitelist. It includes adding, deleting, importing and exporting blacklist and whitelist.

After setting the blacklist and whitelist, in the plate snapshot list on the preview interface, the blacklist plate number is red, the whitelist plate number is green and the regular plate number is white.

#### Adding B/W List

Step 1 Select Setup > Event > ANPR > B/W List.

The B/W list is diaplayed. See Figure 5-90.

ANPR	B/W List			
License				
Туре	Whitelist 💌	Add Search		
	No.	License	Туре	Delete
			I	< < 1/1 ▶ ▶ 1 😥
Del	Clear Import	Export		

Figure 5-90

Step 2 Enter the plate number and selecy whitelist or blacklist in the drop-down list.

Step 3 Click Add to complete the registration.

#### Deleting B/W List

In the Type list, select whitelist, blacklist or all and click Search, system displays the detailed information. See Figure 5-91.

• Select the check box in front of the plate number and click Delete to delete the plate info in the list.

You can also click 🤤 corresponding to the plate number to delete it.

• Click Clear to delete all the information in the B/W list.

License			
Туре	Whitelist	Add Search	
	No.	License	Type Delete
	1	A12345	Blacklist 😑
			₩ ◀ 1/1 ► ₩ 1
Del	Clear Im	Dort Export	

Figure 5-91

## Importing /Exporting B/W List

System supports to import B/W list from the peripheral USB device and export B/W list to the USB device. System supports to import .csv files and .xlsx files, and the exported files are in the format of .csv or .backup.

- Importing B/W list: Click Import, select the file, and then click Open to import the file.
- Export B/W list: Click Export and the File Backup Encryption interface is displayed. See Figure 5-92. Enter the password and click OK. Select the save path and click Save.

File Backup Encryption				
File Backup 🔽 On Encryption				
Password:				
It is 6 to 32-digit containing letter(s), number (s), symbol(s). It contains at least two types.				
OK Cancel				

Figure 5-92

## D NOTE

File backup encryption is enabled by default.

- When file backup encryption is enabled, the extension name of the file is .backup.
- When file backup encryption is disabled, the extension name of the file is .csv. It might lead to data leakage.

## 5.11.3.8 Audio Detect (Optional)

System can generate an alarm once it detect the audio input is abnormal or audio volume changes. From main menu->Setup->Event->Audio detect, you can see an interface shown as in Figure 5-93.

 Input abnormal: Check the box here, system can generate an alarm once the audio input is abnormal.

- Intensity change: Check the box here, system can generate an alarm once the audio volume becomes strong.
- Sensitivity: It refers to the audio recognition sensitivity. The higher the value is, the higher the sensitivity is.
- Threshold: It is to set intensity change threshold. The smaller the value is, the higher the sensitivity is.

For detailed setups, please refer to chapter 5.11.3.1.1 motion detect for detailed information.

AUDIO DETECT	
Channel	D8 💌
🔽 Input Abnormal	
Intensity Change	
Sensitivity	□
Threshold	□ ──── (+ 50
Period	Setup
Record Channel	Setup
Delay	10 s (10~300)
Alarm Out	1 2 3 4 5 6
Latch	10 s (0-300)
PTZ Activation	Setup
Tour	Setup
🔲 Snapshot	Setup
Voice Prompts	File Name None 💌
🔲 Alarm Upload	🗌 Send Email 📄 Buzzer 📄 Message 👽 Log
	OK Refresh Default

Figure 5-93

#### 5.11.3.9 Alarm

Before operation, please make sure you have properly connected alarm devices such as buzzer. The input mode includes local alarm and network alarm.

#### 5.11.3.9.1 Local Alarm

The local alarm interface is shown as in Figure 5-94. It refers to alarm from the local device.

Local Alarm	Net Alarm	IPC External Alarm	IPC Offline Alarm
Enable	1	✓ Ala	Jarm Name
Period	Setup		
Anti-Dither	5	Sec.(0-600)	Type NO 💌
Record Channel	Setup		
Delay	10	Sec.(10~300)	
Alarm Out	1 2 3	4 5 6	
Latch	10	Sec.(0~300)	
PTZ Activation	Setup		
Tour	Setup		
Snapshot	Setup		
Voice Prompts	File Name	None	×
📄 Show Message	📃 Send Ema	il 🔲 Alarm Upload	🗍 Buzzer 🦳 Message 🔽 Log
	Сору	ОК	Refresh Default

Setup			E
Т	hursday 💌	Сору	
	00 : 00	- 24 : 00	
	00 : 00	- 24 : 00	
	00 : 00	- 24 : 00	
	00 : 00	- 24 : 00	
	00 : 00	- 24 : 00	
	00 : 00	- 24 : 00	
	Save	Cancel	]

Figure 5-95

PTZ	Activation	1			×
	D1	None	-	1	<u> </u>
	D2	None	Ŧ	1	
	D3	None	Ŧ	1	
	D4	None	Ŧ	1	
	D5	None	Ŧ	1	
	D6	None	Ŧ	1	E
	D7	None	-	1	
	D8	None	•	1	
	D9	None	-	1	
	D10	None	Ŧ	1	
	D11	None	•	1	
	D12	None	Ŧ	1	
	D13	None	•	1	
	D14	None	•	1	
	D15	None	•	1	
	D 40				*
		ОК	C	ancel	

Figure 5-96

Parameter	Function
Enable	You need to check the box to enable this function.

Parameter	Function	
	Please select a channel from the dropdown list.	
Period	<ul> <li>This function becomes activated in the specified periods.</li> <li>There are six periods in one day. Please draw a circle to enable corresponding period.</li> <li>Select date. If you do not select, current setup applies to today only. You can select all week column to apply to the whole week.</li> <li>Click OK button, system goes back to local alarm interface, please click save button to exit.</li> </ul>	
Anti-dither	System only memorizes one event during the anti-dither period. The value ranges from 5s to 600s.	
Sensor type	There are two options: NO/NC.	
Record channel	System auto activates motion detection channel(s) to record once an alarm occurs. Please note you need to set alarm record period and go to Storage-> Schedule to set current channel as schedule record.	
Record Delay	System can delay the record for specified time after alarm ended. The value ranges from 10s to 300s.	
Alarm out	Enable alarm activation function. You need to select alarm output port so that system can activate corresponding alarm device when an alarm occurs.	
Latch	System can delay the alarm output for specified time after an alarm ended. The value ranges from 1s to 300s.	
Show message	System can pop up a message to alarm you in the local host screen if you enabled this function.	
Buzzer	Check the box here to enable this function. The buzzer beeps when an alarm occurs.	
Alarm upload	System can upload the alarm signal to the center (Including alarm center).	
Send Email	If you enabled this function, System can send out an email to alert you when an alarm occurs.	
Tour	You need to click setup button to select tour channel. System begins 1-wiindow or multiple-window tour display among the channel(s) you set to record when an alarm occurs. See Figure 5-64.	
PTZ Activation	Here you can set PTZ movement when alarm occurs. Such as go to preset X. See Figure 5-96.	
Snapshot	Click setup button to select snapshot channel. See Figure 5-65.	

## 5.11.3.9.2 Net Alarm

The network alarm interface is shown as in Figure 5-97.

Network alarm refers to the alarm signal from the network. System does not anti-dither and sensor type setup. For setup information, please refer to chapter 5.11.3.9.1.

Local Alarm	Net Alarm IPC External Alarm IPC Offline Alarm	
🔽 Enable	1  Alarm Name	
Period	Setup	
Record Channel	Setup	
Delay	10 Sec.(10~300)	
Alarm Out	1 2 3 4 5 6	
Latch	10 Sec.(0~300)	
PTZ Activation	Setup	
🔲 Tour	Setup	
Snapshot	Setup	
Voice Prompts	File Name None 💌	
🔲 Send Email 🔲 /	Alarm Upload 🔲 Buzzer 📄 Message 🔽 Log	
	Copy OK Refresh Default	

Figure 5-97

## 5.11.3.9.3 IPC external alarm

The IPC external alarm interface is shown as in Figure 5-98.

Network alarm refers to the alarm signal from the network. System does not anti-dither and sensor type setup. For setup information, please refer to chapter 5.11.3.9.1.

Local Alarm	Net Alarm         IPC External Alarm         IPC Offline Alarm	
Channel	D8   Alarm Name	
Period Anti-Dither	Setup         Type         NC	
Record Channel	Setup	
Delay	10 Sec.(10~300)	
Alarm Out	1 2 3 4 5 6	
Latch	10 Sec.(0~300)	
PTZ Activation	Setup	
Tour	Setup	
Snapshot	Setup	
Voice Prompts	File Name  None	
Show Message	📄 Send Email 📄 Alarm Upload 📄 Buzzer 📄 Message 🔽 Log	
	Copy OK Refresh Default	



The IPC offline alarm interface is shown as in Figure 5-99.

System can generate an alarm once the network camera is offline. For setup information, please refer to chapter 5.11.3.9.1.

Local Alarm	Net Alarm IPC External Alarm IPC Offline Alarm
Channel	D8
Record Channel	Setup
Delay	10 Sec.(10~300)
Alarm Out	1 2 3 4 5 6
Latch	10 Sec.(0~300)
PTZ Activation	Setup
🔲 Tour	Setup
Snapshot	Setup
Voice Prompts	File Name None 💌
Show Message	📄 Send Email 📄 Alarm Upload 📄 Buzzer 📄 Message 🔽 Log
	Copy OK Refresh Default

Figure 5-99

#### 5.11.3.10 Abnormality

From main menu->Setup->Event->Abnormality, it includes four types: HDD/Network/User/Device. See Figure 5-100 through Figure 5-103.

HDD	Network	Username			
Event Type	No HDD	•			
Enable					
Alarm Out	123	4 5 6			
Latch	10	Sec.(0~300)			
Voice Prompts	5 File Name	None	•		
🔲 Show Messag	je 📃 Send Ema	ail 🔲 Alarm Upload	Buzzer	Message	✓ Log
	ОК	Refresh	]		

Figure 5-100

HDD	Network	User	Device	
Event Type	Disconnect	۲		
🕑 Enable				
Record Channel	1234	5 6 7 8	9 10 11 12 13	14 15 16
Delay	10 s	sec.(10~300)		
Alarm Out	1 2 3 4	5 6		
Latch	10 s	ec.(0~300)		
Voice Prompts	File Name N	one	¥	
Show Message	🗌 Send Email	Buzzer		
Message	🕑 Log			
	Save	Refresh		

Figure 5-101

HDD	Network	Username	
Event Type	Disconnect	•	
Enable			
Alarm Out	1 2 3	4 5 6	
Latch	10	Sec.(0~300)	
Voice Prompts	File Name	None	
📃 Show Message	Send Email	il 🔲 Buzzer 🔲 Message	Log
	ОК	Refresh	

Figure 5-102

HDD	Network	Username
Event Type	Illegal Login	•
Enable		
Attempt(s)	5	Times (1~10)
Lock Time	5	Min. (1~30)
🔲 Alarm Out	1 2 3	4 5 6
Latch	10	Sec.(0~300)
Voice Prompts	File Name	None
📄 Send Email 🔲	Buzzer 🔲 Mess	age 🔽 Log
	ОК	Refresh

Figure 5-103

Parameter	Function	
Event	The abnormal events include:	
Туре	HDD: No disk, disk error, disk no space;	
	<ul> <li>Network: Net disconnection, IP conflict, MAC conflict.</li> </ul>	
	User: Illegal login.	
	• Device: Temperature is too high, fan speed is abnormal. Please	
	note this function is for some series product only.	
	<ul> <li>You can set one or more items here.</li> </ul>	
	• Less than: You can set the minimum percentage value here. The	
	device can generate an alarm when capacity is not sufficient. This	
	item is for disk no space type only.	
Enable	Check the box here to enable selected function.	
Alarm Out	Please select corresponding alarm output channel when an alarm occurs. You need to check the box to enable this function.	
Latch	The alarm output can delay for the specified time after an alarm stops.	
	The value ranges from 0s to 300s. The default setup is 10 seconds. The	
	o second means there is no delaying time.	
Attempt(s)	It is to set login attempt times. Once the login attempt exceeds the	
	threshold you set here, current account will be locked. This function is	
	for illegal login only.	
Lock time	It is to set account lock time once its login attempt has exceeded the	
	threshold you set. This function is for illegal login only.	
Show	System can pop up a message to alarm you in the local host screen if	
message	you enabled this function.	

Parameter	Function
Alarm	System can upload the alarm signal to the center (Including alarm
upload	center.
Send	If you enabled this function, System can send out an email to alert you
Email	when an alarm occurs.
Buzzer	Check the box here to enable this function. The buzzer beeps when an
	alarm occurs.
Log	Check the box here, system can record the network event alarm log.

## 5.11.3.11 Alarm Out

The alarm output interface is shown as below. See Figure 5-104 Here you can set alarm output mode: auto/manual/stop.

Alarm Out	
Alarm Type	All 1 2 3
Auto	$\odot \odot \odot \odot$
Manual	$\circ \circ \circ \circ$
Stop	$\circ \circ \circ \circ$
Status	
	Save Refresh

Figure 5-104

## 5.11.4 Storage

5.11.4.1 Basic

It is to manage HDD storage space.

Step 4 From main menu->Setup->Storage->Basic.

Enter Basic interface. See Figure 5-44.

BASIC	
HDD Full	Overwrite
Pack Mode	Time Length
Auto Delete Old	ies Never
	Save Refresh Default

Figure 5-105

Step 5 Set parameters.

Parameter	Function
HDD full	It is to select working mode when hard disk is full. There are two option
	stop recording or rewrite.
	• Stop: If current HDD is full while there is no idle HDD, then system
	stops recording,
	• Overwrite: If the current HDD is full while there is no idle HDD, then
	system overwrites the previous files.
Pack	It is to specify record duration. The max value is 120 minutes.
duration	
Auto	Never: Do not auto delete old files.
delete old files	<ul> <li>Customized: input customized period here, system can auto delete corresponding old files</li> </ul>

## 5.11.4.2 Schedule

In this interfaces, you can add or remove the schedule record setup. See Figure 5-106.

There are four record modes: general (auto), motion detect, alarm and MD&alarm. There are six periods in one day.

You can view the current time period setup from the color bar.

- Green color stands for the general record/snapshot.
- Yellow color stands for the motion detect record/snapshot..
- Red color stands for the alarm record/snapshot.
- Blue color stands for MD&alarm record/snapshot.



Time Period 1	00:00	24:00	Regular		Alarm	MD&Alarm
Time Period 2	00:00	24:00	Regular	🗆 MD	Alarm	MD&Alarm
Time Period 3	00:00	24:00	Regular		Alarm	MD&Alarm
Time Period 4	00:00	24:00	Regular		Alarm	MD&Alarm
Time Period 5	00:00	24:00	Regular		Alarm	MD&Alarm
Time Period 6	00:00	24:00	Regular		🗌 Alarm	MD&Alarm
All S	unday 🗌 Monda	y 🗌 Tuesday 🗌	Wednesday 🗌	] Thursda	/ 🗆 Friday	Saturday
🗹 Holiday						
		Save	Cancel	_		
		Save	Cancer			

Figure 5-107

×
Channel 2
Channel 4
Channel 6
Channel 8
Channel 10
Channel 12
Channel 14
Channel 16
Channel 18
Channel 20
Channel 22
Channel 24
Cancel

Figure 5-108

Parameter	Function
Channel	Please select a channel from the dropdown list.
Pre-record	Please input pre-record time here. The value ranges from 0 to 30.
Redundancy	Check the box here to enable redundancy function. Please note this function is null if there is only one HDD.
Snapshot	Check the box here to enable snapshot function.
Holiday	Check the box here to enable holiday function.
Setup	Click the Setup button, you can set record period. See Figure 5-107. There are six periods in one day. If you do not check the date at the

Parameter	Function
	bottom of the interface, current setup is for today only. Please click Save button and then exit.
Сору	Copy function allows you to copy one channel setup to another. After setting in channel, click Copy button, you can go to interface Figure 5-108. You can see current channel name is grey such as channel 1. Now you can select the channel you want to paste such as channel 5/6/7. If you want to save current setup of channel 1 to all channels, you can click the first box "ALL". Click the OK button to save current copy setup. Click the OK button in the Encode interface, the copy function succeeded.

5.11.4.3 HDD Manager

5.11.4.3.1 Local Storage

The local interface is shown as in Figure 5-109. Here you can see HDD information. You can also operate the read-only, read-write, redundancy (if there are more than on HDD) and format operation.

Device Name	HDD Operation	Status	Free Space/Total Space
SATA-2	Read-Write 💌	Normal	129.77GB/1862.88GB
Save Refresh Fo	ormat		

Figure 5-109

## 5.11.4.3.2 HDD

The HDD interface is to set HDD group. See Figure 5-110.

Local Storage HDD	FTP
HDD	HDD Group
1	-
2	1
Save Refresh	

Figure 5-110

## 5.11.4.3.3 FTP

Configure FTP information on the FTP interface. See Figure 5-111.

Set the FTP as your remote storage location. System can save record file or snapshot picture to the FTP once the network is offline or malfunction.

FTP			
🗹 Enable 🔿 FTP	<ul> <li>SFTP (Recommended)</li> </ul>		
Host IP	0.0.0.0	*	
Port	22	*(1~65535)	
Username			
Password		Anonymous	
Remote Directory			
File Size	0	Μ	
Image Upload Interval	2	S	
Channel	D4		
Channel	D1 💌		
Weekday	Thursday 💌		
Period1	00 : 00 - 24 : 00	ALARM&IVS&POS MD	Regular
Period2	00 : 00 - 24 : 00	ALARM&IVS&POS MD	Regular
	Test		
	OK Ref	Default	

Figure 5-111

## 

FTP transmits data with clear text mode and SFTP transmits data with encrypted mode. SFTP is recommended.

- Host IP: The host IP you have installed the FTP server.
- Port: The default SFTP port number is 22 and the default FTP port number is 21.
- User name/Password: The account for you to access the FTP server.
- Remote directory: The folder you created under the root path of the FTP according to the corresponding rule.
  - If there is no remote directory, system can auto create different directories according to the IP, time and channel.
  - ♦ If there is remote directory, system can create corresponding folder under the FTP root path and then create different folders according to IP address, time and channel.
- File length: File length is upload file length. When setup is larger than the actual file length, system will upload the whole file. When setup here is smaller than the actual file length, system only uploads the set length and auto ignore the left section. When interval value is 0, system uploads all corresponding files.
- Image upload interval: It is the image upload interval. If the image upload interval is larger than the image snapshot frequency, system just uploads the lasted image.
  - If the image interval is 5 seconds and the snapshot frequency is 2 seconds, system will send out the latest image at the buffer at 5 seconds.
  - If the image upload interval is smaller than the snapshot frequency, system will upload at the snapshot frequency. For example, if the image interval is 5 seconds and the snapshot frequency is 10 seconds, system will send out the image at 10 seconds.
  - ♦ From main menu->Setting->Camera->Encode->Snapshot to set snapshot frequency.
- Channel: Select a channel from the dropdown list and then set week, period and record type.

- Week day/Period: Please select from the dropdown list and for each day, you can set two periods.
- Type: Please select uploaded record type (Alarm/intelligent/motion detect/regular). Please check the box to select upload type.

## 5.11.4.4 Record Control

The interface is shown as in Figure 5-112.

Record														
Main Stream	All	D8	D11	D13	D14	D15	D17	D18	D19	D20	D21	D22	D23	024
Auto	۲	۲	۲	۲	۲	۲	۲	۲	۲	۲	۲	۲	۲	۲
Manual	$\odot$	$\odot$	$\odot$	$^{\odot}$	$\odot$									
Stop	$\odot$	$\odot$	$\odot$	$^{\odot}$	$^{\odot}$	$\odot$	$\odot$	$^{\odot}$	$\odot$	$\odot$	$\odot$	$\odot$	$\odot$	$\odot$
Sub Stream1														
Auto	$\odot$	$\odot$	$\odot$	$\odot$	$\odot$	$\odot$	$\odot$	$\odot$	$\odot$	$\odot$	$\odot$	$\odot$	$\odot$	$\bigcirc$
Manual	$\odot$	$\odot$	$\odot$	$\odot$	$\odot$	$\odot$	$\odot$	$\odot$	$\odot$	$\odot$	$\odot$	$\odot$	$\odot$	$\bigcirc$
Stop	۲	۲	۲	۲	۲	۲	۲	۲	۲	۲	۲	۲	۲	۲
Sub Stream2														
Auto	$\bigcirc$	$\odot$	$\bigcirc$											
Manual	$\bigcirc$	$\odot$	$\bigcirc$											
Stop	۲	۲	۲	۲	۲	۲	۲	۲	۲	۲	۲	۲	۲	۲
Snapshot														
Open	$\odot$	$\odot$	$\odot$	$\odot$	$\odot$	$\odot$	$\bigcirc$	$^{\odot}$	$\odot$	$\odot$	$\bigcirc$	$\bigcirc$	$\bigcirc$	$\odot$
Stop	۲	۲	۲	۲	۲	۲	۲	۲	۲	۲	۲	۲	۲	۲

Figure 5-112

Parameter	Function
Channel	Here you can view channel number. The number displayed here is the max channel amount of your device.
Status	There are three statuses: schedule, manual and stop.
Schedule	System enables auto record function as you set in record schedule setup (general, motion detect and alarm).
Manual	It has the highest priority. Enable corresponding channel to record no matter what period applied in the record setup.

Stop	Stop current channel record no matter what period applied in the
	record setup.
Start all/ stop all	Check the corresponding All button, you can enable or disable all channels record.

#### 5.11.4.5 RAID Manager

#### Important

Please make sure your purchased product support the RAID function, otherwise you cannot see the following interface.

RAID (redundant array of independent disks) is a data storage virtualization technology that combines multiple physical HDD components into a single logical unit for the purposes of data redundancy, performance improvement, or both.

# Note

- RAID function is for some series product only. Slight difference may be found on the user interface.
- Right now, NVR supports RAID0, RAID1, RAID5, RAID6, and RAID 10. Local hotspare supports RAID1, RAID5, RAID6, and RAID10.
- Refer to the following table for detailed information.

RAID Type	HDD Amount
RAID0	At least 2 HDDs.
RAID1	Only 2 HDDs.
RAID5	At least 3 HDDs. Usually recommend the RAID5 consists of 4 to 6 HDDs.
RAID6	At least 4 HDDs.
RAID10	At least 4 HDDs.

## 5.11.4.5.1 RAID Config

It is for you to manage RAID HDD. It can display RAID name, type, free space, total space, status and etc. Here you can add/delete RAID HDD.

Click Add button to select RAID type and then select HDDs, click OK button to add. See Figure 5-113.

## One click to create RAID

- Click it to automatically create RAID5.
- For create RAID function, you can select the physical HDD that does not included in the RAID group or the created disk array to create a RAID5. You can refer to the following situations:
- There is no RAID, no hotspare disk: System directly creates the RAID5 and creates one hotspare disk at the same time.
- There is no RAID, but there is a hotspare disk: System creates the RAID5 only. It uses previous hotspare disk.
- There is RAID: System cancel the previous RAID setup and then create the new RAID5. System creates the hotspare disk if there is no one. System uses previous hotspare disk if there is hotspare disk available.
- The background will format the virtual disk.

## Create manually

- Step 4 Select RAID type first and then follow the prompts to set HDD amount.
- Step 5 Click Create Manually button, system pops up dialogue box to warning you it is going to clear all data.
- Step 6 Click OK button to complete the operation.

	📖 No	ote				
	Click 🎽	to delete	RAID.			
	Raid Config					
-	Name	Туре	Status	Remain/Total	Detail	Delete
	Add	Hotspare	Refresh			

Figure 5-113

## 5.11.4.5.2 Hotspare disks

In Figure 5-113, click hotspare button, you can add the hot spare HDD. See Figure 5-114. The type includes two options:

- Global: It is global hotspare disk. When any RAID becomes degrading, it can replace and build the RAID.
- Local: It is local hotspare disk. When the specified RAID becomes degrading, it can replace and build the RAID.

Select a hot spare device and then click Delete button. Click Apply button to delete.

Hotspar	e					×
Туре	Global	~				
	Name		Physical		Capacity	
						×
						~
					Add	
	Name	Physical	Capacity	Raid nan	ne Type	
					Delete	

Figure 5-114

#### 5.11.4.6 Storage

#### 5.11.4.6.1 Main Stream

The main stream interface is shown as in Figure 5-115. Here you can set corresponding HDD group to save main stream.

Channel	HDD	Group									
Channel 1	1	<b>~</b>	Channel 2	1	<b>~</b>	Channel 3	1	<b>~</b>	Channel 4	1	<b>~</b>
Channel 5	1	<b>~</b>	Channel 6	1	~	Channel 7	1	×	Channel 8	1	<b>~</b>
Channel 9	1	×	Channel 10	1	×	Channel 11	1	✓	Channel 12	1	~
Channel 13	1	×	Channel 14	1	×	Channel 15	1	<b>~</b>	Channel 16	1	<b>~</b>
Channel 17	1	×	Channel 18	1	×	Channel 19	1	✓	Channel 20	1	~
Channel 21	1	×	Channel 22	1	<b>~</b>	Channel 23	1	×	Channel 24	1	<b>~</b>
Channel 25	1	×	Channel 26	1	×	Channel 27	1	✓	Channel 28	1	~
Channel 29	1	×	Channel 30	1	×	Channel 31	1	×	Channel 32	1	~

Figure 5-115

#### 5.11.4.6.2 Sub Stream

The sub stream interface is shown as in Figure 5-116.

Here you can set corresponding HDD group to save sub stream.

Channel	HDD (	Group	Channel	HDD (	Group	Channel	HDD	Group	Channel	HDD	Group
Channel 1	1	<b>~</b>	Channel 2	1	<b>~</b>	Channel 3	1	~	Channel 4	1	<b>~</b>
Channel 5	1	<b>~</b>	Channel 6	1	<b>~</b>	Channel 7	1	~	Channel 8	1	~
Channel 9	1	~	Channel 10	1	<b>~</b>	Channel 11	1	~	Channel 12	1	<b>~</b>
Channel 13	1	~	Channel 14	1	<b>~</b>	Channel 15	1	<b>~</b>	Channel 16	1	<b>~</b>
Channel 17	1	~	Channel 18	1	<b>~</b>	Channel 19	1	~	Channel 20	1	<b>~</b>
Channel 21	1	~	Channel 22	1	<b>~</b>	Channel 23	1	<b>~</b>	Channel 24	1	<b>~</b>
Channel 25	1	~	Channel 26	1	~	Channel 27	1	~	Channel 28	1	~
Channel 29	1	~	Channel 30	1	~	Channel 31	1	~	Channel 32	1	~

#### Figure 5-116

#### 5.11.4.6.3 Snapshot

The snapshot interface is shown as in Figure 5-117. Here you can set corresponding HDD group to save snapshot picture.

Channel	HDD	Group	Channel	HDD	Group	Channel	HDD	Group	Channel	HDD	Group
Channel 1	1	~	Channel 2	1	~	Channel 3	1	<b>~</b>	Channel 4	1	~
Channel 5	1	×	Channel 6	1	×	Channel 7	1	×	Channel 8	1	~
Channel 9	1	~	Channel 10	1	~	Channel 11	1	×	Channel 12	1	~
Channel 13	1	~	Channel 14	1	~	Channel 15	1	×	Channel 16	1	~
Channel 17	1	~	Channel 18	1	~	Channel 19	1	✓	Channel 20	1	~
Channel 21	1	~	Channel 22	1	~	Channel 23	1	✓	Channel 24	1	~
Channel 25	1	~	Channel 26	1	~	Channel 27	1	×	Channel 28	1	~
Channel 29	1	~	Channel 30	1	~	Channel 31	1	~	Channel 32	1	~

Figure 5-117

## 5.11.5 Setting

5.11.5.1 General

The general interface includes general, date/time and holiday setup.

5.11.5.1.1 General

The general interface is shown as in Figure 5-118.

General	Date&Time	Holiday	
Device Name	NVR		
Device No.	8		
Language	ENGLISH	•	
HDD Full	Overwrite	•	
Pack Duration	60	Min.	
Auto Logout	10	Min. (0-60)	
Startup Wizard			
Navigation Bar			
IPC Time Sync	24	Hour	
	ОК	Refresh	Default



Parameter	Function
Device ID	It is to set device name.
Device No.	It is device channel number.
Language	You can select the language from the dropdown list.
	Please note the device needs to reboot to get the modification
	activated.

Video	This is to display video standard such as PAL.
Standard	
Auto logout	Here is for you to set auto logout interval once login user remains
	inactive for a specified time. Value ranges from 0 to 60 minutes.
IPC Time	You can input an interval here to synchronize the NVRtime and IPC
Sync	time.
Navigation	Check the box here, system displays the navigation bar on the
bar	interface.

## 5.11.5.1.2 Date and time

The date and time interface is shown as in Figure 5-119

General	Date&Time Holiday
Date Format	YYYY MM DD
Time Format	24-HOUR
Date Separator	-
Time Zone	GMT+08:00
System Time	2017 - 04 - 20 16 : 01 : 10 Sync PC
DST	
DST Type	🔿 Date 💿 Week
Start Time	Jan 💌 Last Week 💌 Sunday 💌 00 : 00
End Time	Jan 💌 Last Week 💌 Sunday 💌 00 : 00
NTP	
Server	time.windows.com Manual Update
Port	123 (1~65535)
Interval	60 Min. (0~65535)
	OK Refresh Default

Figure 5-119

Parameter	Function
Date format	Here you can select date format from the dropdown list.
Time Format	There are two options: 24-H and 12-H.
Time zone	The time zone of the device.
System time	It is to set system time. It becomes valid after you set.
Sync PC	You can click this button to save the system time as your PC current time.

DST	Here you can set day night save time begin time and end time. You can set according to the date format or according to the week format.
NTP	You can check the box to enable NTP function.
NTP server	You can set the time server address.
Port	It is to set the time server port.
Interval	It is to set the sync periods between the device and the time server.

## 5.11.5.1.3 Holiday Setup

Holiday setup interface is shown as in Figure 5-120.

Here you can click Add holidays box to add a new holiday and then click Save button to save.

General		Date&Time	Holiday						
No.	Status	Holiday Name	_	Date	Duration	Repeat Mode	Edit	Delete	
1	Open 💌			4.19	1 day	Always	2	•	~
									Ŧ
Add Holida OK		Refresh Defau	+						
UK		Cerrestr Defau	11						

Figure 5-120

5.11.5.2 Display

Display interface includes GUI, TV adjust, Tour and Customized split.

5.11.5.2.1 Display

Here you can set background color and transparency level. See Figure 5-121.

Display	Tour
Resolution	1280*1024
Color Mode	Standard
Transparency	⊲ ()⊳0%
Time Display	
Channel Display	
Image Enhance	
Auto Logout	10 Minute(0-60)
Startup Wizard	
Navigation Bar	
Original Scale	Set
Display the intelligent	t 🗸
rules	
	Save Refresh Default

Figure 5-121

Parameter	Function					
Resolution	There are four options: 1920×1080, 1280×1024(default),					
	1280×720, 1024×768. Please note the system needs to reboot to					
	activate current setup.					
Color mode	Please select from the dropdown list.					
Transparency	Here is for you to adjust transparency. The value ranges from 128					
	to 255.					
Time	Check the box here, you can view system time and channel					
title/channel	number on the monitor video.					
title						
Image	Check the box; you can optimize the margin of the preview video.					
enhance						
Startup	Once you check the box here, system will go to the startup wizard					
wizard	directly when the system restarts the next time. Otherwise, it will go					
	to the login interface.					
Navigation	Check the box here, system displays the navigation bar on the					
bar	interface.					
Original scale	Click the Set button to select a channel, it can restore original scale.					
Auto logout	Here is for you to set auto logout interval once login user remains					
	inactive for a specified time. Value ranges from 0 to 60 minutes. 0					
	means there is no standby time. After the auto logout, the user					
	needs to input user name and password to login again.					
-------------	---					
Display	Check the box to enable IVS function, system can display IVS rule					
intelligent	on the preview interface.					
rule(s)						

## 5.11.5.2.2 Tour

The tour interface is shown as in Figure 5-122. Here you can set tour interval, split mode, motion detect tour and alarm tour mode.

Display		Tour	
Enable Tour			
Interval	5		Second(5-120)
Window Split	View 1		<b>M</b>
	32 🗹	Channel Group	+
	1 🗹	1	
	2 🗹		
	3 🗹		
	4 🗹		
	5 🗹		
	6 🗹		
	7 🗹 8 🗹	7 8	
	8 🗹 9 🔽	8	
	10 🗹	10	
Motion Tour Type	View 1		<u>~</u>
Alarm Tour Type	View 1		<b>M</b>
	5	Save	Refresh Default

Figure 5-122

Please refer to the following sheet for detailed information.

Parameter	Function
Enable tour	Check the box here to enable tour function.
Interval	Here is for you to adjust transparency. The value ranges from 5 to 120s. The default setup is 5s.
Split	Here you can set window mode and channel group. System can support 1/4/8/9/16/25/36-window according to device channel amount.
Motion tour/Alarm tour	Here you can set motion detect tour/alarm tour window mode. System supports 1/8-window now.

## 5.11.5.2.3 Custom Split

From main menu->Setup->System->Display->Custom split, the interface is shown as in Figure 5-123. Here you can set customized split mode.

# Note

• This function is for some series products. Please refer to the actual product for detailed information.

•	Device max su	upports 5	customized	videos.
---	---------------	-----------	------------	---------

Display	Tour	Custom S	olit		
+			25 36		压
Name	Delete				
	ОК	Refresh			

Figure 5-123

Click 🛨 and then click 🖽 💷 💷 💷 📧 to select basic mode

In regular mode, drag the mouse in the preview frame, you can merge several small windows to one window so that you can get you desired split mode.

After the setup, the selected window has the red frame.

Select the merging window, the frame is red; you can click 🛄 to cancel the merge to restore regular mode.

Click OK to exit. 5.11.5.3 RS232

The RS232 interface is shown as in Figure 5-124.

R\$232			
Function	Console	<b>~</b>	
Baud Rate	115200	<b>~</b>	
Data Bit	8	<b>~</b>	
Stop Bit	1	<b>M</b>	
Parity	None		
	Save	Refresh	Default



Please refer to the following sheet for detailed information.

Parameter	Function
Protocol	Select the corresponding dome protocol. Default setup is console.
Baud Rate	Select the baud rate. Default setup is 115200.
Data Bit	The value ranges from 5 to 8. Default setup is 8.
Stop bit	There are two options: 1/2. Default setup is 1.
Parity	There are five options: none/odd/even/space/mark. Default setup is none.

## 5.11.5.4 PTZ

The PTZ interface is shown as in Figure 5-125 (Local) and Figure 5-126 (Remote).

Before setup, please check the following connections are right:

- PTZ and decoder connection is right. Decoder address setup is right.
- Decoder A (B) line connects with NVR A (B) line.

Click Save button after you complete setup, you can go back to the monitor interface to control speed dome.

PTZ	
Channel	2
PTZ Type	Local
Protocol	PELCOD
Address	1
Baud Rate	9600
Data Bit	8
Stop Bit	1
Parity	None
	Copy Save Refresh Default

Figure 5-125

PTZ				
<b>PTZ</b> Channel PTZ Type	1 Remote	▼ ▼		
	Сору	Save	Refresh	Default

#### Figure 5-126

Please refer to the following sheet for detailed information.

Parameter	Function
Channel	Select speed dome connected channel.
PTZ Type	There are two options: local/remote.
	Please select remote type if you are connecting to the network PTZ.
	Please select local type if you are using RS485 to the PTZ camera.
Protocol	Select the corresponding dome protocol such as PELCOD.
Address	Set corresponding dome address. Default value is 1. Please note
	your setup here shall comply with your dome address; otherwise
	you cannot control the speed dome.
Baud Rate	Select the dome baud rate. Default setup is 9600.
Data Bit	The value ranges from 5 to 8. Default setup is 8. Please set according to the speed dome dial switch setup.
Stop bit	The value ranges from 1 to 2. Default setup is 1. Please set according
	to the speed dome dial switch setup.
Parity	The options include non/odd/even/space/null. Default setup is none. Please set according to the speed dome dial switch setup.

## 5.11.5.5 POS

Connect the NVR to the POS, it can receive the POS information and overlay on the corresponding record.

Note

POS info overlay and playback function is for 1-window only.

From main menu->Setting->System->POS, you can go to the following interface. See Figure 5-127.

POS								
			Connect Type	Protocol	Status	Modify		
	1	pos	Net	POS	Off	2	•	~
								Ŧ
Add	Delete							

Figure 5-127

Click Add, you can see the following dialogue box. See Figure 5-128.

Add	Ε	×
Enable		
Name	pos	
Connect Type	Net Set	
Protocol Type	POS 💌	
Transaction Start		
Transaction End		
Line Delimiter		
Ignore String	Case Sensitive	
NetWork Overtime	30 (5~900) s	
CHANNEL		
	OK Cancel	

Figure 5-128

Check the box to enable POS function, Click Set button; you can see the following interface. See Figure 5-129.

Modify		×
Source IP	192 . 168 . 0 . 1 Port 37777	
Destination IP	172 . 11 . 1 . 12 Port 38800	
	OK Cancel	



Set source IP and destination IP, and then click OK. System goes back to Figure 5-128.

- Source IP: POS device IP address.
- Destination IP: NVR IP address. •

In Figure 5-128, click Channel Set button, select the channel you want to overlay POS information. Click OK button to complete the setup.

Tips



Click it to delete POS setup.



Click it to change setup information.

#### 5.11.5.6 Voice

The audio function is to manage audio files and set schedule play function. It is to realize audio broadcast activation function.

#### 5.11.5.6.1 File List

From main menu->Setup->System->Voice->File list, here you can add audio file, or delete audio file. See Figure 5-130.

File Size(Byte)	Delete
3953561	• ·
	<u>×</u>
	3953561

Figure 5-130

Click Add button, you can add audio file and import the audio file via the local computer. See Figure 5-131.

Choose File to	Upload					? 🔀
Look jn:	🞯 Desktop		~	G 🖻	بي 🥙	
My Recent Documents Desktop	Wy Computer My Documents My Network Pla Adobe Acrobat Microsoft Office Microsoft Office	7.0 Professional Access 2003 PowerPoint 2003				
My Documents						
My Computer	<					>
	File <u>n</u> ame:				~	<u>O</u> pen
My Network	Files of type:	All Files (*.*)			~	Cancel

Figure 5-131

## 5.11.5.6.2 Schedule

It is to set schedule broadcast function. You can play the different audio files in the specified periods. From main menu->Setup->System->Voice->.Schedule, you can see the following interface. See Figure 5-132.

		Peri	od	Schedule		interval		Repeat Playback	Output	
Enable	00 : 00	]-[	24 : 00	None	•	60	min.	0	Mic	•
Enable	00 : 00	]-[	24 : 00	None	•	60	min.	0	Mic	•
📄 Enable	00 : 00	]–[	24 : 00	None	•	60	min.	0	Mic	•
🔲 Enable	00 : 00	]-[	24 : 00	None	•	60	min.	0	Mic	•
Enable	00 : 00	]-[	24 : 00	None	•	60	min.	0	Mic	•
Enable	00 : 00	]_[	24 : 00	None	-	60	min.	0	Mic	•

Figure 5-132

Please refer to the following sheet for detailed information.

Parameter	Function
Period	There are six periods. Check the box to enable current setup.
Repeat	It is to set audio file repeat times in the specified period.
Interval	It is the audio file repeated interval in the specified period.
Output port	There are two options: MIC (default)/audio. When reuse the MIC port and bidirectional talk port, the bidirectional port has the higher priority. Please note some series product does not support audio function.

# D<sub>Note</sub>

- The audio file end time depends on the audio file size and the interval setup.
- Priority: Bidirectional talk>Event trigger alarm>Trial listening>Audio schedule broadcast.

## 5.11.5.7 Account

D Note

- For the user name, the string max length is 31-byte, and for the user group, the string max length is 15-byte. The user name can only contain English letters, numbers and "\_", "@", ".".
- The default user amount is 64 and the default group amount is 20. System account adopts two-level management: group and user. The user authorities shall be smaller than group authorities (The **admin** user authorities are set by default).
- For group or user management, there are two levels: admin and user. The user name shall be unique and one user shall only belong to one group.

## 5.11.5.7.1 User name

From main menu->Setup->System->Account->Account, enter account interface. See Figure 5-133.



#### Add user

It is to add a name to group and set the user rights.

Step 1 Click Add user button.

Enter add user interface. See Figure 5-134.

Step 2 Here you can input the user name and password and then select one group for current user.

Add User			i
User Password	Low Middle Hig	ab	
Confirm Password			
Group	admin	•	
User MAC			
Memo			
Period	Setting		
Authority			
System	Playback	Monitor	
	YSTEM SYSTEM VENT NETWO ACKUP DEVICE		I MANUAL CONTROL I CAMERA
	Save	Cancel	

Figure 5-134

Step 3 Click the Set button after the period. It is to set valid period to use current account. See Figure 5-135.

Period															×
	0 2	4		6	8	10	12	14	16	18	20	22	24		
Sunday														Setting	
Monday														Setting	
Tuesday														Setting	
Wednesday														Setting	
Thursday	_												-	Setting	
Friday	_													Setting	
Saturday	-												-	Setting	
		Sunday	m M	londav	ПТ	uesday	🗆 We	dnesdav	( 🗆 Т	hursdav	Eri	dav 「	Satu	rdav	
Period 1		D : 00	] - [	24 ;		]									
Period 2	0	00 : 00	-  -	24 :	00	ĺ									
Period 3	0	00 : 00	7-6	24 :	00	ī									
Period 4	0	D : 00	7-6	24 :	00	ī									
Period 5	0	00 : 00	7 - [	24 :	00	1									
Period 6	0	D : 00	] -[	24 :	00										
				Defa	ult		Save		C	ancel					

Figure 5-135

- Click Setting to set the periods. Or you can draw on the interface directly. There are six periods in one day. Or you can input start time and end time directly.
- Check the box before the date, the settings are for the selected date(s).
- Check the box before the period1-6, it is to enable the period function.

Step 4 Click Save to complete the setup.

# Note

Please note the user rights shall not exceed the group right setup. For convenient setup, please make sure the general user has the lower rights setup than the admin.

#### Modify user

It is to modify the user property, belonging group, password and rights. See Figure 5-136.

Modify User					E
User	test		•		
Group	admin		-		
Memo					
User MAC					
Period	Sett	ng			
Modify Password					
Authority					
System	Play	/back	Monitor		
<b>⊠</b> AII					
	SYSTEM	SYSTEM	M INFO	MANUAL CONTROL	
	EVENT	<b>NETWO</b>	RK	CAMERA	
SECURITY SECURITY	BACKUP		MAINTENANCE		
		Save	e Canc	cel	

Figure 5-136

# Note Note

For admin, you can change the email information. See Figure 5-137.

Modify User		Ð
User	admin 💌	
Group	admin 👻	
Memo	admin 's account	
User MAC		
Modify Password		
Email Address	z***@tech.com	
Authority		
System	Playback Monitor	
All		
	SYSTEM SYSTEM INFO	
	Save Cancel	
	Jave Galicer	

## Figure 5-137

## Modify password

It is to modify the user password.

Step 1 In Modify user interface, click Modify password box. See Figure 5-138.

Modify User	
User	admin 💌
Group	admin 💌
Memo	admin 's account
User MAC	
Modify Password	
Old Password	
New Password	
	Low Middle High
Confirm Password	
Email Address	z***@tech.com
Authority	
System	Playback Monitor
STORAGE	ISTEM INFO IMANUAL CONTROL IENT INETWORK ICAMERA ACKUP IDEVICE MAINTENANCE
	Save Cancel

Figure 5-138

- Step 2 Input old password, and then input new password and confirm.
- Step 3 Click Save button.



The password ranges from 8 to 32 digitals. It can contain letters, numbers and special characters (excluding "!", "!", ";", "&"). The password shall contain at least two categories. Usually we recommend the strong password.



STRONG PASSWORD RECOMMENDED-For your device own safety, please create a strong password of your own choosing. We also recommend you change your password periodically especially in the high security system.

## 5.11.5.7.2 Group

It is to add/remove group, modify group password and etc. From main menu->Setup->System->Account->Account. Click Group tab, the interface is shown as in Figure 5-139.



Figure 5-139

## Add group

It is to add group and set its corresponding rights.

Step 1 Click Add group button. Enter add group interface. See Figure 5-140.

Add Group						×
Group Name Memo Authority						
System	Play	back	Мо	nitor		
AII ACCOUNT STORAGE SECURITY	SYSTEM EVENT BACKUP	SYSTEM		ICE	MANUAL CONTROL	
		Save		Cancel	]	

Figure 5-140

- Step 2 Input the group name and then check the box to select the corresponding rights. It includes: system, playback, and monitor.
- Step 3 Click Save button.

## Modify group

Step 1 Select a group and then click . See Figure 5-141.

Modify Group				×
Group Name Group Name Memo Authority	user user user grou	p		
System	Play	/back	Monitor	
AII ACCOUNT STORAGE SECURITY	SYSTEM EVENT BACKUP			MANUAL CONTROL
		Save	Cancel	

Figure 5-141

Step 2 Change corresponding information and then click Save button.

#### 5.11.5.7.3 ONVIF User

When the camera from the third party is connected with the NVRvia the ONVIF user, please use the verified ONVIF account to connect to the DVR.

Step 1 From main menu->Setting->System->Account->ONVIF User.

Enter ONVIF user interface. See the following figure.

ACCOUNT	ONVIF User				
No.		User	Group Name	Modify	Delete
1		admin	admin	Ø	•
Add User					

Figure 5-142

Step 2 Click Add user button.

Enter add user interface. See Figure 5-143.

Add User		×
User		
Password		
	Low Middle High	
Confirm Password		
Group	admin 💌	
	Save Cancel	

Figure 5-143

- Step 3 Set user name, password and then select group from the dropdown list.
- Step 4 Click Save to complete setup.



## 5.11.5.8 Security

To enhance device network security and protect device data, please set the access right of the IP host (IP host here refers to the IP PC or the server). After you enabled trusted sites function, only the IP listed below can access current NVR.

If you enable blocked sites function, the following listed IP addresses cannot access current NVR.

Step 1 From main menu->Setting->System->Security.

Enter security interface. See Figure 5-144.

Step 2 Check the Enable box.

Select trusted sites/block sites.

- Enable trusted site function and then add the whitelist.
- Enable blocked site function and then add the blacklist.

Step 3 Set parameters.

- Start address/end address: Select one type from the dropdown list, you can input IP address in the start address and end address. Now you can click Add IP address or Add IP section to add. System supports max 64 IP addresses.
  - a) For the newly added IP address, it is in enable status by default. Remove the  $\sqrt{}$  before the item, and then current item is not in the list.
  - b) System max supports 64 items.

  - d) System automatically removes space if there is any space before or after the newly added IP address.
  - e) System only checks start address if you add IP address. System check start address and end address if you add IP section and the end address shall be larger than the start address.

- System may check newly added IP address exists or not. System does not add if input IP address does not exist.
- Delete: Click it to remove specified item.
- Edit: Click it to edit start address and end address. See Figure 5-145. System can check the IP address validity after the edit operation and implement IPv6 optimization.
- Default: Click it to restore default setup. In this case, the trusted sites and blocked sites are both null.

Step 4 Click Save to complete setup.

- If you enabled trusted sites, only the IP in the trusted sites list can access the device.
- If you enabled blocked sites, the IP in the blocked sites cannot access the device.

Access Right					
Enable					
Trusted Sites	Blocked Sites				
		IP Address	Edit	Delete	
					^ ^
					*
Add					
Save Refre	esh Default				

Figure 5-144

Add		X
IP Segment 💌 IPv4 💌	1.0.0.1	
	1.0.0.1	
Save	Cancel	

Figure 5-145

## 5.11.5.9 Auto maintain

The auto maintain interface is shown as in Figure 5-146.

Here you can select auto reboot and auto delete old files interval from the dropdown list. If you want to use the auto delete old files function, you need to set the file period. Click Manual reboot button, you can restart device manually.

Auto Maintain			
Auto Reboot	Saturday	02:00	
Auto Delete Old Files	Customized	✓ 31	Days Ago
	Manual Reboot	1	
	Save	Refresh	

Figure 5-146

## 5.11.5.10 Import/Export

The interface is shown as in Figure 5-147. This interface is for you to export or import the configuration files.

Import&Export	
Import Config File Config Export	Browse Config Import
Coning Export	

Figure 5-147

Please refer to the following sheet for detailed information.

Parameter	Function
Browse	Click to select import file.
Import	It is to import the local setup files to the system.
Export	It is to export the corresponding WEB setup to your local PC.

## 5.11.5.11 Default

The default setup interface is shown as in Figure 5-148.

Here you can select Network/Event/Storage/Setting/Camera. Or you can check the All box to select all items.

Default			
II 🔍			
	VETWORK	VENT	
STORAGE	SYSTEM		
STORAGE	IN STSTEM		
Default	Factory Reset		

Figure 5-148

5.11.5.12 Upgrade



- During the upgrade process, do not unplug the power cable, network cable, or shutdown the device.
- Improper upgrade program may result in device malfunction!

There are two upgrade modes: file upgrade and online upgrade.

5.11.5.12.1 File Upgrade

The upgrade interface is shown as in Figure 5-149.

Please select the upgrade file and then click the update button to begin update. Please note the file name shall be as \*.bin.

Upgrade	
Select Firmware File	Browse Upgrade

Figure 5-149

#### 5.11.5.12.2 Cloud Upgrade

When the NVR is online, you can use the cloud upgrade to update the firmware.

# D Note

Make sure the NVR has properly connected to the network.

## **Version Detection**

The version detection includes auto detection and manual detection. It displays current system version and application released date.

• Enable auto detection, NVR interacts with the cloud every day to detect if there is a new version available. When there is a new version, system marks a red point on the Upgrade tab.

# Note

To inform you upgrading firmware timely, we will collect your device information such as IP address,

device name, firmware version and serial number. The collected information is used for verifying device legality and pushing upgrade notice.

- Click manual detection to view the latest new version on the cloud.
  - > If current version is the latest one, system prompts that "It is the latest version".
  - If there is new version available, system displays new version information such as release date and corresponding release note.

## **Upgrade System**

Click Start to upgrade the system.

## 5.12 Information

## 5.12.1 Version

The version interface is shown as in Figure 5-150. Please note the following information for reference only.

Here you can view record channel, alarm input/output information, software version, release date and etc. When there is any new version, it prompts found new version. Click it, NVR goes to upgrade interface.

VERSION	
Device Type:	NVR
Record Channel:	24
Alarm In:	16
Alarm Out:	6
SN:	2J015E7YAZE4G2P
Web Version:	3.2.3.79489
Onvif Version:	2.4.1
System Version:	3.210.0003.0, Build Date: 2017-04-14

Figure 5-150

## 5.12.2 Log

Here you can view system log. See Figure 5-151.

Log		
Start Time 2013 - 1	1 - 10 00 : 00 : 00 End Time 2013 - 11 - 13 00 :	00 : 00
Types All	Search Matched 1024 logs Record Time 2013	-11-12 11:26:23 2013-11-12 11:48:43
No.	Time	Event
1	2013-11-12 11:26:23	User logged in.
2	2013-11-12 11:26:23	User logged out.
3	2013-11-12 11:26:23	User logged in.
4	2013-11-12 11:26:23	User logged out.
5	2013-11-12 11:26:23	User logged in.
6	2013-11-12 11:26:23	User logged out.
7	2013-11-12 11:26:23	User logged in.
8	2013-11-12 11:26:23	User logged out.
9	2013-11-12 11:26:23	User logged in.
10	2013-11-12 11:26:23	User logged out.
Backup		K ◀ 1/11 ► ► Go To 1 🗐 Clear

Figure 5-151

Please refer to the following sheet for log parameter information.

Parameter	Function
Туре	Log types include: system operation, configuration operation, data
	operation, event operation, record operation, user management, log
	clear.
Start time	Set the start time of the requested log.
End time	Set the end time of the requested log.
Search	You can select log type from the drop down list and then click search
	button to view the list.
	You can click the stop button to terminate current search operation.
Detailed information	You can select one item to view the detailed information.
Clear	You can click this button to delete all displayed log files. Please note system does not support clear by type.
Backup	You can click this button to backup log files to current PC.

## 5.12.3 Online User

The online user interface is shown as in Figure 5-152.

	User Name	Group Name	IP Address	User Login Time	
1	admin	admin	10.15.9.152	2013-10-24 04:31:33 PM	
2	admin	admin	10.15.9.152	2013-10-24 04:21:12 PM	
3	admin	admin	10.15.6.145	2013-10-24 04:50:01 PM	

Figure 5-152

## 5.12.4 People Counting

From main menu->Info->People counting, the interface is shown as in Figure 5-153.

Channel	1 Search Export
Report Type	Daily Report 🔹 *Daily report max has 24 hours. 🔘 Histogram 🔿 Polygon Graph
	Graph
Start Time	2016-03-29  00:00:00 End Time 2016-03-29  16:00:00
Flow Direction	🖉 🗖 Enter 🔍 Exit 🔍 Display No.
	Report

Figure 5-153

## 5.12.5 Heat Map

From main menu->Info->Heat Map, the interface is shown as in Figure 5-154.



Figure 5-154

## 5.12.6 HDD

From main menu->Info->HDD, the HDD interface is shown as in Figure 5-155. Here you can view HDD information.

HDD						
Device Name	Physical Position	Status	Free Space/Total Space	S.M.A.R.T.	Path	
sda	host_1	Normal	0GB/930.51GB		-	2
HDD Time						
Refresh	_					

Figure 5-155

# 5.13 Playback

Click Playback button, you can see an interface is shown as in Figure 5-156.

	ogøx I	
	000 x	• ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○ ○
4 6 6 7 8 8 8 9 8 1 2 3 4 6 6 7 8 8 8 8 8 8 8 8 8 8 8 8 8	Image: Sync         Image: All         Image:	Image: state

Figure 5-156

## 5.13.1 Search Record

Please set record type, record date, window display mode and channel name.

• Select Date

You can click the date on the right pane to select the date. The green highlighted date is system current date and the blue highlighted date means it has record files.

Window Split

Select window split mode. Click 🔛 to display in full screen. Click ESC button to exit. See Figure 5-157.





• Select Channel

 $1 \sim 4$  means main stream and A1 $\sim$ A4 means sub stream.

Select Record Type

Check the corresponding box to select record type. See Figure 5-158.



Figure 5-158

## 5.13.2 File List

Click File list button, you can see the corresponding files in the list. See Figure 5-159.



Figure 5-159

## 5.13.3 Playback

Select a file you want to play and then click Play button, system can begin playback. You can select to playback in full-screen. Please note for one channel, system cannot playback and download at the same time. You can use the playback control bar to implement various operations such as play, pause, stop, slow play, fast play and etc. See Figure 5-160.



Figure 5-160

## 5.13.4 Download

Select the file(s) you want to download and then click download button, you can see an interface shown as in Figure 5-161. The Download button becomes Stop button and there is a process bar for your

reference. Please go to you default file saved path to view the files.



Figure 5-161

#### 5.13.5 Load more

It is for you to search record or picture. You can select record channel, record type and record time to download. Or you can use watermark function to verify file.

5.13.5.1 Download By File

Select channel, record type, bit stream type and then input start time and end time. Click Search button, the download by file interface is shown as in Figure 5-162.

Charles Trans.		End Time	2014 - 11 - 18 23 : 5	9 : 59				
	ain Sub 💌							
	No.	File Size 403699KB	Start Time 2014-07-25 15:24:47	End Time 2014-07-25 16:00:00	File Type Regular	Bit Stream Type Main Stream	Channel 1	
	2	403099KB	2014-07-25 15:24:47	2014-07-25 16:00:00	Regular	Main Stream	2	
	3	23348KB	2014-07-25 15:24:47	2014-07-25 16:00:00	Regular	Main Stream	3	
	4	18728KB	2014-07-25 15:24:47	2014-07-25 16:00:00	Regular	Main Stream	4	
	5	18974KB	2014-07-25 15:24:47	2014-07-25 16:00:00	Regular	Main Stream	5	
	6	19211KB	2014-07-25 15:24:47	2014-07-25 16:00:00	Regular	Main Stream	6	
	7	18653KB	2014-07-25 15:24:47	2014-07-25 16:00:00	Regular	Main Stream	7	
	8	19170KB	2014-07-25 15:24:47	2014-07-25 16:00:00	Regular	Main Stream	8	
	7 8	18653KB	2014-07-25 15:24:47	2014-07-25 16:00:00	Regular	Main Stream Main Stream	7	0 1

#### Figure 5-162

Check the file(s) you want to download and there are two options for you to save the file(s).

Download to local

Click Download to local, system pops up the following interface for you to set record format and saved path. See Figure 5-163.

			E
Record Format	DAV	<b>~</b>	
Save Path	C:\RecordDownload\		Browse
	ОК	Cancel	

Figure 5-163

You can click OK to download and view the download process. After the download operation, you can see corresponding dialog box.

Download to USB

Connect the corresponding p peripheral device, and then click Download to USB button, you can see the following interface. See Figure 5-164.

annel All	Records V	Start Time End Time		0 : 00 Searc	ch		
	ain Sub 💌						
	No.	File Size	Start Time	End Time	File Type	Bit Stream Type	Channel
	1	403699KB	2014-07-25 15:24:47	2014-07-25 16:00:00	Regular	Main Stream	1
	2	19227KB	2014-07-25 15:24:47	2014-07-25 16:00:00	Regular	Main Stream	2
<b>V</b>	3	23348KB	2014-07-25 15:24:47	2014-07-25 16:00:00	Regular	Main Stream	3
	4	18728KB	2014-07-25 15:24:47	2014-07-25 16:00:00	Regular	Main Stream	4
	5	18974KB	2014-07-25 15:24:47	2014-07-25 16:00:00	Regular	Main Stream	5
	6	19211KB	2014-07-25 15:24:47	2014-07-25 16:00:00	Regular	Main Stream	6
	7	18653KB	2014-07-25 15:24:47	2014-07-25 16:00:00	Regular	Main Stream	7
	8	19170KB	2014-07-25 15:24:47	2014-07-25 16:00:00	Regular	Main Stream	8
wnload to Local D ckup Device sdb1(t Start backup		Search	Backup Type DAV 💌				1/24 ▶ ▶ Goto 1
Name		Backup Type	BUS	Left Space	Total Space	Dir	ectory
sdb1(USB D	)ISK)	DISK	USB	12.79GB	14.43GB	Na	r/sdb1

Figure 5-164

Select Backup device and backup type first and then click Start backup button.

After the download operation, you can see corresponding dialogue box.

5.13.5.2 Download by Time

Select channel, bit stream type, start time and end time.

Click Download to Local button, you can see download by time interface is shown as in Figure 5-165.

WEB SERVICE Live Plays	ack Alarm	Setup	Info	Logout	
Download by File Download by Time	Watermark				
Channel 1 Y Start Time Bit Stream Type Main Stream Y End Time Download to Local		00 : 00 : 00 23 : 59 : 59	]		
		ordDownload\	Cancel	Browse	
Back					

Figure 5-165

Set record format and saved path, you can click OK to download and view the download process. After the download operation, you can see corresponding dialog box.

#### 5.13.5.3 Watermark

Watermark interface is shown as In Figure 5-166. Please select a file and then click Verify button to see the file has been tampered with or not

Download by File Local File C:\record\root\Centre	Download by Time Watermark	Verify
Watermark Info		-
Watermark Revised Info		
No.	Malfunction type	Watermark Time
1	Normal	<u>_</u>
		~
Back		

Figure 5-166

## 5.14 Smart Playback

It is to search and playback the IVS file, human face file and plate recognition record.

D Note

- There are two types to realize intelligent analytics function.
- Smart network camera supports intelligent functions: Some smart camera supports the intelligent functions. For NVR, it just displays the intelligent alarm information from the smart network camera and set or playback the record file.
- NVR supports intelligent functions: The connected network camera does not support intelligent video analytics function. The NVR supports the analytics function.
- This function is to playback the intelligent record file of the smart camera.

#### 5.14.1 IVS (Behavior Analytics)

It is to search and play back the IVS record files.

Step1 Select Smart Playback-> IVS.

The IVS interface is displayed. See Figure 5-167.



Figure 5-167

Step2 Select the Channel and choose Start Time and End Time.

#### Step3 Click Search.

The pictures meeting the conditions are displayed. See Figure 5-168.



Figure 5-168

## 

Click Delete on the main interface of Smart Playback to clear the set detect type, channel number, start time and end time.

Step4 Click the image and you can view the record file.

- Select a file and then click Backup, you can save current file to peripheral storage devices.
- Select a file and then click Locked, you can lock current file in case it will be overwritten in the future
- Select a file and then click <sup>Tag</sup>, you can mark the time of the detected event.

#### 5.14.2 Plate Recognition

It is to search and playback the record file containing the plate number.

Step1 Select Smart Playback-> ANPR.

The ANPR interface is displayd. See Figure 5-169.

> IVS	Channel	D1	•	
> FACE DETECTION	Start Time	2018 - 03 - 12	00 : 00 : 00	
> FACE RECOGNITION	End Time	2018 - 03 - 16	23 : 59 : 59	Search
> ANPR	License			
> HUMAN BODY DETE				
> ANPR		2018 - 03 - 16	23 : 59 : 59	Search



- Step2 Select Channel, Start Time and End Time and set the license number.
  - The system supports plate fuzzy search.
  - All plates will be searched by default if the license number is not set.
- Step3 Click Search. The images meeting the conditions are displayed. See Figure 5-170.

30H¢ ■⊈∰1581 03 201801-230937-58	△○10C 年時代別 D3 2018-01-23 09:38:37	O1C8 在使191 D3 2018-01-23 09:58:57	Qa x
			00
			ADDITION AND AND A
🖻 Export Plat. 📌 Tag 📔 Locked	🖻 Backup	🔳 AIL 🖂 4 1/1 🕨 🗎 📦	← Back

#### Figure 5-170

Step4 Click the image and you can view the record file.

- Click Export Plate to export the plate information to local.
- Select a file and then click Backup, you can save current file to peripheral storage devices.
- Select a file and then click Locked, you can lock current file in case it will be overwritten in the future
- Select a file and then click Tag , you can mark the time of the detected event.

#### 5.14.3 Human Face

System can search the record containing human face and then replay it.

#### Important

Before you use this function, please make sure current channel has enabled human face detection function. Please refer to chapter 5.11.3.4 (Setup->Event->Face Detection) for detailed information.

Step1 Select Samrt Playback-> Face Detection.

The Face Detection interface is displayed. See Figure 5-171.

> IVS	Channel	D3	•
> FACE DETECTION	Start Time	2018 - 03 - 12	00 : 00 : 00
> FACE RECOGNITION	End Time	2018 - 03 - 16	23 : 59 : 59 Search
➤ ANPR ➤ HUMAN BODY DETE	Gender	All	•
PHOMAN BODT DETE	Age	All	
	Glasses	All	
	Beard	All	
	Mask	All	

Figure 5-171

Step2 Select Channel, Start Time and End Time and set the filter conditions.

Step3 Click Search.

The images meeting the conditions are displayed. See Figure 5-172.

🛄 NOTE

The following human faces have been modified for privacy reason. The actually snapshot images have high definition.



Figure 5-172

Step4 Click the image and you can view the record file.

- Select a file and then click Backup, you can save current file to peripheral storage devices.
- Select a file and then click Locked, you can lock current file in case it will be overwritten in the future
- Select a file and then click Tag , you can mark the time of the detected event.

## 5.15 Alarm

Click alarm function, you can see an interface is shown as Figure 5-173.

Here you can set device alarm type and alarm sound setup (Please make sure you have enabled audio function of corresponding alarm events.).

	No.	Time	Alarm Type	Channel
Alarm Type Motion Detection				
Local Alarm				
Tampering				
HDD Error				
Video Loss				
HDD Full				
IPC Ext Alarm				
IPC Offline Alarm				
Intelligent Detect				
AUDIO DETECT				
UserLock				
Scene Change				
RAID Alarm				
0				
Operation  Message				
moodge				
Alarm Sound				
Play Alarm Sound				
Sound Path Select				

## Figure 5-173

Please refer to the following sheet for detailed information.

Туре	Parameter	Function				
Alarm	Video loss	System alarms when video loss occurs.				
Туре	Motion detection	System alarms when motion detection alarm				
		occurs.				
	Tampering	System alarms when camera is viciously masking.				
	Disk full	System alarms when disk is full.				
	Disk error	System alarms when disk error occurs.				
	External alarm	Alarm input device sends out alarm.				
	IPC external	It refers to the on-off signal from the network				
	alarm	camera. It can activate the NVR local activation				
		operation.				
	IPC offline alarm	System can generate an alarm when the network				
		camera and the NVR are disconnected.				
	Intelligent detect	System alarms when IVS alarm occurs.				
	Audio detect	System alarms when audio detect is abnormal.				
Operation	Prompt	Check the box here, system can automatically pops				
		up an alarm icon on the Alarm button in the main				
		interface when there is an alarm.				
Alarm	Play alarm	System sends out alarm sound when an alarm				
Sound	Sound sound occurs. You can specify as you wish.					
	Sound path	d path Here you can specify alarm sound file.				

# 5.16 Log out

Click log out button, system goes back to log in interface. See Figure 5-174. You need to input user name and password to login again.

(a)hua		
Username:	admin	]
Password:		
Type:	TCP •	Forgot password?
	• LAN • WAN	_
	Login Cancel	

Figure 5-174

## 5.17 Un-install Web Control

You can use web un-install tool "uninstall web.bat" to un-install web control.

Please note, before you un-installation, please close all web pages, otherwise the un-installation might result in error

# 6 Glossary

- **DHCP:** DHCP (Dynamic Host Configuration Protocol) is a network protocol. It is one of the TCP/IP protocol cluster. It is principally used to assign temporary IP addresses to computers on a network.
- **DDNS:** DDNS (Dynamic Domain Name Server) is a service that maps Internet domain names to IP addresses. This service is useful to anyone who wants to operate a server (web server, mail server, ftp server and etc) connected to the internet with a dynamic IP or to someone who wants to connect to an office computer or server from a remote location with software.
- **eSATA**: eSATA(External Serial AT) is an interface that provides fast data transfer for external storage devices. It is the extension specifications of a SATA interface.
- **GPS:** GPS (Global Positioning System) is a satellite system, protected by the US military, safely orbiting thousands of kilometers above the earth.
- **PPPoE: PPPoE** (Point to Point Protocol over Ethernet) is a specification for connecting multiple computer users on an Ethernet local area network to a remote site. Now the popular mode is ADSL and it adopts PPPoE protocol.
- Wi-Fi: Wi-Fi is the name of a popular wireless networking technology that uses radio waves to provide wireless high-speed Internet and network connections. The standard is for wireless local area networks (WLANs). It is like a common language that all the devices use to communicate to each other. It is actually IEEE802.11, a family of standard The IEEE (Institute of Electrical and Electronics Engineers Inc.)
- **3G:** 3G is the wireless network standard. It is called 3G because it is the third generation of cellular telecom standards. 3G is a faster network for phone and data transmission and speed Is over several hundred kbps. Now there are four standards: CDMA2000, WCDMA, TD-SCDMA and WiMAX.
- **Dual-stream:** The dual-stream technology adopts high-rate bit stream for local HD storage such as QCIF/CIF/2CIF/DCIF/4CIF encode and one low-rate bit stream for network transmission such as QCIF/CIF encode. It can balance the local storage and remote network transmission. The dual-stream can meet the difference band width requirements of the local transmission and the remote transmission. In this way, the local transmission using high-bit stream can achieve HD storage and the network transmission adopting low bit stream suitable for the fluency requirements of the 3G network such as WCDMA, EVDO, TD-SCDMA..
- **On-off value:** It is the non-consecutive signal sampling and output. It includes remote sampling and remote output. It has two statuses: 1/0.

# 7 FAQ

Questions	Solutions				
NVR cannot boot up	Input power is not correct.				
properly.	Power connection is not correct.				
	• Power switch button is damaged.				
	Program upgrade is wrong.				
	• HDD malfunction or something wrong with HDD ribbon.				
	• Seagate DB35.1, DB35.2, SV35 or Maxtor 17-g has compatibility				
	problem. Please upgrade to the latest version to solve this				
	problem.				
	Front panel error.				
	Main board is damaged.				
	<ul> <li>Input voltage is not stable or it is too low.</li> </ul>				
NVR often automatically	• HDD malfunction or something wrong with the ribbon.				
shuts down or stops	• Button power is not enough.				
running.	<ul> <li>Front video signal is not stable.</li> </ul>				
	<ul> <li>Working environment is too harsh, too much dust.</li> </ul>				
	Hardware malfunction.				
System cannot detect	• HDD is broken.				
hard disk.	HDD ribbon is damaged.				
	HDD cable connection is loose.				
	Main board SATA port is broken.				
There is no video output	Program is not compatible. Please upgrade to the latest version.				
whether it is one-channel,	Brightness is 0. Please restore factory default setup.				
multiple-channel or	Check your screen saver.				
all-channel output.	NVR hardware malfunctions.				
	HDD ribbon is damaged.				
I cannot search local	• HDD is broken.				
records.	Upgraded program is not compatible.				
	• The recorded file has been overwritten.				
	Record function has been disabled.				
	<ul> <li>Video quality setup is too low.</li> </ul>				
Video is distorted when	• Program read error, bit data is too small. There is mosaic in the full				
searching local records.	screen. Please restart the NVR to solve this problem.				
	HDD data ribbon error.				
	HDD malfunction.				
	NVR hardware malfunctions.				
Time display is not	Setup is not correct				
Time display is not correct.	<ul> <li>Battery contact is not correct or voltage is too low.</li> </ul>				
	Crystal is broken.				

Questions	Solutions			
NVR cannot control PTZ.	<ul> <li>Front panel PTZ error</li> <li>PTZ decoder setup, connection or installation is not correct.</li> <li>Cable connection is not correct.</li> <li>PTZ setup is not correct.</li> <li>PTZ decoder and NVR protocol is not compatible.</li> <li>PTZ decoder and NVR address is not compatible.</li> <li>When there are several decoders, please add 120 Ohm between the PTZ decoder A/B cables furthest end to delete the reverberation or impedance matching. Otherwise the PTZ control is not stable.</li> </ul>			
I cannot log in client-end or web.	<ul> <li>The distance is too far.</li> <li>For Windows 98 or Windows ME user, please update your system to Windows 2000 sp4. Or you can install client-end software of lower version. Please note right now, our NVR is not compatible with Windows VISTA control.</li> <li>ActiveX control has been disabled.</li> <li>No dx8.1 or higher. Please upgrade display card driver.</li> <li>Network connection error.</li> <li>Network setup error.</li> <li>Password or user name is invalid.</li> <li>Client-end is not compatible with NVR program.</li> </ul>			
There is only mosaic no video when preview or playback video file remotely.	<ul> <li>Network fluency is not good.</li> <li>Client-end resources are limit.</li> <li>Current user has no right to monitor.</li> </ul>			
Network connection is not stable.	<ul> <li>Network is not stable.</li> <li>IP address conflict.</li> <li>MAC address conflict.</li> <li>PC or device network card is not good.</li> </ul>			
Burn error /USB back error.	<ul> <li>Burner and NVR are in the same data cable.</li> <li>System uses too much CPU resources. Please stop record first and then begin backup.</li> <li>Data amount exceeds backup device capacity. It may result in burner error.</li> <li>Backup device is not compatible.</li> <li>Backup device is damaged.</li> </ul>			
Keyboard cannot control NVR.	<ul> <li>NVR serial port setup is not correct</li> <li>Address is not correct</li> <li>When there are several switchers, power supply is not enough.</li> <li>Transmission distance is too far.</li> </ul>			

Questions	Solutions
Alarm signal cannot been disarmed.	<ul> <li>Alarm setup is not correct.</li> <li>Alarm output has been open manually.</li> <li>Input device error or connection is not correct.</li> <li>Some program versions may have this problem. Please upgrade your system.</li> </ul>
Alarm function is null.	<ul> <li>Alarm setup is not correct.</li> <li>Alarm cable connection is not correct.</li> <li>Alarm input signal is not correct.</li> <li>There are two loops connect to one alarm device.</li> </ul>
Record storage period is not enough.	<ul> <li>Camera quality is too low. Lens is dirty. Camera is installed against the light. Camera aperture setup is not correct.</li> <li>HDD capacity is not enough.</li> <li>HDD is damaged.</li> </ul>
Cannot playback the downloaded file.	<ul> <li>There is no media player.</li> <li>No DXB8.1 or higher graphic acceleration software.</li> <li>There is no DivX503Bundle.exe control when you play the file transformed to AVI via media player.</li> <li>No DivX503Bundle.exe or ffdshow-2004 1012 .exe in Windows XP OS.</li> </ul>
Forgot local menu operation password or network password	<ul> <li>Please contact your local service engineer or our sales person for help. We can guide you to solve this problem.</li> </ul>
There is no video. The screen is in black.	<ul> <li>IPC IP address is not right.</li> <li>IPC port number is not right.</li> <li>IPC account (user name/password) is not right.</li> <li>IPC is offline.</li> </ul>
The displayed video is not full in the monitor.	Please cheek current resolution setup. If the current setup is 1920*1080, then you need to set the monitor resolution as 1920*1080.
There is no HDMI output.	<ul><li>Displayer is not in HDMI mode.</li><li>HDMI cable connection is not right.</li></ul>
The video is not fluent when I view in multiple-channel mode from the client-end.	<ul> <li>The network bandwidth is not sufficient. The multiple-channel monitor operation needs at least 100M or higher.</li> <li>Your PC resources are not sufficient. For 16-ch remote monitor operation, the PC shall have the following environment: Quad Core, 2G or higher memory, independent displayer, display card memory 256M or higher.</li> </ul>

Questions	Solutions		
I can not connect to the IPC	<ul> <li>Please make sure the IPC has booted up.</li> <li>IPC network connection is right and it is online</li> <li>IPC IP is in the blacklist.</li> <li>The device has connected to the too many IPC. It cannot transmit the video.</li> <li>Check the IPC port value and the time zone is the same as the NVR.</li> <li>Make sure current network environment is stable.</li> </ul>		
After I set the NVR resolution as 1080P, my monitor can not display.	<ul> <li>Make sure current network environment is stable.</li> <li>Shut down the device and then reboot. When you reboot, please press the Fn button at the same time and then release after 5 seconds. You can restore NVR resolution to the default setup.</li> </ul>		
My admin account has been changed and I can not log in.	Use telnet and then input the following command: cd /mnt/mtd/Config/ rm -rf group rm -rf password Reboot the device to restore the default password.		
After I login the Web, I can not find the remote interface to add the IPC.	1		
There is IP and gateway, I can access the internet via the router. But I can not access the internet after I reboot the NVR.	or not. Use telnet to access and then use command "ifconfig –a" to check device IP address. If you see the subnet mask and the gateway		
I use the VGA montior.I want to know if I use the multple-window mode, I see the video from the main stream or the sub stream?	<ul> <li>For 32-channel series product, the 9/16-window is using the s stream.</li> <li>For 4/8/16 series product, system is using the main stream not</li> </ul>		

# **Daily Maintenance**

- Please use the brush to clean the board, socket connector and the chassis regularly.
- The device shall be soundly earthed in case there is audio/video disturbance. Keep the device away from the static voltage or induced voltage.
- Please unplug the power cable before you remove the audio/video signal cable, RS232 or RS485 cable.
- Do not connect the TV to the local video output port (VOUT). It may result in video output circuit.
- Always shut down the device properly. Please use the shutdown function in the menu, or you can press the power button in the rear pane for at least three seconds to shut down the device.

Otherwise it may result in HDD malfunction.

- Please make sure the device is away from the direct sunlight or other heating sources. Please keep the sound ventilation.
- Please check and maintain the device regularly.

## 8 Appendix A HDD Capacity Calculation

Calculate total capacity needed by each device according to video recording (video recording type and video file storage time).

Step 1: According to Formula (1) to calculate storage capacity  $q_i$  that is the capacity of each channel needed for each hour, unit Mbyte.

$$q_i = d_i \div 8 \times 3600 \div 1024 \tag{1}$$

In the formula:  $d_i$  means the bit rate, unit Kbit/s

Step 2: After video time requirement is confirmed, according to Formula (2) to calculate the storage capacity  $m_i$ , which is storage of each channel needed unit Mbyte.

$$m_i = q_i \times h_i \times D_i \tag{2}$$

In the formula:

 $h_i$  means the recording time for each day (hour)

 $D_i$  means number of days for which the video shall be kept

Step 3: According to Formula (3) to calculate total capacity (accumulation)  $q_T$  that is needed for all channels in the device during **scheduled video recording**.

$$q_T = \sum_{i=1}^{c} m_i \tag{3}$$

In the formula: *c* means total number of channels in one device

Step 4: According to Formula (4) to calculate total capacity (accumulation)  $q_T$  that is needed for all channels in device during **alarm video recording (including motion detection)**.

$$q_T = \sum_{i=1}^{c} m_i \times a\% \tag{4}$$

In the formula:a% means alarm occurrence rate

# 9 Appendix B Compatible Network Camera List

Please note all the models in the following list for reference only. For those products not included in the list, please contact your local retailer or technical supporting engineer for detailed information.

Manufact	Model	Version	Video Encode	Audio/Vid	Protocol
ure				eo	
AXIS	P1346	5.40.9.2	H264	$\checkmark$	ONVIF/Private
	P3344/P3344-	5.40.9.2	H264	$\checkmark$	ONVIF/Private
	Е				
	P5512	—	H264	$\checkmark$	ONVIF/Private
	Q1604	5.40.3.2	H264	$\checkmark$	ONVIF/Private
	Q1604-E	5.40.9	H264	$\checkmark$	ONVIF/Private
	Q6034E	—	H264	$\checkmark$	ONVIF/Private
	Q6035	5.40.9	H264	$\checkmark$	ONVIF/Private
	Q1755	—	H264	$\checkmark$	ONVIF/Private
	M7001	—	H264	$\checkmark$	Private
	M3204	5.40.9.2	H264	$\checkmark$	Private
	P3367	HEAD LFP4_0	H264	$\checkmark$	ONVIF
		130220			
	P5532-P	HEAD LFP4_0	H264	$\checkmark$	ONVIF
		130220			
ACTi	ACM-3511	A1D-220-V3.12	MPEG4	$\checkmark$	Private
		.15-AC			
	ACM-8221	A1D-220-V3.13	MPEG4	$\checkmark$	Private
		.16-AC			
Arecont	AV1115	65246	H264	$\checkmark$	Private
	AV10005DN	65197	H264	$\checkmark$	Private
	AV2115DN	65246	H264	$\checkmark$	Private
	AV2515DN	65199	H264	$\checkmark$	Private
	AV2815	65197	H264	$\checkmark$	Private
	AV5115DN	65246	H264	$\checkmark$	Private
	AV8185DN	65197	H264	$\checkmark$	Private
Bosch	NBN-921-P	—	H264	$\checkmark$	ONVIF
	NBC-455-12P	—	H264	$\checkmark$	ONVIF
	VG5-825	9500453	H264	$\checkmark$	ONVIF
	NBN-832	66500500	H264	$\checkmark$	ONVIF
	VEZ-211-IWT	—	H264	$\checkmark$	ONVIF
	EIVA				
	NBC-255-P	15500152	H264	$\checkmark$	ONVIF
	VIP-X1XF		H264	$\checkmark$	ONVIF
Brikcom	B0100		H264	$\checkmark$	ONVIF
	D100	—	H264	$\checkmark$	ONVIF
	GE-100-CB	_	H264	$\checkmark$	ONVIF
	FB-100A	v1.0.3.9	H264	$\checkmark$	ONVIF
	FD-100A	v1.0.3.3	H264	$\checkmark$	ONVIF

Manufact	Model	Version	Video Encode	Audio/Vid	Protocol
ure				ео	
Cannon	VB-M400	—	H264	$\checkmark$	Private
CNB	MPix2.0DIR	XNETM112011 1229	H264	$\checkmark$	ONVIF
	VIPBL1.3MIR VF	XNETM210011 1229	H264	V	ONVIF
	IGC-2050F	XNETM210011 1229	H264	$\checkmark$	ONVIF
CP PLUS	CP-NC9-K	6.E.2.7776	H264	$\checkmark$	ONVIF/Private
	CP-NC9W-K	6.E.2.7776	H264	$\checkmark$	Private
	CP-ND10-R	cp20111129AN S	H264	V	ONVIF
	CP-ND20-R	cp20111129AN S	H264	V	ONVIF
	CP-NS12W-C R	cp20110808NS	H264	$\checkmark$	ONVIF
	VS201	cp20111129NS	H264	$\checkmark$	ONVIF
	CP-NB20-R	cp20110808BN S	H264	$\checkmark$	ONVIF
	CP-NT20VL3- R	cp20110808BN S	H264	$\checkmark$	ONVIF
	CP-NS36W-A R	cp20110808NS	H264	$\checkmark$	ONVIF
	CP-ND20VL2- R	cp20110808BN S	H264	$\checkmark$	ONVIF
	CP-RNP-1820	cp20120821NS A	H264	$\checkmark$	Private
	CP-RNC-TP2 0FL3C	cp20120821NS A	H264	$\checkmark$	Private
	CP-RNP-12D	cp20120828AN S	H264	$\checkmark$	Private
	CP-RNC-DV1 0	cp20120821NS A	H264	$\checkmark$	Private
	CP-RNC-DP2 0FL2C	cp20120821NS A	H264	$\checkmark$	Private
Dynacolor	ICS-13	d20120214NS	H264	$\checkmark$	ONVIF/Private
	ICS-20W	vt20111123NSA	H264	$\checkmark$	ONVIF/Private
	NA222	—	H264	$\checkmark$	ONVIF
	MPC-IPVD-03 13	k20111208ANS	H264	$\checkmark$	ONVIF/Private
	MPC-IPVD-03 13AF	k20111208BNS	H264	$\checkmark$	ONVIF/Private
Honeywell	HIDC-1100PT	h.2.2.1824	H264	$\checkmark$	ONVIF
	HIDC-1100P	h.2.2.1824	H264	$\checkmark$	ONVIF

Manufact	Model	Version	Video Encode	Audio/Vid	Protocol
ure				ео	
	HIDC-0100P	h.2.2.1824	H264	$\checkmark$	ONVIF
	HIDC-1300V	2.0.0.21	H264	$\checkmark$	ONVIF
	HICC-1300W	2.0.1.7	H264	$\checkmark$	ONVIF
	HICC-2300	2.0.0.21	H264	$\checkmark$	ONVIF
	HDZ20HDX	H20130114NS A	H264	$\checkmark$	ONVIF
LG	LW342-FP	—	H264	$\checkmark$	Private
	LNB5100	—	H264		ONVIF
Imatek	KNC-B5000	—	H264	$\checkmark$	Private
	KNC-B5162	—	H264	$\checkmark$	Private
	KNC-B2161	—	H264	1	Private
Panasonic	NP240/CH	—	MPEG4		Private
	WV-NP502	—	MPEG4	$\checkmark$	Private
	WV-SP102H	1.41	H264	$\checkmark$	ONVIF/Private
	WV-SP105H	—	H264	$\checkmark$	ONVIF/Private
	WV-SP302H	1.41	H264、MPEG4	$\checkmark$	ONVIF/Private
	WV-SP306H	1.4	H264、MPEG4		ONVIF/Private
	WV-SP508H	—	H264、MPEG4		ONVIF/Private
	WV-SP509H	_	H264、MPEG4		ONVIF/Private
	WV-SF332H	1.41	H264、MPEG4		ONVIF/Private
	WV-SW316H	1.41	H264、MPEG4	$\checkmark$	ONVIF/Private
	WV-SW355H	1.41	H264、MPEG4	$\checkmark$	ONVIF/Private
	WV-SW352H	—	H264、MPEG4	$\checkmark$	ONVIF/Private
	WV-SW152E	1.03	H264、MPEG4	$\checkmark$	ONVIF/Private
	WV-SW558H	—	H264、MPEG4	$\checkmark$	ONVIF/Private
	WV-SW559H	—	H264、MPEG4	$\checkmark$	ONVIF/Private
	WV-SP105H	1.03	H264、MPEG4	$\checkmark$	ONVIF/Private
	WV-SW155E	1.03	H264、MPEG4	$\checkmark$	ONVIF/Private
	WV-SF336H	1.44	H264、MPEG4	$\checkmark$	ONVIF/Private
	WV-SF332H	1.41	H264、MPEG4	$\checkmark$	ONVIF/Private
	WV-SF132E	1.03	H264、MPEG4	$\checkmark$	ONVIF/Private
	WV-SF135E	1.03	H264、MPEG4	$\checkmark$	ONVIF/Private
	WV-SF346H	1.41	H264、MPEG4	$\checkmark$	ONVIF/Private
	WV-SF342H	1.41	H264、MPEG4	$\checkmark$	ONVIF/Private
	WV-SC385H	1.08	H264、MPEG4	$\checkmark$	ONVIF/Private
	WV-SC386H	1.08	H264、MPEG4	$\checkmark$	ONVIF/Private
	WV-SP539	1.66	H264、MPEG4	$\checkmark$	ONVIF
	DG-SC385	1.66	H264、MPEG4	$\checkmark$	ONVIF
PELCO	IXSOLW	1.8.1-20110912 -1.9082-A1.661 7	H264	1	Private
	IDE20DN	1.7.41.9111-O3 .6725	H264	√	Private

Manufact	Model	Version	Video Encode	Audio/Vid	Protocol
ure				ео	
	D5118	1.7.8.9310-A1.	H264	$\checkmark$	Private
		5288			
	IM10C10	1.6.13.9261-O2	H264	$\checkmark$	Private
		.4657			
	DD4N-X	01.02.0015	MPEG4	$\checkmark$	Private
	DD423-X	01.02.0006	MPEG4		Private
	D5220	1.8.3-FC2-2012	H264	$\checkmark$	Private
		0614-1.9320-A			
		1.8035			
Samsung	SNB-3000P	2.41	H264、MPEG4	$\checkmark$	ONVIF/Private
	SNP-3120	1.22_110120_1	H264、MPEG4	$\checkmark$	ONVIF/Private
	SNP-3370	1.21_110318	MPEG4	$\checkmark$	Private
	SNB-5000	2.10_111227	H264、MPEG4	$\checkmark$	ONVIF/Private
	SND-5080	_	H264、MPEG4	$\checkmark$	Private
	SNZ-5200	1.02_110512	H264、MPEG4	$\checkmark$	ONVIF/Private
	SNP-5200	1.04_110825	H264、MPEG4	$\checkmark$	ONVIF/Private
	SNB-7000	1.10_110819	H264	$\checkmark$	ONVIF/Private
	SNB-6004	V1.0.0	H264	$\checkmark$	ONVIF
Sony	SNC-DH110	1.50.00	H264	$\checkmark$	ONVIF/Private
	SNC-CH120	1.50.00	H264	$\checkmark$	ONVIF/Private
	SNC-CH135	1.73.01	H264	$\checkmark$	ONVIF/Private
	SNC-CH140	1.50.00	H264	$\checkmark$	ONVIF/Private
	SNC-CH210	1.73.00	H264	$\checkmark$	ONVIF/Private
	SNC-DH210	1.73.00	H264	$\checkmark$	ONVIF/Private
	SNC-DH240	1.50.00	H264	$\checkmark$	ONVIF/Private
	SNC-DH240-T	1.73.01	H264	$\checkmark$	ONVIF/Private
	SNC-CH260	1.74.01	H264	$\checkmark$	ONVIF/Private
	SNC-CH280	1.73.01	H264	$\checkmark$	ONVIF/Private
	SNC-RH-124	1.73.00	H264	$\checkmark$	ONVIF/Private
	SNC-RS46P	1.73.00	H264	$\checkmark$	ONVIF/Private
	SNC-ER550	1.74.01	H264	$\checkmark$	ONVIF/Private
	SNC-ER580	1.74.01	H264	$\checkmark$	ONVIF/Private
	SNC-ER580	1.78.00	H264	$\checkmark$	ONVIF
	SNC-VM631	1.4.0	H264	$\checkmark$	ONVIF
	WV-SP306	1.61.00	H264、MPEG4	$\checkmark$	SDK
	WV-SP306	1.61.00	H264	$\checkmark$	ONVIF
	SNC-VB600	1.5.0	H264	$\checkmark$	Private
	SNC-VM600	1.5.0	H264	$\checkmark$	Private
	SNC-VB630	1.5.0	H264	$\checkmark$	Private
	SNC-VM630	1.5.0	H264	$\checkmark$	Private
SANYO	VCC-HDN400	—	H264	$\checkmark$	ONVIF
	0PC				

#### Note

- This manual is for reference only. Slight difference may be found in the user interface.
- All the designs and software here are subject to change without prior written notice.
- All trademarks and registered trademarks are the properties of their respective owners.
- If there is any uncertainty or controversy, please refer to the final explanation of us.
- Please visit our website or contact your local service engineer for more information.